



No.1/1991.

BULLETIN

A. TECHNICAL INFORMATION

10.00	ENGINE
20.00	TRANSMISSION
30.00	BRAKES
40.00	STEERING AND SUSPENSIONS
50.00	VENTILATION AND HEATING
60.00	IGNITION AND ELECTRICAL SYSTEM
70.00	OUTER BODY COMPONENTS
80.00	INTERIOR TRIM
90.00	TOOLS

HOW TO USE THIS CATALOG

I INTRODUCTION

This catalog is designed to identify parts on a vehicle. Once correctly identified, the parts may be obtained from stock or purchased.

There are two ways to use the catalog to identify parts:

- Illustration
- Parts list

To simplify the identification process, two cross-referance listings are provided at the beginning of the catalog. The first listing specifies a main parts group, a more detailed subgroup and a description of the subgroup. The second listing specifies the main parts group, a description of the subgroup (in alphabetical order within main group) and shows the subgroup number. For example, the main group for engines is 10.00.

The subgroup for an oil pump is 13.02. To find the oil pump part number, either the subgroup illustration or parts numerical listing can be searched.

The specific instructions for locating parts follow.

II HOW TO IDENTIFY SERVICE PARTS

An accurate identification of the service part is critical in assuring that a proper vehicle repair is made.

A. Consult the definitions index and find the appropriate main group.

B. Locate the desired subgroup associated with the main group. This can be done either with the numerical index or the alphabetical index.

C. With the subgroup identified, go to the subgroup illustration page and find the specific part required.

D. If the part number is known, the numerical listing can be utilized to find the subgroup number. With this number, the illustration can be analyzed for any associated parts that might be needed.

III. ILLUSTRATIONS

A. Illustrations show the service parts of each subgroup.

B. The page title is at the lower middle section of the page and includes the master component part number (when applicable).

C. The subgroup is located at the bottom R/H corner of each illustration. Also listed is the page number within the subgroup, (when applicable) and the date the illustration page was issued.

IV. SERVICE PART NOTIFICATIONS

3.25. 4204141 — Indicates part dimension is 3.25 mm/example-valve adjusting shim 3.25 mm in thickness).

+ 0,2 1900525 — Indicates part is oversized (example-piston +0,2 mm oversized).

— 0,254 1301911 — Indicates part is undersized).

1-66.14 — Assembly whose component parts are listed on subgroup 66.14.

- 1 — Indicate engineering change has taken place.
 Part indicated with preceding letter (* 1) has been changed.
 New part is designated with preceding letter (* 2).
- S—1343056=8 (nx2)+9(nx2) — Indicates a kit. In this case S=part designated with
 no. 8(1610547) — quantity 2 pieces and part designated
 with no 9 (1610548) — quantity 2 pieces.
- S=A(11.03)+B(11.05) — S indicates a kit. In this case S=all parts designated A
 on subgroup 11.03 and all parts designated B on subgroup
 11.05.
- L = left hand
 application — All parts that have a left and right designation are noted by
 a 1 or r. lefthand being the driver side of the car.
- R = right hand
 application
- RM — Indicates the reverse gear in the transmission.
- 1a, 2a — Indicates the 1 st gear, etc, of the transmission.
- mm — Indicates that part is sold in cut lengths measured by the
 millimetre
- IP 20, IP 60 — Indicates interior trim color
 — IP 20 Indicates CAMEL
 — IP 60 Indicates DOVE GRAY

V. MISCELLANEOUS

This section lists data relevant to bearing dimensions electrical cables, terminals and terminal boots.

GROUP DEFINITIONS

Main Group	Sub Group	Description
10-00		Engine
	10.01	Engine and Supports
	11.01	Engine and Cylinder Head Components
	11.02	Oil Pan and Crankcase Covers
	11.03	Crankshaft and Flywheel
	11.05	Connecting Rods and Pistons
	11.06	Camshaft Drive and Components
	11.07	Camshaft and Valve Train Components
	11.15	Engine Drive Belts
	12.01	Fuel Tank and Fuel Lines
	12.02	Fuel Tank and Fuel Lines
	12.02/1	Fuel Tank and Fuel Lines
	12.04/1	Carburetor
	12.04/2	Air Filter Assembly
	12.05	Air Filter Element
	12.21	Accelerator Pedal and Linkage
	12.54	Intake and Exhaust Manifolds
	12.56	Exhaust System Components
	12.58	Air diverter Valve
	12.59	Pressure Transducer
	12.60	Altitude Compensator
	12.61	Relation Improving Exhaust Gas Scheme
	12.62	Air Pump
	13.01	Oil Filter and Lubrication System
	13.02	Oil Pump
	14.01	Radiator and Overflow Tank
	14.02	Water Pump, Thermostat and Lines
	14.03	Water Pump Components
	14.09	Radiator Cooling Fan
20-00		Transmission
	21.01	Clutch Pedal and Clutch Release System
	21.05	Clutch Assembly
	22.01	Transmission and Differential Unit
	22.04	Transmission Components
	22.07	Gearshift Lever and Components
	22.10	Gearshift Linkage and Inner Control
	22.24	Speedometer Cable and Drive Gear
	24.01	Axle Shafts
	24.04	Differential Gears
30-00		Brakes
	31.01	Brake Pedal Assembly
	31.02	Brake Hydraulic System
	31.04	Brake Action Compensator Control
	31.06	Brake Master Cylinder
	31.07	Wheel Cylinder
	31.10	Brake Action Compensator
	31.31	Front Wheel Brake Caliper
	31.32	Rear Wheel Brake Components
	31.35	Parking Brake Control

Main Group	Sub Group	Description
40.00		Steering and Suspensions
	42.01	Steering Gear
	42.02	Steering Box
	42.10	Steering Linkage
	43.01	Front Suspension Components
	43.02	Front Shock Absorber and Stabilizer Bar
	43.05	Rear Suspension Components
	43.16	Road Wheels
	43.21	Rear Stub Shaft
50.00		Ventilation and Heating
	51.01	Heater Assembly
	51.02	Heater Components
	51.03	Ventilation and Heating Controls
	51.07	Front Windshield Washer System
	51.08	Rear Windshield Washer System
60.00		Ignition and Electrical System
	61.01	Engine Ignition System
	62.01	Starter Motor
	63.01	Alternator Charging System
	64.01/1	Outer Lighting
	64.01/2	Electrical Installation
	65.01	Signalling Devices
	65.03	Instrument Cluster and Operating Indicators
	65.06	Front Windshield Wiper Components
	65.06	Rear Windshoild Wiper Components
	66.03	Alternator 46620183—46624644 (31)
	66.03/1	Alternator 46641386—46641387 (31)
	66.08	Starter Motor 46621390 »Iskra«
	66.08/1	Starter Motor 1616404 »R. Č.«
	66.14	Ignition Distributor Components 46620555
	66.29	Headlamp 46620766 R — 46620828 1
	66.32	Lamp — Back up 46621053 R — 46621054 1
	66.34	Tail Lamp Assembly
	66.35	Lamp — Tail 46621145
	66.65	Front Windshield Wiper Motor 46620216 »PES«
	66.65/1	Front Windshield Wiper Motor 44620603
	66.66	Rear Windshield Wiper Motor 46620891
70.00		Outer Body Components
	71.01	Engine Compartment Lid and Release Cable Assembly
	71.02	Instrument Panel and Relevant Components
	71.04	Inner Body Elements — Frame Components
	71.05	Outer Body Panels
	71.06	Protection Items
	71.09	Front Doors, Door and Trim Panels
	71.15	Rear Door Assembly
	71.18	Front Windshield
	71.19	Rear Quarter Window
	71.25	Outer Trim, Mouldings and Ornaments
	73.01	Front Radiator Grille
	73.06	Front Bumper Assembly
	73.07	Rear Bumper Assembly

Main Group	Sub Group	Description
80.00		Interior Trim and Accessory
	81.01	Front Seats-Covers and Rails
	81.02	Rear Seats-Covers and Release Levers
	81.06	Floor Carpeting
	81.07	Interior Trim and Mirrors
	81.08	Spare Wheel and Tire Jack Mounting Components
	81.09	Insulation
	81.10	Belt — Seat Front/Rear
90.00		Tools
	91.01	Tire Jack and Tool Kit
	91.10	Labels

GROUP DEFINITIONS

Main Group	Sub Group Description	Group Number
Brakes		30.00
	Brake Action Compensator	31.10
	Brake Action Compensator Control	31.04
	Brake Hydraulic System	31.02
	Brake Master Cylinder	31.06
	Brake Pedal Assembly	31.01
	Front Wheel Brake Caliper	31.31
	Front Wheel Brake Components	31.30
	Parking Brake Control	31.35
	Rear Wheel Brake Components	31.32
	Wheel Cylinder	31.07
Engine		10.00
	Accelerator Pedal and Linkage	12.21
	Air Diverter Valve	12.58
	Air Filter Assembly	12.04/2
	Air Filter Element	12.05
	Air Pump	12.62
	Altitude Compensator	12.60
	Camshaft Drive and Components	11.06
	Camshaft and Valve Train Components	11.07
	Carburetor	12.04/1
	Connecting Rods and Pistons	11.05
	Crankshaft and Flywheel	11.03
	Engine/Cylinder Head Components	11.01
	Engine and Supports	10.01
	Engine Drive Belts	11.15
	Exhaust System Components	12.56
	Fuel Pump and Lines	12.02
	Fuel Tank and Fuel Lines	12.01
	Fuel Pump and Lines	12.02/1
	Emission Control Components	12.61
	Intake and Exhaust Manifolds	12.54
	Oil Filter and Lubrication System	13.01
	Oil Pan and Crankcase Covers	11.02
	Oil Pump	13.02
	Radiator Cooling Fan	14.09
	Radiator and Expansion Tank	14.01
	Water Pump Components	14.03
	Water Pump, Thermostat and Cooling Lines	14.02
Ignition and Electrical System		60.00
	Alternator	66.03
	Alternator and Charging System	63.01
	Electrical Installation	64.01/2
	Engine Ignition System	61.01
	Front Windshield Wiper Components	65.05
	Front Windshield Wiper Motor 46620216 »PES«	66.05
	Front Windshield Wiper Motor 46620603	66.65/1
	Headlamp	66.29
	Lamp — Front parking	66.32
	Lamp Back Up	66.33
	Ignition Distributor Components	66.14
	Inner and Outer Lighting	64.01
	Instrument Cluster and Operating Indicators	65.03

Main Group	Sub Group Description	
	Rear Windshield Wiper Components	65.06
	Rear Windshield Wiper Motor	66.66
	Signalling Devices	65.01
	Starter Motor	62.01
	Starter Motor Components	66.08
	Starter Motor 1616404 »R. Č.«	66.08/1
	Tail Lamp Assembly	66.34
	Tail Lamp Assembly 46621145	66.35
Interior Trim and Accessoriess		80.00
	Floor Carpeting	81.06
	Front Seats, Covers and Reils	81.01
	Interior Trim and Mirrors	81.07
	Insulation	81.09
	Rear Seats, Covers and Release Levers	81.02
	Spare Wheel and Jack Mounting Components	81.08
Outer Body Components		70.00
	Engine Comartment Lid and Release	71.01
	Front Bumper Assembly	73.06
	Front Doors, Door Glass and Trim Panels	71.09
	Front Radiator Grille	73.01
	Front Windshield	71.18
	Inner Body Elements-Frame Components	71.04
	Instrument Panel and Relevant Components	71.02
	Oute Body Panels	71.05
	Outer Trim, Mouldings and Ornaments	71.25
	Protection items	71.06
	Rear Bumper Assembly	73.07
	Rear Door Assembly	71.15
	Rear Quarter Window	71.19
Suspension Steering and		40.00
	Front Chock Absorber and Stabilizer Bar	43.02
	Front Suspension Components	43.01
	Rear Stub Shaft	43.21
	Rear Suspension Components	43.05
	Road Wheels	43.16
	Steering Box	42.02
	Steering Gear	42.01
	Steering Linkage	42.10
Tools		90.00
	Jack and Tool Kit	91.01
	Labels	91.10
Transmi- ssion		20.00
	Axle Shafts	24.01
	Clutch Assembly	21.05
	Clutch Pedal and Clutch Release System	21.01
	Differential Gears	24.04
	Gear Shift Lever and Components	22.07
	Gear Shift Linkage and Inner Control	22.10
	Speedometer Cable and Drive Gear	22.24
	Transmission Components	22.04
	Transmission and Differential Unit	22.01

Main Group	Sub Group Description	Group Number
Ventilation and Heating		50.00
	Front Windshield Washer	51.07
	Heater Assembly	51.01
	Heater Components	51.02
	Rear Windshield Washer	51.08
	Ventilation and Heating Controls	51.03

VERSION LIST

CODE No.	MODEL TYPE
79	YUGO GV M 86
27	YUGO GVL (RC-1)
29	YUGO GVL CALIFORNIA
31	YUGO GVX
33	YUGO GVX CALIFORNIA
42	YUGO GV M 87
44	YUGO GVL-5 SPEED
98	YUGO GV CALIFORNIA
22	YUGO GVS — WITH PASSIVE SEAT BELTS
23	YUGO GVS CALIFORNIA — WITH PASSIVE SEAT BELTS
36	YUGO GVL WITHOUT CATAPULT SEATS
38	YUGO GVL WITHOUT CATAPULT SEATS CALIFORNIA
11	YUGO GV — WITH PASSIVE SEAT BELTS
47	YUGO GVL WITHOUT CATAPULT SEATS WITH PASSIVE SEAT BELTS
58	YUGO GV PLUS EFI
48	YUGO CABRIO
50	YUGO GV PLUS EFI WITH AUTOMATIC TRANSMISSION

NOTE: ALL PARTS DESIGNATED CODE (27) ARE VALID FOR ALL MODELS, IF NOT SPECIFICALLY NOTED EXCEPT FOR MODELS (79 AND 98).

PART NUMBER LISTING

Part Number	Subgroup	Illus. №	Description
87230	71.01	20	Band-Hood Release Cable
701390	11.01	6	Screw
701425	12.62	15	Bolt
701475	11.01	20	Head-Cylinder
701480	91.14	3	Label
701487	12.04/1	6	Connection on Carburetor
701596	11.01	20	Head Cclinder
790118	31.30	12	Spring Brake pad Support
791329	31.06	2	Plug-Master Cylinder
809064	31.02	16	Screw-Brake Cclinder
809065	31.02	13	Washer-Brake Cylinder
812877	31.10	2	Washer
814838	81.01/4	14	Fishplate
857808	31.35	10	Spring-Hand Brake Lever
857810	31.35	11	Pin-Hand Brake Lever
872241	21.01	15	Psug-Clutch Pedal
873093	22.10	8	Roller-Shift Fork
874162	12.62	12	Washer
874690	22.01/1	37	Key-Transmission Case
874761	22.10	7	Roller-Shift Fork
877205	11.01	23	Dowel-Transmission case
884162	12.62	12	Washer
890414	43.01	2	Screw-Ball Joint
894040	21.01	3	Ring-Clutch Release Cable
902160	11.03	7	Plate-Thrust (Standard)
902161	11.03	8	Plate-Thrust o 127
970490	43.05	7	Washer-Rear Suspension
972486	31.35	6	Cam-Hand Brake
978832	14.03	15	Ring
983027	22.10	25	Spring-Shift Fork
983028	22.10	27	Casing-Shift Fork
994922	31.02	7	Retainer-Brake Line
994922	31.02	24	Retainer-Brake Line
1014083	14.09	8	Fan-Cooling
1014105	31.02	5	Hose-Front Brake
1014106	31.02	15	Hose-Front Brake
1014824	51.02	3	Radiator-Heater Core Assy
1015548	22.10	6	Screw-Shiet Dog
1015565	12.05	1	Nut-Wing Air Cleaner
1016712	51.02	5	Radijator-Heater
1017176	14.02	1	Sending Unit-Water temp
1017506	65.05	6	Fishplate-Priwiper Motor
1017506	65.06	3	Fishplate-Priwiper Motor
1018076	51.02	13	Motor-Heater
1018650	91.01	1	Kit-Tool*
1018883	66.65	6	Motor-Windshield Wiper
1018889	66.65	5	Gear
1022177	81.10/1	15	Screw
1022602	22.01/1	14	Switch-Back-Up
1022806	81.10/1	11	Screw
1022806	81.11	3	Screw
1023230	81.10/1	4	Screw
1023230	81.11	7	Screw
1024589	12.01	5	Gasket-Fuel Tank Sending Unit
1024628	42.01/1	3	Box-Steering
1024629	41.02	3	Housing
1024632	42.02	10	Plate-Steering Shaft
1024633	42.02	25	Cover-Steering Box
1024634	42.02	11	Gasket-Steering Shaft

Part Number	Subgroup	Illus. №	Description
1024640	42.02	28	Shim 0 10-Steering Box Adjusting
1024641	42.02	27	Shim 0 10-Steering Box Adjusting
1024644	42.02	8	Gasket-Steering Shaft
1024645	42.02	1	Bushing-Steering Rack
1024646	42.02	22	Boot-Steering Rack
1024647	42.02	2	Boot-Steering Rack
1024650	42.02	9	Screw-Steering Shaft
1024651	42.02	7	Shaft-Pinion/Steering
1024652	42.02	12	Ring 0 12
1024653	42.02	13	Ring 0 20
1024654	42.02	14	Ring 0 25
1024655	42.02	15	Ring 0 50
1024656	42.02	29	Seal-Steering Box
1024657	42.02	5	Bering-Steering Shaft
1024658	42.02	6	Rack-Steering
1024659	42.02	30	Plug-Steering Box
1024660	42.02	17	Spring-Steering Rack
1024661	42.02	26	Spring
1024663	42.02	19	Pin-Steering Rack
1024664	42.02	18	Guard-Steering Rack
1024665	42.02	20	Nut-Steering Rack
1024666	42.02	16	Nut-Steering Rack
1026428	31.30	6	Protection-R/H Brake Disc
1026429	31.30	7	Protection-L/H Brake Disc
1026767	71.15	6	Strap-Grab
1026768	71.15	8	Strap-Grab
1119117	71.19	14	Clip-PR/QTR/ Glass Weatherstrip
1300150	31.32	S	Kit-Rear Brake Choe
1301062	12.02	4	Cap-Fuel Pump
1301527	66.08	9	Bushing
1301910	11.03	9	Bearing Set-Crankshaft (Standard)
1301911	11.03	10	Set-Bearing + 0 254 Crankshaft
1301912	11.03	11	Seat-Bearing + 0 508 Crankshaft
1301913	11.03	12	Seat-Bearing 0 762 Crankshaft
1302217	66.03	12	Condenser-Starter Motor
1302349	66.03	13	Plate-Contact
1303678	66.03/1	8	Bearing-Alternator
1303678	66.03	8	Bearing-Alternator
1304541	66.08/1	12	Clip-Starter Motor
1304559	66.08/1	11	Ring-Starter Motor
1304560	66.08/1	10	Drive-Starter
1304561	66.08/1	9	Armature-Starter Motor
1304562	66.08/1	22	Shim-Starter Motor
1304563	66.08/1	21	Shim-Starter Motor
1304564	66.08/1	20	Clip-Starter Motor
1304565	66.08/1	8	Support-Starter Motor
1304566	66.08/1	7	Pin-Starter Motor
1304567	66.08/1	6	Pin-Starter Motor
1304568	66.08/1	5	Fork-Starter Motor
1304569	66.08/1	4	Housing-Starter Motor
1304570	66.08/1	15	Brush-Starter Motor
1304571	66.08/1	16	Spring-Starter Motor
1304572	66.08/1	17	Holder-Brush/Starter
1304573	66.08/1	18	Screw-Starter Motor
1304574	66.08/1	19	Support-Starter Motor
1304575	66.08/1	3	Screw-Starter Motor
1304576	66.08/1	2	Washer-Starter Motor
1304577	66.08/1	1	Nut-Starter Motor
1304578	66.08/1	13	Screw-Starter Motor
1304579	66.08/1	14	Solenoid-Starter Motor

Part Number	Subgroup	Illus. №	Description
1334115	31.07	5	Kit-Master & Wheel Cyl
1334115	31.06	9	Kit-Master & Wheel Cyl
1335102	66.66	4	Gear-Rear Wiper Motor
1335345	66.08	11	Drive-Starter
1335354	66.08	7	Brush-ST
1336015	51.03	16	Cable-Heater/Control
1336016	51.03	17	Cable-Heater/Control
1336030	14.01	10	Tank-Expansion/Radiator
1343056	31.31	S	Kit-Caliper Seal
1343057	31.31	S	Kit-Caliper Rebuild
1450119	13.01	23	Bushing
1450120	13.01	24	Bushing
1450185	13.01	6	Sending-Unit-Oil Pressure
1450260	12.04/1	4	Gasket-Carburetor
1450264	12.04/1	5	Spacer-Carburetor
1450542	11.05/1	2	Bolt-Piston
1450546	61.01	4	Cable Assy
1450573	11.03	2	Crankshaft
1450625	10.01/1	3	Support-Engine
1452583	81.07/1	9	Mirror-Inner Rear View
1452743	81.10/1	13	Washer
1452875	81.11	2	Washer
1452957	81.11	8	Bushing
1452958	81.10/1	12	Washer
1452959	81.10/1	1	Spacer
1453385	81.10/1	5	Belt-Seat Front R/H
1453386	81.10/1	6	Belt-Seat Front L/H
1453393	81.10/1	3	Cover
1453394	81.10/1	14	Center Receptacle
1453398	81.11	1	Belt-Seat Rear
1453404	81.11	6	Belt-Seat Rear
1453506	81.01/4	15	Lever
1453515	81.01/4	13	Cable Release
1453516	81.01/4	4	Cable Release
1453525	81.01/4	25	Spring-Gear Mechanism
1453527	81.01/4	30	Spring-Gear Mechanism
1453528	81.01/4	31	Spring L/H
1453533	81.01/4	23	Washerlock
1453538	81.01/4	26	Lever Activating-Gear Mach R/H
1453539	81.01/4	27	Lever Activating-Gear Mech L/H
1453540	81.01/4	19	Seat Frame R
1453541	81.01/4	19	Seat Frame L
1453548	81.01/4	29	Nut-Gear Mechanisasm/Cat-Seat
1453567	81.01/4	21	Gear Mechanisam-R/H
1453568	81.01/4	22	Gear Mechanisam-L/H
1453650	81.01/4	19	Framing Cushion R/H
1453651	81.01/4	19	Framing Cushtion L/H
1453658	81.01/4	20	Mehan-Bush
1453684	81.01/4	19	Seat Frame R/H
1453685	81.01/4	19	Seat Frame L/H
1454582	66.32	1	Gasket
1454748	66.34	6	Gasket Tail Light Assy
1468897	14.09	1	Ring
1469267	66.33	1	Lens Lamp Back UP R/H
1469268	66.33	2	Lene Lamp Back UP L/H
1469289	51.02	20	Case-Heater
1469294	66.35	5	Support
1469340	66.29	1	Support-Head Lamp R
1469341	66.29	2	Support-Head Lamp L
1469351	66.34	6	Gasket-Tail Light Assy
1469352	66.34	5	Gasket-Tail/Lamo

Part Number	Subgroup	Illus. №	Description
1469400	66.35	3	Gasket-Lamp Tail
1469457	66.65	6	Motor Wiwiper
1469521	51.02	20	Case-Heater
1469610	73.07/1	8	Bar Bumper
1469643	73.06	5	Front Bumper Assembly
1610532	64.01/2	10	Lamp-Interior
1610536	31.30	5	Caliper-Spake L/H Complete
1610537	31.30	4	Caliper-Brake R/H Complete
1610538	31.31	11	Caliper-Brake L/H
1610539	31.31	10	Caliper-Brake R/H
1610542	31.31	1	Support-Brake Caliper
1610544	31.31	2	Clip-Caliper Mount
1610545	31.31	7	Piston-Caliper/Brake
1610546	31.31	5	Chield-Caliper Bleed Screw
1610547	31.31	8	Seal-Caliper
1610548	31.31	9	Seal-Caliper/Brake
1610550	31.31	4	Plate-Caliper Mounting
1610556	31.31	3	Pin-Cotter
1610557	31.31	6	Screw-Brake/Bleed
1610771	14.01	2	Cap-Radiator
1610865	65.03	13	Switch-Parking Brake
1611434	51.02	8	Valve-Heater
1611489	64.01/2	8	Relay-Flasher
1611876	42.02	24	Collar-Steering Rack Boot
1611877	42.02	4	Bracket-Steering Rack Boot
1611878	42.02	21	Bracket-Steering Rack Boot
1611962	64.01/2	20	Relay
1611962	65.01	17	Relay
1612107	64.01/2	6	Relay-Flasher
1612386	66.65	1	Linkage-Wiper Motor
1612392	66.65	8	Link-Wiper
1612399	66.65	2	Link-Wiper
1612401	66.65	4	Link-Wiper
1612403	66.65	7	Link-Wiper
1612711	51.08	7	Plug-Washer Reservoir
1612711	51.07	9	Plug-Washer Reservoir
1612713	51.07	12	Pump-Wind/Washer
1613059	66.66	6	Tie Rod-Wiper Motor
1613090	66.66	3	Casing-Wiper Motor
1613090	65.06	6	Casing-Wiper Motor
1613810	66.65	3	Clip Wiper Arm
1614192	64.01/2	23	Relay
1615349	21.05	1	Plate-Driven
1615415	81.06	5	Plug Mat
1615514	51.01	2	Weatherstrip-Heater
1615808	31.32	3	Support-R/H Rear Brake
1615809	31.32	4	Support-L/H Rear Brake
1615851	42.10	2	End-Tie Rod
1615858	64.01/2	31	Relay Flasher
1615933	71.15	3	Hinge-Assy Rear Hatch
1615962	71.09/2	30	Screw
1615992	51.01	17	Weatherstrip-Heater Box
1616152	71.01	26	Handle
1616404	62.01	1	Motor-Starter
1616518	10.01/1	13	Support-Engine
1616842	51.07	1	Jet-Windshield/Washer
1616842	51.08	1	Jet-Windshield/Washer
1616843	51.07	2	Clip-Windshield Washer Jet
1616843	51.08	2	Clip-Windshield Washer Jet
1616876	71.15	4	Glass-Rear Door
1616942	65.06	2	Arm-Wiper

Part Number	Subgroup	Illus. №	Description
1617156	10.01/1	18	Plate
1617220	64.01/2	7	Relay
1617307	81.10/1	9	Lever R/H
1617308	81.10/1	10	Lever L/H
1617494	12.01	4	Sending Unit-Fuel Tank Level
1617531	43.16	5	Weight-Balance
1617532	43.16	6	Weight-Balance
1617533	43.16	7	Weight-Balance
1617534	43.16	8	Weight-Balance
1617535	43.16	9	Weight-Balance
1617564	73.01	5	Grille-Front/Radiator
1617708	43.16	3	Weight-Balance
1617709	43.16	4	Weight-Balance
1617711	10.01/1	18	Plate
1617811	21.05	4	Cover-Clutch Pressure Plate
1617860	63.01	18	Cable-Battery
1617954	71.09/1	27	Lock
1617955	71.09/1	28	Lock
1618016	81.01	13	Spring Skeleton
1618062	66.66	1	Washer
1618130	65.03	17	Switch-Hazard
1618199	64.01/2	14	Switch-Door Jam Button
1618200	64.01/2	13	Boot-Door Jam Switch
1618222	43.05	32	Bumper-Rear Suspension
1618230	71.04/1	13	Support-Inner Frame
1618267	81.01	34	Plug
1618516	24.01	2	Spider Axle Shaft
1618548	12.01/1	2	Line-Fuel
1618549	12.01/1	3	Line-Fuel Supply
1618550	12.01/1	1	Line-Fuel Supply
1618553	71.25	4	Washer
1618633	21.01	20	Gasket
1618772	31.35	18	Lever-L/H Service Brake
1618773	31.35	17	Lever-R/H Service Brake
1618826	81.07	35	Casing
1618827	81.07	34	Sleeve
1618853	43.16	21	Valve-Tire
1618853	43.16/1	17	Valve-Tire
1618886	81.07	3	Retianer
1618887	81.07	1	Retianer
1618888	81.07	2	Retianer
1618889	31.30	12	Calip-Caliper Mount
1618923	43.16	22	Wheel-Road
1618976	24.01	13	Boot-C V Joint
1618978	24.01	15	Collar-C V Joint Boot
1618987	24.01	23	Shaft-Axle R/H
1618990	24.01	14	Shaft Axle
1618992	24.01	17	Joint-Constant Velocity
1619087	21.05	4	Cover-Clutch Pressure Plate
1619138	24.01	11	Boot-C. V. Joint.
1619140	24.01	16	Ring-Lock
1619208	31.02/2	6	Plate
1619274	71.09/2	3	Csrew
1619278	71.09/2	9	Handle R/H
1619279	71.09/2	10	Handle L/H
1619326	31.02	4	Line-Brake
1619327	31.02	10	Line-Brake
1619631	81.07	23	Pillar-R/H-Rear IP60
1619632	81.07	24	Pillar-L/H-Rear IP60
1619660	22.07/1	2	Spacer
1619662	22.07/1	7	Joint-Flexible

Part Number	Subgroup	Illus. №	Description
1619695	71.09/2	32	Glass-Door
1619696	71.09/2	31	Glass-Door
1619732	91.11	7	Label
1619790	81.07/1	11	Tray-Ach IP20
1619791	81.07/1	12	Tray-Ach IP20
1619800	71.02	16	Faceplate-Console
1619801	71.02	17	Faceplate-Console
1619804	71.02	14	Cover-Steering Column
1619805	71.02	15	Cover-Steering Column
1619818	71.02	18	Panel-IP20
1619819	71.02	19	Panel-IP60
1619820	71.02	20	Console-IP20
1619821	71.02	21	Console-IP60
1619822	71.02	22	Console-Radio/Utility
1619823	71.02	23	Console-Radio/Utility
1619828	71.02	5	Panel-Dash IP20
1619834	71.02	12	Cover-Steering Column
1619835	71.02	13	Cover-Steering Column
1619851	22.07	14	Boot Shift IP60
1619859	22.07	16	Clip-Shift Plate Retainer
1619861	31.01	8	Pedal-Brake
1619864	21.01	24	Pedal-Clutch
1619865	91.11	1	Label
1619869	12.21	3	Pedal-Accelerator
1619882	81.02	11	Panel-Seat Back
1619883	81.07/1	6	Bracket
1619884	81.07/1	8	Support-Mirror
1619885	81.07/1	4	Visor R/H
1619886	81.07/1	10	Visor L/H
1619890	81.01	2	Seat-Front Complete
1619891	81.01	18	Seat-Front Complete
1619892	81.01/1	2	Cover-Seat Back IP60
1619903	81.01/2	2	Cover-Cushion IP60
1619916	66.29	3	Lens-Headlamp
1619918	81.01	1	Seat-Front Complete IP20
1619919	81.01	17	Seat-Front Complete IP20
1619920	65.01	7	Switch-Unit/Steer Column IP20
1619921	65.01	8	Switch-Unit/Steer Column IP60
1619924	81.01/1	1	Cover-Seat Back IP60
1619926	81.01/2	1	Cover-Cushion IP20
1619927	71.05	6	Fender R/H Front
1619928	71.05	5	Fender L/H Front
1619929	71.05	8	Panel-R/H Rear Quarter
1619930	71.05	9	Panel-L/H Rear Quarter
1619931	91.11	3	Label
1619932	91.11	2	Label
1619936	91.12	5	Label
1619937	71.05	7	Panel-Rear
1619945	22.07	13	Boot Shift IP20
1619949	81.01	14	Headreset-IP20
1619949	81.02	9	Headreset-IP20
1619951	81.01	15	Headreset-IP60
1619951	81.02	10	Headreset-IP60
1619954	51.02	13	Motor-Heater
1619966	81.02	1	Seat-Rear Complete
1619967	81.02	2	Seat-Rear Complete
1619968	81.02	15	Cushion-Seat IP20
1619969	81.02	16	Cushion-Seat IP60
1619970	81.02	13	Seat-Back Complete IP20
1619971	81.02	14	Seat-Back Complete IP60
1619972	81.02/2	1	Cover-Seat Back IP20

Part Number	Subgroup	Illus. №	Description
1619973	81.02/2	2	Cover-Seat Back IP60
1619974	81.02/1	1	Cover-Cushion IP20
1619975	81.02/1	2	Cover-Cushion IP60
1619980	51.02	14	Motor-Heater/Assy
1619981	64.01/1	5	Lamp-Side Marker
1619983	64.01/1	10	Lamp,Rear Side Marker
1643844	73.06	8	Reinforcement
1643845	73.07/1	9	Reinforcement
1643846	73.06/1	13	Reinforcement
1643847	73.07	7	Reinforcement
1900501	11.05/3	1	Ring-Piston/Set (STD)
1900525	11.05/3	2	Piston + 0 2
1900526	11.05/3	3	Piston + 0 4
1900527	11.05/3	4	Piston + 0 6
4007478	81.01	7	Pin-Seat Guide
4008928	31.32	8	Cup-Brake Adjuster
4019755	22.07/1	1	Screw-Shift Control Rod
4032794	65.01	11	Washer-Brake Switch
4046512	31.32	7	Pin-Brake Adjuster
4055378	81.01	6	Sleeve-Seat Guide
4056239	22.04/1	14	Ring-Lock/Transmission Bearing
4056690	51.02	11	Nut-Heater Motor
4058800	31.04	16	Clip-Brake Compensator
4058800	22.07/1	10	Clip-Brake Compensator
4058802	31.04	17	Washer-Brake Compensator
4059537	22.10	28	Spring
4062070	63.01	15	Boot-Battery Terminal
4077589	31.02	30	Connection-Brake Line
4078568	31.02	28	Connection-Brake Line
4082895	12.56	4	Clamp-Exhaust Pipe
4085631	14.09	3	Gasket-Fan Sending Unit
4092092	22.04/2	3	Guide
4092094	22.04/2	4	Synchronizer
4092105	22.04/2	7	Band
4094308	81.01	4	Bumper-Seat Guide
4102593	31.35	22	Equalizer-Emergency Brake Cable
4103528	31.01	12	Locktab-Brake Pedal Support
4103996	31.35	16	Pin-Emergency Brake Cable
4105291	51.02	15	Clip-Heater Case
4108077	21.01	12	Bushing-Clutch Release Lever
4108236	14.03	10	Seal
4108237	14.03	7	Seal
4109133	61.01	11	Gasket-Ignition Distributor
4109369	13.02	6	Ring-Oil Pump Drive
4109896	71.09/1	19	Support-Door Lock Rod
4111201	11.03	3	Dowel-Flywheel
4111357	42.01	13	Bolt-Steering Column Support
4112977	71.25	2	Screw
4112977	71.05	2	Screw
4115451	31.06	5	Seal-Master Cylinder
4116766	81.07	31	Strap Tool Kit
4117215	31.02	12	Screw-Brake Line Connection
4118920	22.24	6	Screw-Speedo Drive Gear
4119189	22.04/1	13	Washer-Transmission Gears
4119397	31.35	8	Button-Hand Brake Lever
4119398	31.35	9	Washer-Hand Brake Lever
4120686	22.04/3	5	Seal-Reverse Gear
4120686	21.01	9	Seal-Reverse Gear
4121082	13.02	4	Pin-Oil Pump Drive
4121201	81.07	31	Strap Tool Kit

Part Number	Subgroup	Illus. №	Description
4124504	31.32	9	Spring-Brake Adjuster
4126729	12.56	22	Strap-Hanger Exhaust
4127040	21.01	5	Clip-Throw out Bearing
4127208	51.02	16	Washer-Motor Heater
4129417	61.01	5	Ruber Ring
4129982	13.01	19	Bushing-Oil Pump Drive
4130569	91.01	3	Jack
4130912	14.09	5	Bushing-Radiator Cooling Fan
4130913	14.09	6	Spacer
4130961	13.01	21	Key-Locating
4130961	11.07	3	Key-Locating
4133879	71.09/1	11	Pin-Door Handle
4134900	11.07	8	Spring
4135346	31.10	8	Ring
4136475	31.30	9	Plate-Brake Disc
4138104	81.01/3	2	Spring Skeleton Cushion Seat
4138104	81.01/4	2	Spring Skeleton Cushion Seat
4138439	71.09/2	42	Clip-Window Crank Handle
4138766	14.03	18	Seal
4140833	63.01	6	Washer-Alternator Bracket
4142528	31.32	12	Screw-Brake Disc Back Plate
4142528	31.30	10	Screw-Brake Disc Back Plate
4144275	31.01	13	Pad-Pedal
4144275	21.01	19	Pad-Pedal
4144518	31.35	21	Spacer-Emergency Brake Adjuster
4149974	11.06	9	Cup-Idler Bearing
4149975	11.06	8	Washer-Idler Bearing
4150297	11.05	9	Bolt-Connecting Rod
4150297	11.05/1	3	Bolt-Connecting Rod
4152332	11.06	24	Bolt
4152447	11.07	5	Tappet-Valve
4152448	11.07	31	Shim-Valve Adjust 4 00
4152449	11.07	21	Shim-Valve Adjust 3 50
4152450	11.07	22	Shim-Valve Adjust 3 55
4152451	11.07	23	Shim-Valve Adjust 3 60
4152452	11.07	24	Shim-Valve Adjust 3 65
4152453	11.07	25	Shim-Valve Adjust 3 70
4152454	11.07	26	Shim-Valve Adjust 3 75
4152455	11.07	27	Shim-Valve Adjust 3 80
4152456	11.07	28	Shim-Valve Adjust 3 85
4152457	11.07	29	Shim-Valve Adjust 3 90
4152458	11.07	30	Shim-Valve Adjust 3 95
4152459	11.07	32	Shim-Valve Adjust 4 05
4152460	11.07	33	Shim-Valve Adjust 4 10
4152461	11.07	34	Shim-Valve Adjust 4 15
4152462	11.07	35	Shim-Valve Adjust 4 20
4152463	11.07	36	Shim-Valve Adjust 4 25
4152464	11.07	37	Shim-Valve Adjust 4 30
4152465	11.07	38	Shim-Valve Adjust 4 35
4152466	11.07	39	Shim-Valve Adjust 4 40
4152467	11.07	40	Shim-Valve Adjust 4 45
4152468	11.07	41	Shim-Valve Adjust 4 50
4153891	13.02	5	Spring-Oil Pump
4154550	31.10	4	Ring
4154552	31.10	5	Ring
4156262	81.07	30	Tray
4158100	13.01	9	Gasket-Flame Trap
4158311	71.09/1	26	Plate-Striker
4159642	13.01	4	Trap-Flame
4161222	13.01	2	Gasket-Oil Cap
4162202	31.32	5	Spring

Part Number	Subgroup	Illus. №	Description
4162888	11.07	42	Shim-Valve Adjust 4 55
4162889	11.07	43	Shim-Valve Adjust 4 60
4162890	11.07	44	Shim-Valve Adjust 4 65
4162891	11.07	45	Shim-Valve Adjust 4 70
4164335	71.01	23	Spring-Hood Release
4164496	31.30	3	Bolt
4166194	22.07/1	6	Plate-Gearshift Control
4166592	31.10	6	Spring
4166593	31.10	7	Ring
4166789	11.07	7	Cup-Valve
4169379	42.01/1	5	Bracket-Steering Rack
4169380	41.01/1	4	Bushing-Steering Rack
4169421	22.07/1	3	Washer-Gearshift Control Plate
4170458	11.07	9	Spring-Valve
4170541	22.10	1	Bolt-Shift Dog
4171090	43.05	3	Band-Leaf Spring
4171405	71.01	24	Spring
4176182	81.02	3	Handle
4176840	11.06	5	Belt-Timing
4176872	51.02	6	Gasket-Heater Valve
4177124	65.01	9	Switch-Brake Light
4177449	24.04	19	Ring 0 5
4177450	24.04	20	Ring 0 6
4177451	24.04	21	Ring 0 7
4177452	24.04	22	Ring 0 8
4177453	24.04	23	Ring 0 9
4177454	24.04	24	Ring 1 0
4177455	24.04	25	Ring 1 1
4177456	22.01/1	26	Flange-Transmission
4177457	24.01	6	Cover-C. V. Joing
4177457	24.01	26	Cover-C. V. Joing
4177459	24.04	12	Pinion-Differential
4177459	24.04	15	Pinion-Differential
4177463	24.04	18	Bearing-Differential
4177463	24.04	2	Bearing-Differential
4177465	24.04	5	Shim
4177466	24.04	6	Shim
4177467	24.04	7	Shim
4177468	24.04	8	Shim
4177469	24.04	9	Shim
4177470	24.04	10	Shim
4177471	24.04	11	Shim
4177472	24.01	11	Boot-C. V. Joint
4177785	43.02	20	Spacer-Stabilizer Bar
4177788	43.02	21	Washer-Stabilizer Bar
4177989	51.03	1	Spring-Heater Door
4178140	71.09/1	25	Band-Door Handle/Outer
4178141	71.09/1	24	Band-Door Handle/Outer
4178747	31.10	3	Ring
4178748	31.10	1	Cap
4178800	43.05	4	Gasket Oil Pan
4179038	11.02	11	Spring-Leaf
4179040	11.02	1	Cover-Engine
4179043	11.02	6	Gasket-Timing Cover
4179060	14.02	36	Outlet-Water
4179112	12.02	11	Spacer-Fuel Pump
4179112	12.02/1	10	Spacer-Fuel Pump
4179113	12.02	6	Spacer-Fuel Pump
4179113	12.02/1	5	Spacer-Fuel Pump
4179114	12.02	9	Gasket-Fuel Pump 0 7
4179114	12.02/1	8	Gasket-Fuel Pump 0 7

Part Number	Subgroup	Illus. №	Description
4179116	12.02/1	4	Bracket-Fuel Hose
4179117	11.02	16	Gasket-Cam End
4179138	13.01	18	Gasket-Oil Pump
4179154	14.03	13	Gasket
4179155	14.02	6	Gasket-Water Pump
4179183	14.02	34	Gasket-Thermostat
4179194	11.15	3	Nut-Crankshaft Pulley
4179801	42.01/1	2	Bracket-Steering Rack
4179802	42.01/1	1	Bracket-Steering Rack
4179874	22.01/1	3	Bearing-Pilot
4180207	14.02	15	Connection-Water Line
4180207	14.02	24	Connection-Water Line
4180489	14.02	23	Hose-Water
4183873	22.04/1	9	Key-Trans Synchronizer
4183876	22.04/1	4	Spring-Synchronizer
4183877	22.04/1	8	Guard-Synchronizer Hub
4183888	22.04/1	3	Ring-Lock/Synchronizer
4184495	14.02	32	Gasket-Thermostat
4185496	31.06	6	Bushing-Master Cylinder
4185981	22.10	24	Rod-Shift Control
4186393	22.04/3	9	Plate-Lock/Reverse Shaft
4186493	81.07/1	3	Boot-Assist Handle
4186530	22.01/1	16	Plate
4186531	22.01/1	15	Gasket
4186666	71.09/1	5	Weatherstrip-Door Check
4187379	12.21	4	Pad-Pedal
4188789	43.05	6	Spring-Leaf
4188790	43.05	2	Spring-Leaf
4188797	43.05	17	Bumper-Rear Suspension
4188857	43.02	7	Bolt-Shock Absorber
4190619	21.01	10	Lever-Clutch Release
4190790	22.04/3	3	Bearing-Transmission Shaft
4190790	22.04/2	1	Bearing-Transmission Shaft
4190790	22.04/1	12	Bearing-Transmission Shaft
4191151	42.10	1	Nut-Tie Rod
4191635	14.03	19	Impeller-Water Pump
4191636	14.03	17	Shaft
4191639	14.03	9	Spacer
4193370	51.02	21	Outlet-Heater Case
4193959	14.02	7	Gasket-Water Pump Outlet
4194595	11.03	2	Crankshaft
4194642	13.02	2	Body-Oil Pump
4194644	13.02	3	Plate-Oil Pump
4194648	13.02	10	Gear-Oil Pump
4194651	13.01	22	Shaft-Oil Pump
4194656	13.02	9	Gear-Oil Pump
4194902	51.01	7	Gasket
4195117	11.02	9	Cover-Oil Pump
4195119	11.02	10	Gasket-Engine
4195129	11.01	1	Cover Cam
4195149	12.02/1	6	Rod-Fuel Pump
4195149	12.02	7	Rod-Fuel Pump
4196292	12.56	17	Spacer
4198159	14.02	16	Gasket-Thermostat Housing
4200425	42.01/1	10	Shield-Steering Box
4200619	43.05	5	Bracket-Leaf Spring
4200713	21.01	14	Screw-Clutch Release Lever
4201404	22.10	10	Boot-Shift Rod
4201847	71.09/1	30	Gasket R/H
4201848	71.09/1	29	Gasket L/H
4202351	43.01	12	Cup-Coil Spring

Part Number	Subgroup	Illus. №	Description
4202352	43.01	11	Spring-Coil/Front
4202412	81.01	16	Guide
4202627	43.02	24	Washer-Stabilizer Bar
4202635	14.02	20	Strap-Water Hose
4203475	14.09	2	Shroud-Fan
4203740	22.01/1	9	Chield-Transmission
4204141	11.07	16	Shim-Valve Adjust 3.25
4204142	11.07	17	Shim-Valve Adjust 3.30
4204143	11.07	18	Shim-Valve Adjust 3.35
4204144	11.07	19	Shim-Valve Adjust 3.40
4204145	11.07	20	Shim-Valve Adjust 3. 45
4204212	22.04	1	Bearing-Transmission
4205017	24.01	15	Collar-C. V. Joint Boot
4205319	81.01/3	4	Hook Spring Skeleton Seat
4205663	12.02/1	7	Gasket-Fuel Pump/0.3
4205663	12.02	8	Gasket-Fuel Pump/0.3
4205664	12.02/1	9	Gasket-Fuel Pump/1.2
4205664	12.02	10	Gasket-Fuel Pump/1.2
4206407	51.02	17	Case-Heater
4206471	51.02	12	Blade-Fan
4206516	22.10	3	Lever-Transmission Linkage
4206519	22.10	13	Rod-Transmission Linkage
4206520	22.10	12	Rod-Transmission Shifting
4206774	24.04	13	Gear-Ring/Differential
4207884	31.35	7	Rod-Emergency Brake
4210542	42.01/1	8	Cover-Shaft
4211272	12.56	1	Gasket-Header Pipe
4211978	11.02	15	Cover-Camshaft End
4212140	22.01/1	17	Bolt-Transmission
4212498	71.09/2	11	Washer Glass Vent
4212615	51.03	13	Weatherstrip-Heater Cable
4212738	51.03	6	Plug-Heater Control
4212738	51.03	12	Plug-Heater Control
4214151	61.01	9	Bracket-Ignition Distributor
4214586	22.10	16	Support-Shift Control
4214598	22.10	20	Screw
4214590	22.10	17	Spacer-Shift Control
4216610	11.06	19	Spacer-Timing Belt Tensioner
4217280	13.01	8	Trap-Cyclonic
4218076	11.02	21	Cover-Crankcase Engine
4218077	11.02	22	Gasket-Cover Crankcase
4218079	11.02	23	Cover-Crankcase Engine
4218080	11.02	24	Gasket-Cover Crankcase
4219736	31.02	2	Plate-Lock
4219737	31.02	3	Plate-Lock
4220309	14.02	33	Thermostat
4221815	31.32	10	Stud-Wheel/Locating
4221815	31.30	11	Stud-Wheel/Locating
4222578	71.09/1	21	Plate-Striker R/H
4222579	71.09/1	20	Plate-Striker L/H
4223398	43.05	23	Bolt-Rear Shock
4223580	22.01/1	4	Gasket-Transmission
4223901	11.01	7	Bolt-Cylinder/Head
4223945	51.02	19	Clip
4224377	11.15	2	Belt-Alternator/Water Pump
4224378	63.01	5	Bracket
4224559	14.03	14	Cup
4225256	71.04/1	10	Screw
4227113	43.05	28	Washer-Rear Shock
4227114	43.05	27	Bushing

Part Number	Subgroup	Illus. №	Description
4229610	22.24	2	Support-speedo Drive
4230338	31.06	3	Spring-Master Culinder
4230519	22.24	8	Support-Speedo Drive Gear
4230520	22.24	3	Gear-Driven/Speedo
4230532	22.01/1	22	Gasket
4230797	31.07	3	Valve-Bleed/Wheel-Cyl
4231866	12.01/1	6	Grommet-Fuel Line
4232606	13.01	1	Cap-Oil Filer
4233041	31.35	30	Shield-Emergency/Brake
4233042	31.35	29	Plug-Emergency Brake
4233062	43.02	12	Bushing-Stabilizer Bar
4233064	43.02	11	Bracket-Stabilizer Bar
4233470	43.01	11	Spring-Coil/Front
4235181	12.05	1	Nut-Wing/Air Cleaner
4238373	31.01	10	Pin-Brake Pedal
4239011	63.01	21	Bracket-Battery
4239917	11.07	15	Intake Valve
4240587	43.02	19	Bushing-Stabilizer Bar
4240587	43.02	23	Bushing-Stabilizer Bar
4240624	22.10	34	Dog-Shift*
4240625	22.10	5	Dog-Shift*
4241119	65.03	14	Bracket
4241218	31.06	4	Spring-M/Cylinder
4242487	22.04	3	Bushing-Transmission
4242488	22.04	11	Bushing-Transmission
4242489	22.04/1	2	Bushing-Transmission
4242490	22.04/1	11	Bushing-Transmission
4243293	24.01	19	Ring-Axle Shaft
4243594	14.03	6	Washer
4246743	43.05	24	Bolt-Rear Shock
4247393	24.01	2	Spider-Axle Shaft
4248591	22.01/1	1	Shield-Bell Housing
4248736	31.04	3	Roller-Brake Compensator
4248737	31.04	6	Bar-Sway
4248739	31.04	10	Bracket-Brake Compensator
4248740	31.04	8	Bracket-Brake Compensator
4248742	31.04	15	Ling-Brake Compensator
4248747	31.04	4	Plate-Brake Compensator
4248777	24.01	21	Washer
4248910	43.05	1	Spring-Rear Suspension
4248946	43.01	15	Support-L/H
4248947	43.01	14	Support-R/H
4249329	24.04	1	Case-Differential
4249333	24.04	4	Tab-Lock/Differential
4249840	31.01	9	Spring-Return/Brake Pedal
4249852	43.05	26	Pad
4250995	24.04	3	Bolt-Differential
4251115	43.05	10	Washer-Rear Suspension
4251145	71.19	3	Handle-Rear QTR Window
4252982	71.09/1	8	Ring-Door Hinge
4254944	71.19	8	Bushing-Hinge/Rear Qtr/Window
4255251	22.10	19	Washer-Gearshift Control
4255438	31.04	13	Clip-Brake Comensator
4256384	31.02	17	Plate-Lock/Wheel Cyl
4256385	31.02	18	Plate-Lock/Wheel Cyl
4256493	14.02	28	Housung-Thermostat
4257361	51.02	7	Shield-Heater Core
4257633	51.03	8	Lever-Heater Control
4257634	51.03	5	Lever-Heater Control
4258741	24.01	16	Ring-Lock
4259824	81.01/4	3	Spring Skeleton Cushion

Part Number	Subgroup	Illus. №	Description
4260431	24.01	20	Hub-Axle Shaft
4260749	22.10	11	Bushing-Shift Linkage
4261250	12.56	3	Nut-Exhaust Pipe
4262336	24.04	14	Shaft-Pinion
4262442	13.01	14	Connection-Oil Filter
4263402	65.03	23	Plug
4263780	11.01	24	Bolt-Crankcase
4264257	31.35	31	Clip-Emergency/Brake
4265911	12.56	18	Bushing
4267819	61.01	3	Bumper
4268873	10.01/1	15	Plate-Engine Support
4269482	43.01	1	Washer-Ball Joint
4269585	62.01	7	Cable-Battery Ground
4270741	31.06	7	Seal-Master Cylinder
4272721	11.03	4	Flywheel
4273876	71.09/1	12	Spring-Door Handle
4272979	12.01	20	Gasket-Fuel Drain Hose
4274532	51.03	10	Retainer
4276430	71.01	22	Pad-Hood Panel
4277194	31.07	1	Seal-Wheel Cylinder
4277207	14.01	17	Clip-Radiator/Overflow Hose
4286034	11.01	8	Washer-Lock
4287797	11.01	21	Key
4289140	42.01	12	Washer-Steer/Column Support
4292720	51.03	26	Lockwasher
4294235	71.09/1	10	Gasket-inner Door Handle
4294261	81.09/1	10	Isolation
4296059	12.56	25	Support-Rear Muffler
4296864	71.02	30	Holder-Bulb
4296865	71.02	31	Lens
4297102	14.03	16	Body-Water Pump
4299196	31.01	1	Support
4300225	11.01	11	Gasket-Cam/Cover
4301906	71.04	2	Grommet-Door Jamb
4302267	11.02	18	Gasket-Engine Cover
4302309	24.01	12	Collar-C V Joint Boot
4302786	51.02	4	Weatherstrip-Heater Core
4304626	22.10	9	Rod-Shift Control
4305891	12.01/1	12	Grommet-Fuel Line
4306182	42.10	3	Cup-Tie Rod End
4306439	43.02	13	Bracket-Stabilizer Bar
4307324	43.21	2	Washer
4307325	43.21	3	Nut-Axle Stub
4307325	24.01	22	Nut-Axle Stub
4307442	71.15	16	Cable
4308412	24.01	17	Joint-Constant Velocity
4308418	43.21	1	Shaft-Stubirear
4308871	11.06	22	Shield-Timing Belt
4309031	12.54	6	Gasket-Manifold/Intake-Exhaust
4310029	13.01	20	Gear-Oil Pump
4314869	11.07	14	Valve-Exhaust
4318466	22.07	6	Plate-Shift Control
4318467	22.07	2	Cover-Shift Control
4318468	22.07	5	Seal-Shift Control
4318477	22.07	3	Bushing-Split
4321152	11.01	10	Tower-Cam
4321849	81.07/1	1	Handle-Grab
4322151	22.10	18	Spring-Gearshift Control
4323401	31.02/2	10	Bearings Pilot
4323521	31.02/2	11	Connection
4323541	65.01	5	Spring-Horn Button

Part Number	Subgroup	Ilus. №	Description
4323542	65.01	4	Ring-Lock/Horn Button
4326429	22.01/1	36	Magnet-Trans/Case
4326561	66.32	1	Lens-Tail Lamp
4327158	11.01	12	Gasket-Cam/Tower
4327420	71.04	14	Nut
4327737	65.01	6	Washer
4328364	22.01/1	23	Rung-O Trans Rear
4329658	43.05	9	Rod-Rear Suspension
4331448	71.09/1	1	Pin-Door Hinge
4331968	43.01	5	Bushing-Ball Joint
4332012	31.04	9	Bushhing-Brake Compensator
4333081	24.01	8	Bushing
4333088	24.01	9	Boot-Axle Shaft
4333412	22.07	4	Retainer-Gearshift Control
4333757	12.21	5	Bushing-Accelerator/Pedal
4335139	24.04	5	Ring 0 85
4335140	24.04	6	Ring 0 90
4335141	24.04	7	Ring 0 95
4335142	24.04	8	Ring 1 00
4335143	24.04	9	Ring 1 05
4335144	24.04	10	Ring 1 10
4335145	24.04	11	Ring 1 15
4335312	71.09/1	3	Screw-Door Hinge
4335818	12.02/1	3	Pump-Fuel
4335818	12.02	3	Pump-Fuel
4336372	13.01	25	Dipstick-Oil
4339308	24.01	18	Rearing-Axle
4340338	31.06	1	Bushing
4340878	14.09	4	Switch-Radiator Cooling Fan
4342670	51.03	24	Clip
4342680	51.03	23	Screw
4343527	64.01/2	4	Box-Fuse
4343529	64.01/2	2	Cover Box-Fuse
4346796	61.01	16	Plug-Spark (Shampion)
4347664	22.04	8	Ring-Synchronizer
4348824	71.09/2	8	Washer
4349747	12.02	5	Bracket-Fuel Hose
4351739	22.07/1	11	Retainer-Gearshift Control
4353105	81.09/1	4	Isolation
4355952	51.03	19	Holder-Bulb
4357962	43.16/1	14	Bolt-Wheel
4358713	11.07	1	Camshaft
4358920	31.01	1	Support
4362476	31.06	8	Spring-Master Cylinder
4363024	81.02	6	Sleeve-Channel/Rear Seat
4363896	71.01	25	Lock-Hood
4366271	31.04	14	Bushing-Brake Compensator
4366610	22.04/1	6	Gleeve-Transmission
4366764	22.10	31	Fork-Shift
4367852	22.04	4	Gear (1ST)
4367853	22.04	6	Hub-Transmission
4368286	22.04/2	2	Casing
4369036	71.02	1	Spacer/Panel-Dash
4369037	71.02	2	Shim/Panel-Dash
4371517	11.07	10	Cup-Valve
4371720	22.04	2	Shaft-Transmnssion
4371721	24.04	17	Gear-Differential
4371722	24.04	16	Differential
4372020	11.07	12	Washer-Valve Cup
4372160	11.07	13	Guide-Valve
4372341	31.02/2	4	Cylinder-Brake Master

Part Number	Subgroup	Illus. №	Description
4373596	31.35	14	Shield-Emer/Brake
4373597	31.35	24	Shield-Emer/Brake
4373598	31.35	15	Shield-Emer/Brake
4373599	31.35	23	Shield-Emer/Brake
4373915	71.19	4	Casing
4374564	71.19	5	Washer
4375263	51.03	21	Knob-Heater Control Lever
4375263	71.02	24	Knob-Heater Control Lever
4375415	31.04	18	Support-Brake Compensator
4375474	22.10	33	Fork-Shift
4375691	22.04	8	Ring-Synchronizer
4376750	71.19	9	Plate
4376753	71.19	10	Channel
4376754	71.19	13	Screw
4376755	71.19	11	Washer
4378932	71.09/2	43	Plug Glass
4379275	71.01	5	Pin-Hood Hinge
4379434	21.01	7	Pad-Clutch Release
4379529	14.01	9	Gasket-Radiator Bracket
4379531	14.01	3	Bracket-Support/Radiator
4379664	31.32	6	Spring-Brake Shoe
4379798	31.02/2	1	Cover
4379876	31.02	21	Compensator-Brake Action
4380802	71.09/1	2	Hinge-Door
4381043	43.16	1	Hub
4381043	43.16/1	1	Hub
4381511	31.04	1	Collar-Boot/Brake Comp
4393295	81.01	13	Spring
4383758	24.01	13	Boot-C V Joint
4383759	22.01/1	38	Plug
4384314	14.03	4	Cover
4384494	11.06	15	Wheel-Timing Belt Drive
4385093	81.01	8	Lock-Seat Guide
4385095	81.01	29	Cable-Release/Seat Back
4385778	63.01	12	Cable-Battery
4385812	31.30	8	Rotor-Brake
4386575	11.06	10	Bearing-Idler/Timing Belt
4386905	31.01	2	Gasket-Support/Brake Pedal
4387315	14.01	4	Bushing-Bracket/Rad Support
4387464	71.02	10	Shim/Panel-Dash
4391001	21.01	4	Spring-Clutch Release
4391371	11.02	13	Pan-Oil
4391374	13.01	13	Tube-Oil
4391376	13.01	15	Pump-Oil
4391377	13.02	12	Intake-Oil Pump
4392448	81.02/3	3	Bushing
4392619	22.04	10	Gear (2ND)
4392620	22.04/1	7	Hub-Transmission
4392622	22.04/1	10	Gear (4TH)
4392625	22.04/1	1	Gear (3RD)
4392821	22.10	30	Fork-Shift
4392872	22.04	2	Shaft
4393300	22.04/2	11	Lockwasher
4393742	22.04/2	8	Sleeve
4395662	11.03	6	Washer-Flywheel
4396026	22.01/1	50	Gasket
4396030	22.01/1	41	Gasket
4396386	22.04/3	10	Shaft-Reverse
4397231	71.19	6	Pin
4398499	22.01/1	11	Gasket-Transmission Housing

Part Number	Subgroup	Illus. №	Description
4399276	22.01/1	31	Cover-Trans/Rear
4399777	24.01	20	Hub-Axle Shaft
4400648	63.01	24	Boot-Alternator
4400853	22.01/1	32	Gasket
4400893	43.01	9	Plate-Coil Spring
4400894	43.01	10	Ring-Coil Spring
4400895	43.01	8	Ring-Coil Spring
4400896	43.01	7	Cup-Coil Spring
4400902	43.02	4	Washer-Front Strut
4400904	43.02	2	Washer-Front Strut
4400905	43.02	3	Support-Chock Absorber
4401469	24.01	27	Shaft-Ahle L/H
4401472	24.01	23	Shaft-Ahle R/H
4402134	43.05	13	Support-Rear Leaf Spring
4402361	43.01	6	Joint-Ball/Assy
4402362	43.01	4	Bushing-Ball Joint
4402363	43.01	3	Spacer-Ball Joint
4402475	21.01	1	Sable-Clutch
4402681	31.35	26	Rod-Emergency Brake
4402683	31.35	13	Cable-Emergency Brake
4402688	31.35	13	Cable-Emergency Brake
4404483	31.02	14	Cylinder-Brake
4404597	31.07	2	Seal-Wheel Cylinder
4404601	31.07	4	Spring-Washers-Wheel/Cyl
4404610	10.01/1	5	Washer-Engine
4404622	43.05	12	Bushing
4405031	71.18	2	Windshield
4405040	71.18	1	Weatherstrip
4406754	11.15	4	Pulley
4408148	71.19	1	Glass-R/H Rear QTR
4408149	71.19	2	Glass-L/H Rear QTR
4408340	43.02	5	Boot-Front Strut
4408887	22.10	32	Striker-Plate
4408897	22.10	20	Screw
4409361	21.01	11	Bearing-Throw QUt
4409865	71.09/2	36	Glass-Door R
4409866	71.09/2	37	Glass-Door L
4410279	43.16	2	Cap-Hub
4410279	43.16/1	2	Cap-Hub
4411368	71.09/2	26	Glass-Door R/H
4411369	71.09/2	25	Glass-Door L/H
4411372	71.09/2	39	Weatherstrip-Went Window
4411390	43.16	18	Bolt-Wheel
4411737	22.04/3	12	Nut
4411737	22.04/2	10	Nut
4413051	65.05	7	Bushing-Wiper Arm
4413616	81.01	5	Reinforcement-Front Seat
4413628	81.01	11	Guide-Front Seat
4414024	13.01	7	Bot-Oil Sending Unit
4414407	22.04/2	6	Lockwasher
4414553	71.05	3	Support
4415364	71.05	11	Pillar-Windshield R/H
4415365	71.05	12	Pillar-Windshield L/H
4417667	71.01	39	Rod Stay/Hood
4417668	71.01	1	Hinge-Hood R/H
4417669	71.01	2	Hinge-Hood L/H
4417765	71.01	31	Latch-Hood
4417888	71.09	9	Weatherstrip-Door Glass
4417889	71.09	10	Weatherstrip-Door Glass
4417890	71.09/2	22	Channel-R/H Door Glass
4417891	71.09/2	21	Channel-L/H Door Glass

Part Number	Subgroup	Illus. №	Description
4417900	71.09/1	22	Lever-Door Lock
4418006	71.09/2	38	Plug
4418895	66.32	2	Lens Lamp Front
4418896	66.32	3	Lens Lamp Front
4418972	81.09	2	Isolation
4419573	71.09/2	18	Regulator-Window
4419574	71.09/2	17	Regulator-Window
4420136	71.09/1	16	Rod-Door Lock Control
4420139	71.09/1	17	Rod-Door Lock Control
4420140	71.09/2	20	Channel-Door
4421110	71.09/1	15	Housing
4421389	65.03	6	Gauge-Fuel
4421876	64.01/1	8	Lamp-Tail R/H
4421877	64.01/1	9	Lamp-Tail L/H
4421880	66.34	3	Lamp-Tail R/H
4421881	66.34	4	Lamp-Tail L/H
4423328	65.06	4	Washer-Wiper Motor
4423329	65.06	5	Washer-Wiper Motor
4423581	71.15	5	Strut-Hatch
4424367	71.05	13	Panel-Cowl
4425170	71.15	12	Latch-Rear Door
4425172	71.15	10	Striker-Rear Door
4425325	71.01	26	Handle-Hood Lift
4425435	43.02	10	Bar-Stabilizer
4425843	71.04/1	9	Support-Jack
4426277	12.01/1	7	Line-Fuel
4426278	12.01/1	8	Line-Fuel
4426279	12.01/1	10	Line-Fuel
4426280	12.01/1	11	Sleeve
4426382	14.02	2	Boot-Oil Sending Unit
4426577	11.06	14	Wheel-Drive/Timing Belt
4426627	71.04/1	7	Reinforcement-Rocker Panel
4426628	71.04/1	8	Reinforcement-Rocker Panel
4426629	71.04/1	5	Rail-R/H
4426630	71.04/1	6	Rail-L/H
4426796	81.08	4	Bracket
4426797	81.08	5	Holder
4426873	65.01	3	Spring-Horn Button
4426874	64.01/2	9	Base-Fuse Box
4426882	43.05	8	Arm Swing
4426975	10.01/1	25	Support-Transmission
4427042	71.15	9	Ring-Lock/Rear Hatch
4427087	14.02	35	Hose-Radiator
4427088	14.02	22	Hose-Radiator
4427327	43.05	33	Cap-Shock Absorber
4427328	65.03	24	Housing-Switch
4427329	65.03	28	Housing-Switch
4427334	81.07/1	18	Moulding-Carpet R/H
4427335	81.07/1	19	Moulding-Carpet L/H
4427537	71.01	7	Support-R/H Hood Hinge
4427538	71.01	8	Support-L/H Hood Hinge
4427541	71.01	40	Spring-Hood Stay Rod
4427542	71.01	34	Bracket-Hood Safety Latch
4427543	71.01	19	Cable Hood Release
4427544	71.01	21	Cable-Inner
4427566	81.02/3	5	Lever
4427581	81.02	17	Channel-Rear Seat
4427791	71.04	9	Support-Firewall
4428082	22.24	5	Cable-Speedometer
4428083	22.24	4	Cable-Inner
4428251	71.01	17	Hood-Engine

Part Number	Subgroup	Illus. №	Description
4428825	81.07/1	25	Cable
4428826	81.07/1	27	Clip
4429289	81.09/1	11	Insulation
4429291	81.09	1	Isolation
4429292	81.09	4	Insulation
4429307	51.03	25	Lever
4429308	51.03	29	Lever
4429309	51.03	28	Pin
4429315	81.09/1	1	Isolation
4429395	31.02/2	2	Reservoir-Master Cylinder
4429791	14.01	7	Bracket-Radiator Support
4429943	51.07	6	Hose-Windshield Washer
4429944	51.07	5	Hose-Windshield Washer
4429945	51.07	3	Hose-Windshield Washer
4430079	10.01/1	3	Support-Engine
4430241	71.04/1	1	Ring
4430255	12.01	25	Hose
4430260	12.01	18	Seal-Overflow Hose
4430263	10.01/1	6	Support Engine
4430266	10.01/1	22	Support-Transmission
4430331	10.01/1	21	Washer-Engine Support
4430394	14.01	14	Hose-Radiator Expansion
4430608	12.01	21	Seal-Filler Neck
4430740	12.56	23	Muffler-Center
4430741	12.56	28	Muffler-Rear
4431795	51.02	1	Cover
4431801	51.02	2	Cover
4431807	51.02	18	Cover-Heater Box
4431813	51.03	18	Lever-Heater Control Assy
4432350	22.04/3	1	Bearing-Transmission Shaft
4433619	71.02	7	Screw/Panel-Dash
4433739	71.01	38	Washer
4434526	71.15	11	Lock
4434588	71.09/1	6	Check-Door
4435065	71.04/1	17	Panel Inver/Quarter L/H
4437703	31.35	19	Clip
4437916	81.02	4	Latch-Seat R/H
4437917	81.02	5	Latch-Seat L/H
4437994	81.09/1	6	Isolation
4437995	81.09/1	2	Isolation
4437997	81.09/1	7	Isolation
4437998	81.09/1	3	Isolation
4438550	71.04/1	4	Reinforcement-Floor Pan
4439296	10.01/1	26	Support-Engine
4439353	73.07/1	19	Spacer Rear Bumper
4439353	73.06	18	Spacer Rear Bumper
4439367	73.06	10	Plate-R/H
4439367	73.07/1	11	Plate-R/H
4439368	73.06	11	Plate-L/H
4439368	73.07/1	12	Plate-L/H
4439374	73.06	9	Pad
4439374	73.07/1	10	Pad
4439375	73.07/1	2	Gasket
4439376	73.07/1	3	Gasket
4440096	11.01	26	Crankcase-Engine
4440098	11.01	9	Dowel-Cylinder Head
4440623	22.04	4	Gear
4440658	81.07	27	Panel-R/H Cargo
4441857	81.09	5	Insulation
4441860	81.09	3	Isolation
4441908	64.01/1	7	Lamp-Back UP

Part Number	Subgroup	Illus. №	Description
4441998	71.15	13	Lock
4443881	24.01	19	Ring-Axle Shaft
4443886	43.01	17	End Plate
4444262	51.08	5	Tube-Rear W/Washer
4444263	51.08	3	Tube-Rear W/Washer
4444359	81.02/3	4	Bracket
4445432	71.01	33	Pin
4445715	71.04	1	Stoneguard
4445716	71.04	3	Reinforcement-R/H Inner Fender
4446106	71.01	32	Spring-Hood Safety
4448748	71.06/1	1	Protection
4449463	71.06/1	2	Protection
4451144	22.04/1	5	Ring-Synchronizer
4451145	22.04/2	5	Synchronizer
4451146	22.10	16	Support Fork
4451147	22.10	18	Spring
4451148	22.10	17	Casing
4451150	22.04	5	Pad-Transmission Synchronizer
4451151	22.04	7	Spring-Transmission Synchronizer
4451152	22.10	4	Fork-Shift
4451153	22.10	26	Spring-Gearshift Control
4451155	22.10	35	Lover-Shift Control
4452106	71.02	35	Clip
4452371	71.09/2	40	Chaneel-R/H Door Glass
4452372	71.09/2	41	Chaneel-L/H Door Glass
4454054	71.09	3	Weatherstrip
4454140	71.09/1	36	Rod-Door Lock Control
4454141	71.09/1	37	Rod-Door Lock Control
4455049	71.02	27	Vent R/H
4455050	71.02	28	Vent L/H
4457256	81.01	12	Guide-Front Seat
4457561	22.04/3	4	Chaft-Cluster
4457562	22.04	9	Sleeve-Transmission
4457683	71.09	8	Moulding-Drip/Window
4459198	22.04/3	6	Gear-Reverse Idler
4459433	43.05	30	Bumper
4460113	22.07/1	8	Lever-Shift Control
4460116	22.07	7	Seal
4460196	81.09/1	5	Isolation
4460197	71.09	6	Channel-Window R/H
4460198	71.09	7	Chanel-Wundow L/H
4460398	42.01	5	Bushing-Steering Column
4460399	42.01	6	Shaft-Steering Column
4462671	11.06	21	Support-T/Belt Tensioner
4462672	11.06	21	Support-T/Belt Tensioner
4464018	10.01/1	4	Support-Enginf
4465865	22.04/2	9	Flange
4465916	22.10	23	Rod-Shift
4466648	22.10	23	Rod-Shift Control
4466867	11.06	16	Wheel Timing Belt Drive
4468858	81.09/1	8	Insulation
4468859	81.09/1	9	Insulation
4469446	73.07/1	20	Bracket
4469746	11.01	26	Grankcase Engine
4469751	11.01	7	Screw M10x103
4469752	11.01	6	Screw M10x85
4469762	11.01	26	Crankcase-Engine
4470201	22.04	1	Bearing Shaft
4472693	11.02	1	Cover-Engine
4472696	11.02	19	Cover-Engine

Part Number	Subgroup	Illus. №	Description
4473248	71.09/2	1	Frame-R/H
4473249	71.09/2	2	Frame-L/H
4473252	71.09/2	34	Weatherstrip-Went Window
4473253	71.09/2	33	Weatherstrip-Went Window
4473269	71.09/2	29	Support Glass Vent
4473270	71.09/2	35	Axle Glass Vent
4473271	71.09/2	9	Handle R/H
4473272	71.09/2	10	Handle L/H
4473273	71.09/2	12	Nut Glass Vent
4476293	43.01	18	Support L/H
4476294	43.01	19	Support R/H
4477643	31.03	29	Line Brake
4477649	31.02	25	Line Brake
4477655	31.02	23	Pipe
4478258	11.01	8	Screw
4479339	81.07/1	20	Hanger
5881135	11.01/2	1	Gasket-Set/Engine Overhaul
5881138	11.01/2	2	Gasket-Set/Engine Valve
5924718	21.01	6	Lever-Clutch Release
5930415	11.07	11	Seal-Valve
5936826	43.16	10	Weight-Balance
5936827	43.16	11	Weight-Balance
5936828	43.16	12	Weight-Balance
5936829	43.16	13	Weight-Balance
5936830	43.16	14	Weight-Balance
5936831	43.16	15	Weight-Balance
5936832	43.16	16	Weight-Balance
5936833	43.16	17	Weight-Balance
5937901	22.04	1	Bearing Transmission
5947072	22.07	17	Lever-Shift Control
5953970	11.01	21	Gasket Head Cylinder
5954608	31.04	2	Boot
5984424	11.01	21	Gasket (Goetze)
5992005	22.04/1	1	Gear
5992009	22.04/1	10	Gear
5992013	22.04/2	12	Gear
5992016	22.04/3	13	Gear
7553581	22.04/3	11	Chaft
10158601	11.01	25	Plug
10168890	12.01	28	Collar Fuelline
10205970	11.06	13	Pad
10260060	13.01	28	Washer-Cuclonic Trap
10269750	13.02	1	Plug-Oil Pump
10269850	11.01/1	1	Plug
10269850	11.01	18	Plug
10284460	31.02	11	Washer-Connection/Brake Line
10298350	14.01	5	Seal Plug Radiator
10396180	66.35	4	Bushing-Tail LP
10402580	71.01	18	Nut
10418800	31.02	38	Plate-Lock R/H
10516411	22.01/1	34	Washer-Lock
10516421	42.02	31	Washer
10516470	14.09	10	Washer-Lock
10516470	51.01	1	Washer-Lock
10516470	24.01	5	Washer-Lock
10516470	81.01	9	Washer-Lock
10516470	31.30	13	Washer-Lock
10516470	22.10	2	Washer-Lock
10516470	14.01	16	Washer-Lock
10516470	12.62	8	Washer-Lock
10516470	22.07	9	Washer-Lock

Part Number	Subgroup	Illus. №	Description
10516470	21.05	2	Washer-Lock
10516470	51.01	13	Washer-Lock
10516470	12.54	9	Washer-Lock
10516470	12.56	26	Washer-Lock
10516470	22.01/1	28	Washer-Lock
10516470	42.01	10	Washer-Lock
10516470	11.02	25	Washer-Lock
10516470	21.01	21	Washer-Lock
10516471	31.01	35	Washer-Lock
10516471	22.01/1	7	Washer-Lock
10516471	24.01	24	Washer-Lock
10516471	43.05	15	Washer-Lock
10516471	31.04	11	Washer-Lock
10516670	31.32	2	Washer-Lock
10516670	31.01	4	Washer-Lock
10516670	12.62	8	Washer-Lock
10516670	21.01	17	Washer-Lock
10516670	12.01	8	Washer-Lock
10516670	11.02	28	Washer-Lock
10516670	31.02/2	7	Washer-Lock
10516670	31.02/1	4	Washer-Lock
10516670	14.02	10	Washer-Lock
10516670	12.56	6	Washer-Lock
10516670	22.01/1	19	Washer-Lock
10516670	21.01	13	Washer-Lock
10516670	62.01	3	Washer-Lock
10516670	31.02	19	Washer-Lock
10516670	10.01/1	11	Washer-Lock
10516670	65.01	13	Washer-Lock
10516671	10.01/1	17	Washer-Lock
10516671	22.01/1	51	Washer-Lock
10516671	10.01/1	23	Washer-Lock
10516671	31.35	4	Washer-Lock
10516671	42.01/1	6	Washer-Lock
10516673	43.02	16	Washer-Lock
10516677	63.01	14	Washer-Lock
10516870	43.02	9	Washer-Lock
10516870	63.01	2	Washer-Lock
10516870	31.30	2	Washer-Lock
10516870	43.05	21	Washer-Lock
10516871	10.01/1	9	Washer-Lock
10516873	43.05	19	Washer-Lock
10517070	22.01	3	Washer-Lock
10517071	10.01/1	2	Washer-Lock
10517071	10.01/1	20	Washer-Lock
10519301	65.03	25	Washer
10519301	51.03	7	Washer
10519401	66.35	7	Washer
10519301	51.03	15	Washer
10519301	61.01	19	Washer
10519301	51.03	2	Washer
10519301	51.03	11	Washer
10519307	66.35	10	Washer
10519307	73.06	26	Washer
10519307	31.35	32	Washer
10519307	81.07	11	Washer
10519401	22.04/3	8	Washer
10519401	43.05	14	Washer
10519401	22.10	14	Washer
10519401	22.10	22	Washer
10519401	66.35	7	Washer

Part Number	Subgroup	Illus. №	Description
10519401	14.09	12	Washer
10519401	22.01/1	43	Washer
10519421	22.01/1	47	Washer
10519601	31.35	28	Washer
10519601	11.01	15	Washer
10519601	81.02/3	2	Washer
10519601	73.07/1	17	Washer
10519601	73.06	16	Washer
10519601	31.02	20	Washer
10519601	42.01	9	Washer
10519601	12.56	7	Washer
10519601	62.01	4	Washer
10519607	73.07/1	17	Washer
10519607	31.01/1	7	Washer
10519607	71.15	18	Washer
10519621	71.01	36	Washer-Front Strut
10519621	43.02	17	Washer-Front Strut
10571570	12.60	2	Washer-Lock
10571579	65.05	10	Washer
10571777	81.01	35	Washer
10571979	81.10/1	8	Washer
10615307	66.35	9	Washer-Lock
10615370	64.01/1	13	Washer Sidelamp
10615371	66.35	6	Washer
10615379	64.01/1	16	Washer
10615470	65.01	24	Washer-Heater Valve
10615471	66.35	6	Washer
10615476	12.01	14	Washer
10615611	73.06	3	Washer
10615611	73.07/1	4	Washer
10615671	73.06	15	Washer-Hood Stay Mount
10615671	73.07/1	15	Washer-Hood Stay Mount
10615671	71.01	37	Washer-Hood Stay Mount
10615671	81.01/4	23	Washer-Hood Stay Mount
10615679	73.07/1	4	Washer
10615679	73.06/1	7	Washer
10615679	73.07/1	15	Washer
10725911	51.02	10	Nut-Heater Valve
10725917	12.01	12	Nut
10733601	81.01/4	16	Pin
10734301	31.01	7	Pin-Cotter/Brake Pedal
10791211	65.01	10	Nut-Stop Lingt Switch
10791411	42.01	1	Nut-Steering Wheel
10794011	12.01	2	Nut-Fuel Sending Unit
10794011	71.01	9	Nut-Fuel Sending Unit
10796401	31.35	27	Pin-Cotter
10839610	11.01/1	2	Dowel-Locating/Cyl Head
10839610	11.01	19	Dowel-Locating/Cyl Head
10853090	64.01/2	11	Bulb-Interior Lamp
10857790	64.01/1	3	Bulb-Lamp Licence Plate
10858090	64.01/2	5	Fuse-8 Amp
10902011	66.35	8	Screw
10902011	21.01	23	Screw
10902011	22.01/1	8	Screw
10902021	11.06	20	Bolt-Timing Belt Shield
10902211	22.01/1	5	Screw
10902211	31.04	12	Screw
10902211	65.01	25	Screw
10902217	12.60	5	Screw
10902221	13.01	12	Bolt
10902221	11.02	26	Bolt

Part Number	Subgroup	Illus. №	Description
10902221	51.01	16	Bolt
10902221	12.54	19	Bolt
10902221	65.05	5	Bolt
10902221	11.02	7	Bolt
10902231	21.05	3	Bolt-Clutch Cover
10902321	22.04/3	7	Screw-Reverse Gear Shaft
10902421	42.02	23	Screw-Engine Cover
10902421	11.02	20	Screw-Engine Cover
10902421	12.62	9	Screw-Engine Cover
10902421	43.05	16	Screw-Engine Cover
10902521	51.01	8	Screw
10902617	12.60	5	Screw
10902621	71.01	29	Screw
10902621	22.01/1	44	Screw
10902621	14.02	27	Screw
10902311	11.06	4	Bolt
10902821	11.02	2	Bolt
10902821	11.06	4	Bolt
10902821	13.02	8	Bolt
10902921	22.10	21	Bolt-Shift Control
10902921	11.02	14	Bolt-Shift Control
10903011	11.06	27	Screw
10903420	13.02	11	Bolt-Oil Pump
10903421	22.01/1	39	Screw
10903511	12.56	24	Screw-Rear Muffler support
10977521	31.04	5	Screw
10977611	66.35	8	Screw
10977621	51.03	9	Screw-Heater Control Lever
10979411	31.02	36	Screw-Window Regulator
10979411	71.09/2	15	Screw-Window Regulator
10979421	24.01	25	Washer
10979421	71.09/2	4	Washer
10979421	31.02	8	Washer
10979421	31.30	14	Washer
11048990	64.01/2	16	Fuse-16 AMP
11058076	11.05/1	5	Lockwasher
11063976	21.01	22	Clip-Clutch Cable
11065975	66.66	2	C-Clip-Wiper Motor
11066976	24.01	1	C-Clip-Spider Joint
11101121	11.01	17	Screw
11106321	12.62	11	Screw
11194070	14.03	5	Washer
11194070	12.54	18	Washer
11194070	12.04/1	3	Washer
11194070	11.01	14	Washer
11194070	12.62	2	Washer
11195370	12.01	3	Washer-Fuel Sending Unit
11195470	65.03	26	Washer-Ignition Coil
11195470	31.04	7	Washer-Ignition Coil
11195470	61.01	18	Washer-Ignition Coil
11195477	51.03	4	Washer-Heater Control Lever
11196170	12.56	10	Washer-Lock
11197470	11.02	3	Washer-Engine Cover
11197770	11.01	3	Washer
11197770	14.02	37	Washer
11197770	14.03	3	Washer
11197770	11.02	8	Washer
11197770	13.01	11	Washer
11197771	11.06	3	Washer
11197771	13.02	7	Washer

Part Number	Subgroup	Illus. №	Description
11198070	12.02	13	Washer-Lock
11198070	14.02	30	Washer-Lock
11198070	62.01	5	Washer-Lock
11198070	12.02/1	12	Washer-Lock
11198070	61.01	8	Washer-Lock
11198070	14.02	4	Washer-Lock
11198070	11.06	18	Washer-Lock
11198070	13.01	16	Washer-Lock
11198170	63.01	4	Lockwasher
11198370	12.62	5	Washer-Timing Gear
11198370	63.01	23	Washer-Timing Gear
11198370	11.06	12	Washer-Timing Gear
11198470	11.06	7	Washer-Idler Bearing
11227970	11.06	11	Screw-Timing Gear
11234728	12.56	11	Screw
11297921	12.62	11	Screw
11307021	63.01	7	Screw
11307028	12.56	11	Screw
11500021	24.01	7	Screw
11903040	14.01	6	Plug Radiator
11945008	63.01	17	Screw-Battery Cable
12056285	61.01	12	Boot-Ignition Coil Wire
12056885	61.01	2	Cap
12056985	61.01	6	Cap
12164711	11.06	6	Nut
12164711	12.62	4	Nut
12164711	43.05	20	Nut
12164711	63.01	25	Nut
12164711	43.02	8	Nut
12173690	31.02/2	3	Nut
12180390	12.01/1	13	Clamp-Hose
12180390	12.01/1	15	Clamp
12180390	12.01/1	14	Clamp
12180390	12.02	15	Clamp
12180390	12.01/1	16	Clamp
12180390	12.02/1	2	Clamp
12180490	12.01/1	16	Clamp
12180490	12.01/1	14	Clamp
12180590	51.01	4	Clamp
12180690	14.02	38	Collar
12180690	14.02	25	Clamp
12180790	14.02	38	Clamp
12180790	14.02	21	Clamp
12180890	14.02	21	Clamp
12180890	14.02	26	Bracket-Hose
12181090	12.01	26	Bracket-Hose
12181290	13.01	27	Clamp-Filler Nick Hose
12181390	13.01	29	Clamp
12181390	12.56	19	Clamp-Hose
12182190	51.01	4	Clamp-Hose
12182390	12.02/1	2	Collar
12182390	14.01	8	Clamp
12182390	12.01	16	Clamp
12182490	12.01	16	Clamp
12182490	12.02/1	2	Clamp
12182490	12.01/1	13	Clamp
12182490	12.01/1	15	Clamp
12182590	14.01	13	Clamp
12182590	12.01	16	Clamp
12182790	31.02/2	3	Clamp-Hose
12276080	64.01/2	19	Block

Part Number	Subgroup	Illus. №	Description
12429521	10.01/1	27	Stud-Engine Mount
12555020	11.05/1	4	Nut-Connecting Rod
12555020	11.05	10	Nut-Connecting Rod
12574211	22.07/1	4	Nut
12574511	43.05	31	Nut-Rear Suspension Strut
12574521	43.05	22	Nut-Shock Absorber
12575611	43.05	29	Nut
12575611	42.10	4	Nut
12575811	43.02	22	Nut-Stabilizer Bar
12598271	71.02	3	Washer Window Lift Mech
12598271	51.01	12	Washer Window Lift Mech
12598271	71.09/2	16	Washer Window Lift Mech
12598271	71.09/2	5	Washer Window Lift Mech
12598277	12.58	6	Washer
12599071	71.09/2	24	Lockwasher
12599171	64.01/1	12	Washer
12599570	65.05	4	Lockwasher
12601571	71.01	4	Lockwasher
12605171	61.01	24	Washer
12605270	65.01	20	Washer
12605371	65.06	11	Washer
12605371	71.01	27	Washer
12605377	61.01	21	Washer
12605570	81.02	7	Washer
12605570	63.01	20	Washer
12606877	71.09/1	33	Washer
12606976	10.01/1	23	Washer-Lock
12612207	81.07	14	Washer
12612207	81.06	7	Washer
12624101	71.06/1	6	Washer
12624107	71.06/1	6	Washer
12624107	71.06	4	Washer
12624901	51.01	14	Washer
12626201	43.05	18	Washer
12637807	71.06	4	Washer
12638101	51.03	27	Retainer
12638601	31.01	6	Washer
12639750	22.24	7	Washer
12642001	12.56	15	Washer
12643701	71.04	13	Washer
12643701	71.01	28	Washer
12643701	14.09	11	Washer
12644401	61.01	22	Washer
12644401	13.01	10	Washer
12644401	12.05	2	Washer
12644407	12.01	13	Washer
12644410	73.07	6	Washer
12645801	22.07/1	9	Washer
12646601	11.06	2	Washer
12646701	71.01	3	Washer
12646721	71.01	36	Washer
12646801	10.01/1	10	Washer
12647001	21.01	16	Washer
12647001	73.07/1	18	Washer
12647001	81.01	35	Washer
12647001	73.06	17	Washer
12647001	12.01	7	Washer
12647007	73.07/1	18	Washer
12647101	12.54	14	Washer
12647201	71.01	3	Washer
12647201	31.01	3	Washer

Part Number	Subgroup	Illus. №	Description
12647201	73.07/1	16	Washer
12647201	73.06	14	Washer
12647201	71.01	36	Washer
12647207	73.07/1	16	Washer
12796471	81.11	5	Washer
12796471	81.10/1	2	Washer
12797887	81.10/1	7	Cap
12797887	81.11	4	Cap
13271811	66.66	5	Bolt-Rear Wiper
13272401	61.01	25	Screw
13274817	73.06	23	Screw-Front License-Plate
13279411	81.02/3	1	Screw-Rear Seat Latch
13279417	81.02	8	Screw-Rear Seat Hinge
13299507	81.07/1	7	Screw-Riv Mirror Inner
13303411	10.01/1	24	Screw M8x18
13304011	71.15	7	Screw
13304017	71.15	7	Screw
13312707	71.09/1	32	Screw
13325821	71.09/1	31	Screw
13336307	81.01	23	Washer Lock
13397676	31.35	12	Washer Lock
13414691	22.01/1	21	Plug-Transmission Cover
13422877	12.01/1	14	Clamp
13423178	12.01/1	13	Clamp
13423273	12.01/1	14	Clamp
13423273	14.02	14	Clamp
13423279	12.01/1	16	Clamp
13423373	12.01/1	15	Clamp
13423379	12.01	16	Bracket
13423379	12.01	16	Bracket
13423871	12.01	28	Clamp
13425279	12.04/2	17	Strap
13527021	61.01	10	Stud-Ignition Distributor
13517021	12.54	3	Stud-Ignition Distributor
13517111	12.54	3	Stud
13517321	12.02	12	Stud-Fuel Pump
13517321	12.02/1	11	Stud-Fuel Pump
13540721	11.06	25	Stud-Timing Belt Shield
13540921	22.01/1	49	Stud
13541121	22.01/1	30	Stud
13541121	22.01/1	35	Stud
13541321	11.01	5	Stud-Cam Tower
13541521	11.01	2	Stud-Cam Tower
13541620	12.05	6	Stud
13543321	22.01/1	24	Stud
13543521	12.54	4	Stud-Cam Tower
13543621	14.02	17	Stud-Thermostat Housing
13543821	22.01/1	18	Stud
13543821	12.54	13	Stud
13543921	14.02	18	Stud-Thermostat Housing
13552821	22.01	1	Stud
13766707	71.19	12	Pin Handle-Rear Qtriwindow
13824011	31.02	1	Screw-Brake Line
13824411	51.01	8	Screw
13824521	42.02	23	Screw
13825821	31.02	26	Bolt
13825821	14.02	9	Bolt
13825821	22.07/1	5	Bolt
13831801	71.09/1	23	Nut-Striker Plate
13832101	51.01	11	Slip-Heater Assy
13836071	71.01	30	Screw

Part Number	Subgroup	Illus. №	Description
13836071	71.09/1	4	Screw
13836471	71.04	12	Screw
13838071	71.15	1	Screw
13838071	71.01	6	Screw
13897570	71.09/2	44	Spring
14048117	12.01	22	Nut
14048117	77.07	1	Nut
14048711	63.01	1	Nut
14048717	43.02	1	Nut
14048727	43.01	13	Nut
14048727	43.02	18	Nut
14048811	43.05	11	Nut-Rearsuspension
14054517	73.07	5	Nut
14142390	71.02	29	Bulb
14143790	71.02	29	Bulb-Switch Panel
14143790	51.03	20	Bulb-Switch Panel
14143990	65.03	2	Buls-Instrument Cluster
14143990	65.03	20	Buls-Instrument Cluster
14144690	66.32	6	Bulb-Lamp Tail
14144690	66.34	8	Bulb-Lamp Tail
14148190	66.34	7	Bulb-Tail Lamp
14148190	66.35	2	Bulb-Tail Lamp
14148190	66.33	7	Bulb-Tail Lamp
14151590	64.01/1	2	Bulb
14184376	81.07	4	Clip
14188180	71.09/3	11	Clip
14188180	22.07	15	Clip
14188480	73.01	4	Clip
14196870	11.07	6	Key-Valve
14202985	81.07	10	Klip
14202985	71.19	16	Klip
14203080	71.09/3	6	Klip
14203080	81.07/1	21	Klip
14203780	31.02	22	Clip-Brake Line
14203780	71.02	33	Clip-Brake Line
14205080	31.02/2	5	Hose
14205180	31.02/2	5	Hose
14215282	31.35	31	Clip-Steering Column
14215282	42.01/1	11	Clip-Steering Column
14219290	71.06	3	Clip
14219290	71.02	9	Clip
14289701	31.02	37	Screw
14323211	14.02	11	Plug
14324411	22.01/1	12	Plug
14325301	11.02	12	Plug-Oil Drain
14326213	22.01/1	27	Plug
14328201	11.03	1	Plug-Crankshaft
14328401	22.01/1	10	Plug-Camshaft
14328401	11.07	2	Plug-Camshaft
14328501	22.01/1	6	Plug
14329901	11.01	22	Plug-Crankcase
14348670	11.03	5	Bolt-Flywheel
14359221	81.01	36	Screw
14457180	22.24	1	Gasket-speedo Cable
14496507	12.58	4	Washer
14567780	12.01/1	5	Strap
14569087	71.25	5	Screw
14569680	71.09/1	7	Clip-Door Lock Control
14570680	71.09/2	45	Clip
14570680	64.01/2	29	Clip

Part Number	Subgroup	Illus. №	Description
14572280	64.01/2	27	Clamp
14572586	64.01/2	30	Clip
14572880	51.03	22	Clip
14572880	64.01/2	28	Clip
14573080	51.07	4	Fitting T
14573280	31.02	9	Clip
14573380	64.01/2	26	Clip
14575380	31.02	33	Clip Brake Line
14575480	31.02	32	Clip Brake Line
14575480	12.01/1	9	Clip Brake Line
14578083	71.09/1	39	Sleeve-Door Lock Rod
14583180	51.08	4	Connector-W/Washer Line
14641792	12.04/2	11	Rivet
14778414	73.07	9	Screw
14778707	71.09/2	23	Screw
15541121	22.01	5	Screw
15541427	10.01/1	7	Screw
15641207	81.07/1	14	Screw
15642707	66.34	2	Screw Tail Lamp Assemsly
15642707	66.33	3	Screw Tail Lamp Assemsly
15642807	66.32	5	Screw Lamp Front
15643207	66.33	4	Screw Tail Lamp Assembly
15643207	66.34	1	Screw Tail Lamp Assembly
15643307	66.32	4	Screw Lamp Front
15644001	71.25	3	Screw
15644007	81.07	29	Screw-Front License-Plate
15644007	73.06	21	Screw-Front License-Plate
15644007	71.05	1	Screw-Front License-Plate
15645507	71.06/1	5	Screw
15645707	71.02	11	Screw-Starter Motor
15645907	81.07	12	Screw
15646701	65.03	12	Screw
15647407	71.09/3	5	Screw
15660507	81.07	13	Screw
15661707	81.01	24	Screw
15663207	81.07/1	17	Screw-Carpet Trim
15664707	81.07/1	5	Screw
15674307	71.19	15	Screw
15682001	71.06/1	5	Screw
15685507	73.01	2	Screw
15687207	71.25	3	Screw
15687277	81.08	2	Screw
15687307	66.33	3	Screw
15687307	66.34	2	Screw
15687907	73.06	19	Screw
15688001	31.01	11	Screw
15688107	73.01	3	Screw
15688307	71.06/	5	Screw
15688507	71.06	5	Screw
15690707	81.06	6	Screw M6x16
15691407	81.07/1	22	Screw
15896211	12.05	5	Nut
15896211	65.06	10	Nut
15896211	81.01	10	Nut
15896211	11.06	23	Nut
15896211	12.54	8	Nut
15896211	65.01	23	Nut
15896211	11.01	4	Nut
15896211	14.09	9	Nut
15896211	61.01	20	Nut
15896211	65.05	11	Nut

Part Number	Subgroup	Illus. №	Description
15896211	14.01	15	Nut
15896211	22.01/1	48	Nut
15896211	22.01/1	33	Nut
15896211	24.01	4	Nut
15896211	51.01	11	Nut
15896211	21.01	8	Nut
15896211	22.07	10	Nut
15896211	71.02	4	Nut
15896211	22.01/1	29	Nut
15896211	12.56	27	Nut
15896217	12.60	3	Nut
15896218	63.01	16	Nut-Battery Terminal
15896407	66.35	11	Nut
15896411	71.09/2	28	Nut
15896411	61.01	17	Nut
15896411	51.03	3	Nut
15896411	65.03	27	Nut
15896411	65.01	21	Nut
15896411	64.01/1	11	Nut
15896417	73.06	25	Nut Front Ligenfe Plate
15902701	81.07/1	28	Screw M6x19
15902707	66.32	5	Screw
15903307	73.01	2	Screw
15903407	73.06	23	Screw-Front License Plate
15903901	31.35	33	Screw
15904507	71.02	34	Screw
15904707	71.02	32	Screw
15908407	81.07	13	Screw
15908407	81.07/1	14	Screw
15925101	31.02	31	Screw
15925877	12.58	5	Screw
15965911	71.09/2	27	Screw/Glass-Vent
15970521	10.01/1	8	Screw
15970821	63.01	11	Screw
15972221	63.01	9	Screw
16042637	42.01	14	Screw
16042711	14.03	12	Screw-Water Pump Housing
16043211	31.35	3	Screw
16043221	11.06	17	Screw
16043221	73.06/1	6	Screw
16043221	31.32	1	Screw
16043321	21.54	17	Screw
16043321	11.02	27	Screw
16043327	12.58	3	Screw
16043411	14.02	9	Screw
16043411	63.01	3	Screw
16043421	42.01/1	7	Screw-Battery Cable Strap
16043421	63.01	13	Screw-Battery Cable Strap
16043427	81.01	36	Screw
16043611	10.01/1	29	Screw
16043621	12.56	30	Screw-Engine Support
16043621	10.01/1	16	Screw-Engine Support
16043621	12.62	9	Screw-Engine Support
16043821	10.01/1	28	Screw
16043921	14.02	8	Bolt-Water Pump
16043921	12.62	1	Bolt-Water Pump
16043921	14.03	12	Bolt-Water Pump
16044121	22.01/1	52	Screw
16044221	62.01	6	Bolt-Starter Motor
16044321	22.01/1	46	Screw
16044611	31.02/1	6	Screw

Part Number	Subgroup	Illus. №	Description
16044621	22.01/1	45	Screw
16044721	12.56	8	Screw-Muffler Clamp
16044821	11.01	16	Screw
16045120	13.01	17	Bolt-Oil Pump
16045421	14.02	3	Screw-Water Pump
16045421	13.01	26	Screw-Water Pump
16046721	11.01	13	Screw
16050011	14.03	2	Plug-Water Pump
16050521	22.10	15	Bolt-Shift Control
16100811	12.54	15	Nut
16100811	12.01	9	Nut
16100811	31.02/2	8	Nut
16100811	12.56	5	Nut
16100811	12.04/1	2	Nut
16100811	73.07/1	5	Nut
16100811	12.02	14	Nut
16100811	65.01	12	Nut
16100811	42.01	11	Nut
16100811	10.01/1	12	Nut
16100811	22.01/1	20	Nut
16100811	31.02/1	3	Nut
16100811	12.02/1	13	Nut
16100811	31.01	5	Nut
16100811	43.02	15	Nut
16100811	62.01	2	Nut
16100811	61.01	7	Nut
16100811	73.06	4	Nut
16100811	71.01	35	Nut
16100817	73.07/1	5	Nut
16100817	73.06/1	8	Nut
16101511	22.01	2	Nut
16101517	10.01/1	1	Nut
16102311	21.01	18	Nut-Clutch Pedal Support
16102311	31.35	20	Nut-Clutch Pedal Support
16102411	81.01/4	24	Nut
16104421	42.01	15	Nut-Steering Column
16105111	43.01	16	Nut-Ball Joint
16110780	65.05	6	Nut
16135721	10.01/1	24	Screw
16135911	12.56	20	Screw-Battery Bracket
16135911	63.01	19	Screw-Battery Bracket
16138921	43.02	14	Bolt-Stablizer Bar Brkt
16142921	10.01/1	19	Screw-Transmission Support
16235437	42.01	14	Screw
17670101	31.01	11	Screw-Brake Pedal Support
17671001	81.01	3	Screw-Seat Guide
17671001	31.35	25	Screw-Seat Guide
17671207	71.09/1	9	Screw
17671301	42.01/1	9	Screw
17671307	31.35	33	Screw
17671401	51.03	14	Screw
17672001	65.03	12	Screw-Stop Light Switch
17674001	81.07	2	Screw
17674007	81.07/1	2	Bolt-Grab Handle
17674007	71.06	1	Bolt-Grab Handle
20419310	22.10	29	Ball
22039931	10.01/1	14	Washer-Engine Support
24910871	81.01	37	Washer
24940440	14.03	11	Bearing
24940460	14.03	8	Bearing
40000050	11.02	4	Seal-Timing Cover

Part Number	Subgroup	Illus. №	Description
40000470	11.07	4	Seal-Front Engine
40000470	11.02	5	Seal-Front Engine
40001270	24.01	10	Seal-Axle Shaft
40002900	22.01/1	2	Seal-Input Shaft/Transmission
40003990	11.02	17	Seal
46600174	66.03	1	Blade-Alternator Fan
46600174	66.03/1	1	Blade-Alternator Fan
46600175	66.03	2	Support-Alternator
46600176	66.03/1	3	Bearing-Alternator
46600176	66.03	3	Bearing-Alternator
46600177	66.03/1	4	Stator
46600177	66.03	4	Stator
46600184	66.03	10	Housing-Alternator
46600185	66.03	11	Support-Alternator Housing
46600193	66.14	1	Cap-Distributor
46600194	66.14	2	Rotor-Distributor
46600195	66.14	3	Shield-Distributor
46600199	66.14	5	Winding-Distributor
46600200	66.14	6	Screw-Distributor
46600202	66.14	8	Clip-Dist Cap
46600203	66.14	9	Screw-Clip
46600204	66.14	11	Screw-Vacuum Advance
46600205	66.14	10	Insulator-Distributor
46600310	81.10	5	Belt-Seat Front R/H
46600311	81.10	6	Belt-Seat Front L/H
46600312	66.14	4	Assy Pick UP Distributor
46600313	66.14	7	Insulator Distributor
46600315	66.65/1	1	Linkage Wiper Motor
46600316	66.65/1	16	Link Wiper
46600317	66.65/1	13	Link Wiper
46600318	66.65/1	2	Link Wiper
46600319	66.65/1	12	Link Wiper
46600320	66.65/1	15	Motor Windshield Wiper
46600321	66.65/1	14	Gear Wiper Motor
46600322	66.65/1	9	Clip Wipermotor
46600323	66.65/1	8	Washer Wiper Motor
46600324	66.65/1	10	Ring Wiper Motor
46600325	66.65/1	11	Spring Wiper Motor
46600326	66.65/1	4	Nut Wiper Motor
46600327	66.65/1	3	Washer Wiper Motor
46600328	66.65/1	7	Bolt Wiper Motor
46600329	66.65/1	6	Washer Wiper Motor
46600330	66.65/1	5	Washer Wiper Motor
46600332	61.01	27	Key In Switch-Ignation
46600333	71.09/1	40	Key In Door
46600422	66.08	1	Support Starter Motor
46600423	66.08	4	Solenoid Starter Motor
46600429	81.10	11	Center Receptacle
46600454	31.30	S	Pad-Set (Wartex)
46600464	65.03	3	Bulb Holder
46600465	65.03	11	Cover
46600466	65.03	9	Resistor
46600467	65.03	4	Washer
46600468	65.03	5	Screw
46600491	11.05	1	Piston-Bielle Complete A
46600492	11.05	2	Piston-Bielle Complete B.
46600493	11.05	3	Piston-Bielle Complete C.
46600494	11.05	4	Piston-Bielle Complete D.
46600495	11.05	5	Piston-Bielle Complete E,
46600496	11.05	S	Set-Piston Connesting Rod

Part Number	Subgroup	Illus. №	Description
46600497	11.05	S	Set-Piston Connecting Rod
46600498	11.05	S	Set-Piston Connecting Rod
46600499	11.05/3	5	Piston-Engine (A)
46600500	11.05/3	6	Piston-Engine (B)
46600501	11.05/3	7	Piston-Engine (C)
46600502	11.05/3	8	Piston-Engine (D)
46600503	11.05/3	9	Piston-Engine (E)
46600504	11.05/3	10	Set-Piston Wirings
46600505	11.05/3	11	Set-Piston Wirings
46600506	11.05/3	12	Set-Piston Wirings
46600651	65.03	10	Warning Light Plate
46600835	81.10	2	Seat Belt Rear IP60
46600836	81.10	1	Seat Belt Rear IP20
46600837	81.10	10	Center Receptacle IP60
46600838	81.10	9	Center Receptacle IP20
46600840	81.10	7	Lever R
46600841	81.10	8	Lever L
46600845	81.10	4	Seat Belt Rear IP60
46600846	81.10	3	Seat Belt Rear IP20
46600854	71.09/1	44	Key In Switch-Ignition
46600855	24.01	9	Boot-Ahle Shaft
46600874	11.01/2	1	Gasket Set Engine Overhaul
46600875	10.01	2	Engine Incomplete
46600876	10.01	3	Engine Short Block
46600890	31.30	S	Pad-Set (Ferodo)
46600894	66.33	5	Gasket
46600895	66.33	6	Gasket
46602150	71.09/1	42	Key In Door
46602151	71.09/1	43	Key In Door
46602156	11.03	9	Bearing Set-Crankshaft
46602157	11.03	10	Set-Bearing 254 Crankshaft
46602158	11.03	11	Set-Bearing 508 Crankshaft
46602159	11.03	12	Set-Bearing 762 Crankshaft
46602160	11.05	1	Piston-Rod Assy
46602161	11.05	2	Piston-Rod Assy
46602162	11.05	3	Piston-Rod Assy
46602163	11.05	4	Piston-Rod Assy
46602164	11.05	5	Piston-Rod Assy
46602165	11.05	S	Set-Piston Rod Assy
46602166	11.05	S	Set-Piston Rod Assy
46602167	11.05	S	Set-Piston Rod Assy
46602170	11.05	11	Piston-Bielle Complete
46602171	11.05	12	Piston-Bielle Complete
46602172	11.05	13	Piston-Rod Rings Assy CL C
46602173	11.05	14	Piston Rod Assy With Rings
46602174	11.05	15	Piston Rod Assy With Rings
46602175	11.05	S	Piston Rod Assy With Rings-Set
46602176	11.05	S	Piston Rod Assy With Rings-Set
46602177	11.05	S	Piston Rod Assy With Rings-Set
46602178	11.05	11	Piston-Rod Assy
46602179	11.05	12	Piston-Rod Assy
46602180	11.05	13	Piston-Rod Assy
46602181	11.05	14	Piston-Rod Assy
46602182	11.05	15	Piston-Rod Assy
46602183	11.05	S	Piston-Rod Assy
46602184	11.05	S	Piston-Rod Assy
46602185	11.05	S	Piston-Rod Assy With Ring-Set
46602201	66.03	14	Regulator Voltage
46602216	66.08	10	Rotor
46602231	64.01/2	3	Harness-Wire
46602237	81.02	15	Cushion Seat

Part Number	Subgroup	Illus. №	Description
46602238	81.02	16	Cushion Seat
46602239	81.02	13	Seat Back Complete
46602240	81.02	14	Seat Back Complete
46602241	81.02	13	Seat Back Complete
46602242	81.02	14	Seat Back Complete
46602306	66.03/1	5	Screw-Alternator
46602313	66.03/1	11	Condenser-Starter Motor Compl
46602315	66.03/1	13	Regulator Voltage
46602321	66.03/1	4	Stator-Alternator
46602321	66.03	4	Stator-Alternator
46602322	11.05/2	1	Ring-Piston STD
46602323	11.05/2	2	Ring-Piston + 0 2
46602324	11.05/2	3	Ring-Piston + 0 4
46602325	11.05/2	4	Ring-Piston + 0 6
46602326	11.05/2	5	Piston-Engine A
46602327	11.05/2	6	Piston-Engine B
46602328	11.05/2	7	Piston-Engine C
46602329	11.05/2	8	Piston-Engine D
46602330	11.05/2	9	Piston-Engine E
46602331	11.05/2	10	Set-Piston W/Rings + 0 2
46602332	11.05/2	11	Set-Piston W/Rings + 0 4
46602333	11.05/2	12	Set-Piston W/Rings + 0 6
46602334	11.01/2	1	Gasket-Set Engine Dyerhaul
46602336	66.03/1	9	Shield Compl
46602345	66.03	14	Regulator Voltage Compl
46602370	66.65/1	1	Windshield Wiper Assy
46602371	66.65	1	Windshield Wiper Assy
46602372	66.65/1	16	Wjndsheld Wiper Assy
46602373	66.65	8	Link-Wiper
46602388	71.15	15	Door-Rear
46602390	71.05	9	Panel-L/H Rear Quarter
46602416	81.02	14	Seat-Back Complete
46602417	81.02	16	Cushion Seat Complete
46602424	65.05	13	Boot-Link
46602434	66.65/1	17	Bushing-Wiper Arm
46602442	66.03/1	13	Regulator Voltage
46602448	66.65/1	12	Link-Wiper
46602449	66.65/1	13	Link-Wiper
46602543	66.65/1	15	Motor-Windshield Wiper
46602544	66.65	6	Motor-Wiper Frt
46602572	66.03/1	2	Support Compl
46602599	66.08	12	Kit-Shim Starter Motor
46602640	66.03/1	10	Housing Compl
46602643	66.03	15	Brush
46602643	66.03/1	14	Brush
46602644	66.03	5	Stud-Alternator
46602645	66.03	6	Armature
46602646	66.03	6	Armature
46602647	66.03	7	Rullev Compl. Alternator
46602648	66.03	9	Rectifjer Compl
46602649	66.03/1	6	Armature
46602650	66.03/1	6	Armature
46602651	66.03/1	7	Pullev-Alternator
46602652	66.03/1	12	Rectifier Compl.
46602653	66.08	2	Bushing
46602654	66.08	3	Fork
46602655	66.08	5	Stator
46602656	66.08.	6	Holder
46602657	66.08	8	Support End Starter Motor
46602665	66.14	10	Advance-Vacuum
46620001	66.01/2	3	Harness-Wire

Part Number	Subgroup	Illus. №	Description
46620002	64.01/2	1	Harness-Assy
46620003	64.01/2	12	Harnes S-Wirw RR
46620004	13.01	30	Filter-Oil
46620005	91.11	5	Label
46620006	91.10	1	Label
46620007	91.11	4	Label
46620008	91.10	2	Label
46620010	12.04/2	5	Gasket
46620012	12.56	29	Valve
46620013	12.04/2	14	Hose
46620020	12.04/2	4	Bracket
46620023	22.07	8	Plate
46620031	12.05	3	Cover-Air Filter
46620037	12.01	27	Hose
46620038	12.01	24	Tube-Filler
46620039	65.01	1	Button-Horn IP60
46620040	65.01	2	Button-Horn IP20
46620043	91.11	6	Label
46620044	42.01	8	Shaft-Steering
46620079	10.01	1	Engine-Complete
46620081	10.01	2	Engine-Incomplete
46620082	10.01	3	Engine-Short/Boock
46620083	11.01/1	3	Head Cylinder
46620087	11.01	1	Cover-Cam
46620089	12.54	16	Manifold-Exhaust
46620094	14.02	5	Pump-Water
46620101	71.04	4	Support Batery
46620104	12.54	1	Manifold-Intake
46620110	42.02	2	Wheel-Steering IP20
46620112	42.01	3	Wheel-Steering IP60
46620114	81.01	30	Cover IP20
46620115	81.01	31	Cover IP60
46620116	81.01	32	Lever-Seat Back
46620117	81.01	33	Lever-Seat Back
46620118	31.35	1	Handle-IP20
46620119	31.35	2	Handle-IP60
46620124	81.07	6	Receiver-Ash
46620125	81.07	7	Receiver-Ash
46620129	71.05	4	Protection For Engine
46620137	71.05	16	Panel
46620140	71.05	10	Panel-Roof
46620141	81.02	12	Panel-Seat Back
46620142	71.15	15	Door-Rear
46620144	81.06	3	Carpet-(Storage) IP60
46620145	81.06	4	Carpet-(Storage) IP20
46620147	71.01	10	Scoop-Hood/Red
46620148	71.01	11	Scoop-Hood/White
46620149	71.01	12	Scoop-Hood/Black
46620152	71.01	13	Scop-Hood/Blue
46620153	71.01	14	Scop-Hood/Gold
46620155	71.05	10	Panel-Roof
46620158	81.07	21	Panel-R/H IP60
46620159	81.07	22	Panel-L/H IP60
46620160	81.07	19	Panel-R/H IP20
46620161	81.07	20	Panel-L/H IP20
46620162	81.07/1	23	Panel-Storage
46620163	81.07/1	24	Panel-Storage
46620166	71.25/3	2	Emblem-Yugo
46620167	71.25/3	1	Emblem-GV
46620168	71.02/0	8	Emblem-Dash Panel
46620169	73.01	1	Bezel-Headlamp R/H

Part Number	Subgroup	Illus. №	Description
46620170	73.01	6	Bezel-Headlamp L/H
46620181	71.09	2	Moulding-Doorsill
46620181	81.07/1	15	Moulding-Doorsill
46620182	73.06	22	Front License Plate Brkt
46620183	63.01	8	Alternator
46620185	61.01	16	Plug-Spark
46620189	63.01	22	Battery
46620191	81.07	15	Panel-Speaker R/H IP20
46620192	81.07	17	Panel-Speaker R/H IP60
46620193	81.07	16	Panel-Speaker L/H IP20
46620194	81.07	18	Panel-Speaker L/H IP60
46620199	73.06	24	Front Lic Plate Brkt
46620207	64.01/1	6	Lamp-License Plate
46620208	65.03	1	Cluster-Instrument
46620209	65.03	8	Speedometer
46620210	65.03	7	Gauge-Temperature
46620212	65.03	15	Switch
46620213	65.03	16	Switch-Heater Fan
46620214	65.03	18	Switch-Rear Wiper
46620216	65.05	3	Windshield Wiper-Assy
46620217	65.01	14	Horn
46620218	65.03	17	Switch-Hazard Light
46620220	65.03	19	Switch-Rear Defog
46620222	65.03	21	Cable Assy
46620226	51.08	10	Reservoir-Washer Rear/Assy
46620227	51.08	8	Reservoir-Washer Rear/Assy
46620229	51.08	9	Pump-Washer
46620240	12.04/2	3	Support
46620241	12.04/2	2	Element Support Separator-Oil
46620244	12.04/2	10	Housing-Air Filter
46620248	12.04	23	Ca-Fuel/Locking
46620261	22.07	11	Knob-Shift
46620263	22.07	12	Knob-Shift IP60
46620265	81.07	28	Panel L/H
46620279	71.25	6	Emblem-Front Y
46620282	81.07	5	Lining
46620283	81.07	33	Panel
46620284	81.07	32	Panel
46620285	81.07/1	13	Mirror L/H
46620286	81.07/1	26	Mirror R/H
46620295	71.05	14	Bracket
46620297	73.06	1	Bar-Front Bumper (Complete)
46620298	73.06	5	Bar-Bumper
46620300	73.07/1	1	Bar-Rear Bumper (Complete)
46620301	73.07/1	8	Bar-Bumper RR
46620303	73.06	8	Reinforcement
46620304	73.06	6	Bracket R/H
46620304	73.07/1	6	Bracket R/H
46620305	73.07/1	7	Bracket L/H
46620305	73.06	7	Bracket L/H
46620308	73.07/1	9	Reinforcement
46620309	73.06	12	Support-R/H
46620309	73.07/1	13	Support-R/H
46620310	73.06	13	Support-L/H
46620310	73.07/1	14	Support-L/H
46620317	73.06	2	Screw
46620317	73.07/1	21	Screw
46620327	81.01/3	6	Skeleton For Front Seat R
46620328	81.01/3	6	Skeleton For Front Seat L
46620340	81.01/3	5	Pin

Part Number	Subgroup	Illus. №	Description
46620342	91.10	5	Label
46620343	91.10	3	Label
46620346	12.62	3	Support-Air Pump
46620348	11.15	1	Belt-Alternator (Water Pump)
46620350	12.62	7	Pulley-Air Pump
46620355	12.60	1	Compensator-Altitude
46620356	14.02	13	Swich-Vacuum
46620357	14.02	12	Swich-Vacuum
46620361	12.58	2	Bracket
46620361	31.02/1	5	Bracket
46620362	12.54	7	Valve EGR
46620363	12.54	12	Gasket
46620364	12.54	11	Sleeve
46620367	12.54	10	Mani Fold-Exhaust
46620374	12.01	19	Sleeve
46620375	12.01	15	Sleeve
46620376	12.01	17	Line-Fuel-Vapor
46620382	12.61	7	Hose
46620386	12.04/2	16	Shield
46620388	14.03	1	Pulley-Water Pump
46620391	63.01	10	Bracket
46620393	11.05	1	Cover-Timing Belt
46620394	91.10	4	Label
46620395	73.06	20	Plug
46620396	14.01	12	Tank-Radiator/Expansion
46620417	71.04/1	2	Protection
46620432	51.07	11	ST. Reservoir-Wind/Washer Assy
46620433	51.07	10	ST. Reservoir-Wind/Washer
46620448	51.01	3	Heater Assy
46620450	22.07	18	Plate-Shift
46620474	11.01	27	Bolt-Support/Air Pump
46620487	14.02	19	Pipe
46620491	51.01	6	Connector
46620494	71.25/2	18	Moulding R/H
46620494	71.25	13	Moulding R/H
46620495	71.25	14	Moulding L/H
46620495	71.25/2	19	Moulding L/H
46620498	71.04/1	11	Support-R/H
46620500	71.04/1	12	Support-R/H
46620502	12.54	20	Valve-EGR
46620506	12.54	2	Valve
46620513	81.07	25	Pillar-R/H IP20
46620514	81.07	26	Pillar-L/H IP20
46620521	71.04/1	3	Pan-Floor
46620523	12.62	13	Support-Air Pump
46620551	61.01	23	Coil-Ignition
46620552	61.01	13	Gasket
46620553	61.01	14	Module
46620555	61.01	1	Distributor-Ignition
46620583	51.01	5	Hose-Heater
46620584	51.01	10	Hose-Heater
46620585	12.56	21	Pipe-Exhaust
46620587	31.02	6	Line-Brake
46620589	12.04/2	13	Housing-Assy
46620591	12.04/2	7	Filter-Oil Breather
46620592	12.61/1	6	Sleeve
46620592	12.61	5	Sleeve
46620593	12.61/1	5	Hose
46620593	12.61	6	Hose
46620600	12.01/1	4	Sleeve
46620603	65.05	3	Windsjeld Wiper Assy

Part Number	Subgroup	Illus. №	Description
46620604	71.09/1	13	Handle
46620605	71.09/1	14	Handle
46620607	12.04/2	1	Connestor
46620610	81.01/4	1	Spring Skeleton Back Seat
46620610	81.01/3	1	Spring Skeleton Back Seat
46620611	12.04/2	8	Washer
46620615	81.08	1	Support
46620618	12.04/2	15	Connector
46620620	64.01/2	15	Protection
46620623	71.09/2	6	Handle
46620624	71.09/2	7	Handle
46620627	51.01	9	Connector
46620630	14.02	31	Hose-Heater
46620631	12.62	10	Bracket-Air Pump
46620632	12.62	14	Casing
46620633	13.01	5	Hose-Lubrication
46620638	42.01	4	Column-Steering
46620639	42.01	7	Panel
46620640	71.09/3	7	Armrest
46620641	71.09/3	8	Armrest
46620642	71.09/3	9	Armrest
46620643	71.09/3	10	Armrest
46620644	12.04/2	9	Clip
46620655	71.09/2	13	Ring
46620656	71.09/2	14	Ring
46620657	65.01	19	Buzzer
46620662	12.56	2	Pipe-Front Exhaust
46620666	31.02	34	Line-Brake
46620674	51.07	8	Cap-Expansion Tank
46620674	51.08	6	Cap-Expansion Tank
46620674	14.01	11	Cap-Expansion Tank
46620697	64.01/1	1	Lamp-Side Marker
46620698	64.01/1	4	Lamp-Side Marker
46620728	71.09	11	Houlding-Doorsill
46620728	81.07/1	16	Houlding-Doorsill
46620729	31.02	27	Line Brake
46620732	12.56	9	Busching
46620733	71.02	6	Panel-Dash IP60
46620737	12.04/2	6	Connector-Air Cleaner
46620741	65.03	22	Rheostat-Dash Light
46620745	31.02/2	9	Brake-Servo Unit
46620758	12.56	16	Brace-Catalytic Conv
46620764	12.56	14	Bracket-Catalytic Conov
46620765	12.56	13	Bracket-Catalytic Conov
46620767	71.09	4	Door-Comp R/H
46620768	71.09	5	Door-Comp L/H
46620775	71.04	8	Panel-Dash
46620795	71.25	1	Shield-Stone (Spoiler)
46620796	12.54	5	Valve-Reed
46620797	12.61	4	Vacuum Harness
46620799	12.58	1	Valve-Air Diverter
46620800	12.01	10	Support-Wapor Canister
46620831	12.56	12	Converter-Catalytic
46620834	12.01	6	Tank-Fuel
46620836	12.31	11	Trap-Vapour
46620837	12.04/2	12	Valve
46620838	12.04/1	1	Carbureter
46620840	12.61	2	Vacuum Harness
46620841	12.61	3	Vacuum Harness
46620844	61.01	15	Module-Ignition
46620849	61.01	26	Switch-Ignition

Part Number	Subgroup	Illus. №	Description
46620853	12.01	1	Tank-Fuel
46620854	12.61	1	Sleeve
46620854	12.61/1	3	Sleeve
46620855	71.25	1	Shield-Stone (Spoiler)
46620870	81.13	3	Belt-Seat Front
46620880	12.02	1	Filter-Fuel
46620880	12.02/1	15	Filter-Fuel
46620882	81.01	19	Protection Skeleton Seat R
46620883	81.01	20	Protection Skeleton Seat L
46620888	12.04/1	6	Connection on Carburetor
46620891	65.06	7	Motor-Wiper Rear
46620892	12.02	1	Filter-Fuel
46620892	12.02/1	15	Filter-Fuel
46620894	71.04	11	Wheelbox
46620895	71.04	7	Wheelbox
46620897	43.16/1	16	Cap-Tipe Valve
46620900	12.02	2	Linefuel
46620901	12.02	16	Hose-Fuel Supply
46620911	43.02	6	Absorber-Shock/Front
46620912	43.05	25	Absorber-Shock/Rear
46620915	64.01/2	18	Vacuum-Switch
46620932	12.01	23	Cap-Fuel/Locking
46620936	71.04/1	16	Panel
46620941	71.19	7	Weatherstrip
46620942	71.09	1	Panel-Door
46620943	71.15	2	Weatherstrip
46620951	64.01/2	17	Element
46620965	71.09/1	27	Lock
46620966	71.09/1	28	Lock
46620968	71.09/1	8	Kit
46620969	71.15	11	Lock
46620971	71.15	13	Lock
46620972	71.04	5	Crossrail
46620987	12.05	7	Stud-Air Cleaner
46620989	12.04/2	11	Rivet
46620990	71.09/1	26	Plate-Striker
46621053	64.01/1	14	Lamp-Tail R/H
46621054	64.01/1	15	Lamp-Tail L/H
46621060	81.06	1	Mat
46621061	81.06	2	Mat
46621073	71.04	6	Crossrail
46621077	31.32	11	Drum-Brake
46621095	91.01	2	Kit-Bulb + Fuse
46621099	81.01/3	3	Spring Skeleton Cushion Seat
46621101	71.15	14	Weatherstrip
46621127	71.09/3	1	Panel
46621128	71.09/3	2	Panel
46621131	71.09/3	3	Panel
46621132	71.09/3	4	Panel
46621141	43.16	19	Cover
46621144	61.01	26	Switch-Ignition
46621145	66.35	1	Lamp-Tail
46621153	71.04/1	14	Wheelbox-R/H
46621154	71.04/1	15	Wheelbox-L/H
46621204	71.18	1	Weatherstrip-Windshield
46621213	12.62	6	Air Pump
46621221	71.05	15	Gasket
46621224	71.25/3	5	Emblem GVX
46621249	12.21	1	Bracket
46621252	71.25	7	Moulding-R/H Fender
46621253	71.25	8	Moulding

Part Number	Subgroup	Illus. №	Description
46621254	71.25	9	Moulding-R/H Door
46621255	71.25	10	Moulding-L/H Door
46621256	71.25	11	Moulding R/H Quarter
46621257	71.25	12	Moulding L/H Quarte
46621262	43.16	20	Cap-Tire Valve
46621279	12.21	2	Cable-Accelerator
46621325	71.09/2	19	Channel-Door
46621332	81.07	8	Clip Rear Cargo Panel
46621333	81.07	9	Clip Rear Cargo Panel
46621353	71.09/1	34	Lock-D20R R/H
46621354	71.09/1	35	Loch-D20R L/H
46621390	62.01	1	Motor-Starter
46621394	71.02	30	Holder Bulb
46621395	71.02	31	Lens
46621447	71.02	25	Panel Under Dashboard IP20
46621448	71.02	26	Panel Under Dashboard IP60
46621478	43.02	6	Absorber-Shock/Front
46621481	14.09	7	Motor Engine Cooling Fan
46621482	13.01	30	Filter Oil
46621483	12.05	4	Element Air Filter
46621491	43.16	21	Valve-Tire
46621493	12.61	7	Hose
46621496	65.05	1	Blade Wiper Front
46621497	65.05	2	Arm Wiper
46621499	43.05	25	Absorber-Shockirear
46621505	71.06/1	3	Protection Compl
46621506	71.06/1	4	Protection Compl
46621507	91.13	1	Label
46621508	91.13	2	Label
46621511	65.06	1	Blade-Wiper Rear
46621512	65.06	2	Label
46621516	81.01	21	Protection Skeleton Seat R
46621516	81.01	21	Protection Skeleton Seat R
46621517	81.01	22	Protection Skeleton Seat L
46621517	81.01	22	Protection Skeleton Seat L
46621528	71.15	17	Cable
46621544	24.01	14	Shafi Axle
46621545	24.01	3	Shafi Axle
46621572	73.06	22	Front Licence Plate
46621573	73.06	24	Front Lic Plate Brkt
46621583	91.12	4	Label
46621584	91.12	6	Label
46621585	91.12	2	Label
46621586	91.12	1	Label
46621594	12.05	4	Element Air Filter
46621602	81.07	23	Pillar R/H Rear IP60
46621603	81.07	24	Pillar L/H Rear IP60
46621604	81.07	25	Pillar R/H Rear IP20
46621605	81.07	26	Pillar L/H Rear IP20
46621608	91.29	4	Label
46621608	91.12	3	Label
46621610	22.07	14	Boot-Shift IP60
46621611	51.08	10	Reservoir Washer Rear Assy
46621612	51.08	8	Reservoir Washer Rear
46621617	22.07	13	Boot-Shift IP20
46621618	31.02	4	Line-Brake R/H
46621619	31.02	10	Line-Brake R/H
46621620	31.02	27	Line Brake
46621622	14.09	7	Motor-Engine Cooling Fan
46621623	81.09/1	10	Insulation R

Part Number	Subgroup	Illus. №	Description
46621626	12.60	4	Framing Korector
46621673	13.01	3	Tubing
46621689	71.09/3	3	Panel-Door
46621690	71.09/3	4	Panel-Door
46621693	71.09/3	1	Panel-Door
46621694	71.09/3	2	Panel-Door
46621733	71.09/1	18	Grooved Bush
46621733	71.04	10	Grooved Bush
46621750	63.01	22	Battery
46621753	71.04	5	Crossrail
46621767	91.13	3	Label
46621769	81.07/1	1	Handle-Grab
46621793	71.01	26	Handle
46621798	66.35	5	Support/Lamp Tail
46621802	51.02	22	Cover-Htriair Inlet
46621838	71.06/1	3	Liner Fender R/H
46621839	71.06/1	4	Liner Fender L/H
46621840	64.01/2	17	Element
46621846	12.04/2	13	Housing-Assy
46621871	91.19	5	Label
46621872	81.07	19	Panel-R/H IP20
46621873	81.07	20	Panel-L/H IP20
46621874	81.07	21	Panel-R/H NP60
46621875	81.07	22	Panel-L/H IP60
46621878	64.01/2	3	Harness Wire
46621879	64.01/2	1	Harness Assy
46621880	64.01/2	12	Harness Wire RR
46621891	81.02/2	1	Cover-Seat Back IP20
46621892	81.02/2	2	Cover-Seat Back IP60
46621901	81.02/1	1	Cover-Cushion IP20
46621902	81.02/1	2	Cover-Cushion IP60
46621914	71.02	38	Spacer-Dash Panel IP60 R/H
46621915	71.02	39	Spacer-Dash Panel IP60 L/H
46621918	71.15	20	Strut Hatch
46621950	71.02	36	Spacer-Dash Panel IP20 R/H
46621951	71.02	37	Spacer-Dash Panel IP20 L/H
46621958	81.01/1	1	Cover-Seat Back IP20
46621960	81.01/1	2	Cover Seat Back IP60
46621968	81.01/2	2	Cover-Cushion IP20
46621969	81.01/2	2	Cover-Cushion IP60
46621976	71.15	19	Screw Strut Hatch
46622014	12.62	3	Support-Water
46622020	71.04	3	Element-Joining R/H
46622021	71.04	6	Element-Joining
46622065	81.02	9	Headrest IP20
46622065	81.01	14	Headrest IP20
46622067	81.01	15	Headrest IP60
46622067	81.02	10	Headrest IP60
46622083	81.10	12	Seal Seat Blt Front
46622083	31.02/2	12	Seal Seat Blt Front
46622121	43.16/1	3	Weight-Balance
46622122	43.16/1	4	Weight-Balance
46622123	43.16/1	5	Weight-Balance
46622124	43.16/1	6	Weight-Balance
46622125	43.16/1	7	Weight-Balance
46622126	43.16/1	8	Weight-Balance
46622127	43.16/1	9	Weight-Balance
46622128	43.16/1	10	Weight-Balance
46622129	43.16/1	11	Weight-Balance
46622137	65.03	31	Knos-Dash Rheostat
46622170	22.24	4	Cable-Inter

Part Number	Subgroup	Illus. №	Description
46622178	22.24	5	Cable-Speedometar
46622263	51.01	15	Shield
46622300	65.03	29	Switch
46622303	71.05	7	Panel-Rear
46622304	66.35	5	Support-Lamp Tail
46622316	63.01	18	Cable Battery
46622324	22.01/1	13	Housing-Transmission
46622325	22.01/1	40	Plate
46622326	22.01/1	42	Cover
46622338	22.07	2	Cover-Shift Control
46622342	43.02	10	Stabilizar Bar
46622347	31.02	5	Hose-Front Brake
46622398	71.09/1	41	Key In Door
46622406	71.09/1	S	Kit
46622407	12.01	23	Cover-Fuel/Locking
46622430	81.06	4	Carpet-9 (Storage IP20
46622431	81.06	3	Carpet-9 (Storage) IP 60
46622455	71.01	15	Scoop-Hood
46622470	71.25/2	7	Tape Stripe Rocker L/H
46622471	71.25/2	6	Tape Stripe Rocker R/H
46622482	64.01/2	12	Harness-Wire RR
46622489	81.06	1	Carpet IP60
46622490	81.06	2	Carpet IP20
46622493	64.01/2	17	Element
46622497	65.03	8	Speedometer
46622498	65.03	7	Heat Indicator
46622500	65.03	1	Cluster-Instrument
46622502	71.09	1	Weatherstrip Door
46622503	71.15	2	Weatherstrip Rear Hatch
46622504	71.19	7	W strip Rear Qvarter Glass
46622510	91.17	3	Label
46622523	31.02/2	12	Seal Supprot Brake Servo Unit
46622556	12.04/2	3	Support
46622564	71.04	1	Stone Guard
46622572	12.61	4	Vacuum Harness
46622574	12.58	1	Valve Airidiverter
46622576	91.15	2	Label
46622583	91.15	3	Label
46622584	12.05	3	Cover-Air Filter
46622585	81.09	6	Izolation
46622588	65.01	15	Ambient Switch
46622589	64.01/2	3	Harness-Wire
46622590	64.01/2	1	Harness-Assy
46622592	65.01	22	Californija Elektrinic Unit
46622615	12.56	12	Converter Catalytic
46622617	65 01	16	Support
46622630	71.02	20	Console IP20
46622631	71.02	21	Console IP60
46622632	71.02	18	Panel Console IP20
46622633	71.02	19	Panel Console IP60
46622636	64.01/2	21	Support-Fuse 0,5 (EI)
46622651	12.21	6	Pedal
46622655	91.01	2	Kit Bulb Fuse
46622657	64.01/2	22	Fuse-0 5 Amp
46622679	91.01	1	Kit-Tool
46622680	66.35	5	Support-Lamp Tail
46622699	61.01	16	Plug Spark
46622718	91.15	1	Label
46622743	81.08	3	Support Spare Tire
46622763	65.01	18	Washer-Lock
46622784	81.13	1	Belt-Seat Rear IP20

Part Number	Subgroup	Illus. №	Description
46622785	81.13	2	Belt Seat Rear IP60
46622792	65.05	3	Windshield Wiper-Assy
46622796	65.05	3	Windshield Wiper-Assy
46622797	31.02	4	Line Brake
46622809	81.06	4	Carpet (Storage) IP20
46622810	81.06	3	Chrpel (Storage) IP60
46622814	43.16/1	15	Wheel-Roed
46622815	43.16/1	19	Cover-Wheel
46622823	71.15	4	Glass-Rear Door
46622831	71.02	30	Housing-Cig/Lighter
46622832	71.02	31	Element Cig/Lighter
46622842	24.01	17	Joint-Constant Velocity
46622848	12.61/1	1	Switch Vacuum
46622861	12.04/2	6	Sensor-Temperature
46622862	12.54	7	Valve-Airidiverter
46622863	12.04/1	1	Carburator
46622874	10.01	1	Engine Complete
46622884	12.62	7	Pulley-Water Pump
46622891	22.01/1	11	Gasket-Transmission Housing
46622892	14.09	4	Sending Unit
46622898	71.09/1	26	Plate-Striker
46622899	71.15	11	Lock
46622900	12.01	23	Cap-Fuel/Locking
46622901	71.09/1	S	Kit
46622905	71 09/1	27	Lock
46622906	71.09/1	28	Lock
46622908	71.15	13	Lock
46622913	14.09	7	Motor-Engine-Cooling Fan
46622915	14.09	7	Motor-Engine-Cooling Fan
46622942	73.06/1	2	Corner Bracker R/H
46622943	73.06/1	3	Corner Bracket L/H
46622946	73.07	2	Corner Bracker R/H
46622947	73.07	1	Corner Bracket L/H
46622961	11.07	1	Camshaft
46622967	12.62	6	Air Pump
46622971	12.61/1	2	Switch Vacuum
46622974	12.01	15	Sleeve
46622976	91.14	2	Label
46622979	21.01	1	Cable-Clutch
46622981	71.09/1	38	Check Door
46622990	51.07	7	Elbow
46622994	64.01/2	3	Harness Wire
46622995	64.01/2	1	Harness-Assy Complete
46623016	71.01	16	Scoop-Hoodiblue 091
46623025	31.02	29	Line Brake
46623027	31.02	25	Line Brake
46623031	31.02	23	Line Brake
46623034	11.01/1	3	Cead Cylinder
46623036	61.01	1	Igniton Distrib
46623037	31.02	34	Line Brake
46623039	12.01/1	8	Line
46623041	12.01	17	Line
46623042	31.02	27	Line Brake
46623044	31.02	10	Line Brake
46623046	12.01/1	7	Line
46623053	12.02/1	1	Hose-Fuel Supply (Goodyear)
46623054	12.02/1	14	Sleeve
46623055	12.02/1	16	Sleeve
46623059	31.02	4	Line Brake
46623067	11.15	1	Belt
46623071	61.01	16	Plug-Spark

Part Number	Subgroup	Illus. №	Description
46623072	61.01	16	Plug-Spark
46623073	65.03	1	Speedometer
46623074	65.03	8	Speedometer
46623075	65.03	7	Heat Indicator
46623076	65.03	1	Speedometer
46623077	65.03	8	Speedometer
46623078	65.03	7	Heat Indicator
46623080	12.01/1	3	Line-Fuelreturn
46623082	12.01	25	Sleeve
46623084	81.08	3	Support
46623086	10.01	1	Engine Complete
46623088	65.06	1	Blade-Wiper Rear
46623110	81.01	25	Protection Skeleton R/H IP20
46623111	81.01	26	Protection Skeleton L/H IP20
46623112	81.01	27	Protection Skeleton R/H IP60
46623113	81.01	28	Protection Skeleton L/H IP60
46623118	81.01/1	1	Cover-Seat Back
46623119	81.01/1	2	Cover-Seat Back
46623120	81.01/2	1	Cover-Cushion
46623121	81.01/2	2	Cover-Cushion
46623123	81.01	15	Headrest IP60
46623126	12.01/1	10	Line Fuel
46623127	12.01/1	11	Line Fuel
46623129	81.02/2	2	Seat Back Complete IP60
46623131	81.02/1	2	Headrest IP60
46623140	31.02	4	Line-Brake
46623155	10.01	1	Engine-Complete
46623186	65.03	30	Switch
46623191	71.05	6	Fender-R/H Front
46623192	71.05	5	Fender-L/H Front
46623195	65.05	12	Relay
46623196	71.05	8	Panel R/H Rear Quarter
46623197	71.05	9	Panel L/H Rear Quarter
46623230	64.01/2	3	Harness-Assy
46623231	64.01/2	1	Harness-Assy
46623241	43.02	12	Bushing-Stabilizer Bar
46623252	91.16	2	Label
46623255	65.03	1	Insticluster
46623256	65.03	8	Speedometar
46623257	91.17	5	Label
46623260	65.03	1	Insticluster
46623261	65.03	8	Speedometer
46623266	31.30	4	Caliper-Brake R/H Complete
46623267	31.30	5	Caliper-Brake L/H Complete
46623271	22.07	11	Knob-Shift
46623272	22.07	12	Knob-Shift
46623274	71.25/1	2	Shield-Stone (Spoiler)
46623276	31.02/2	6	Plate
46623277	21.01	2	Cable Clutch
46623289	73.06/1	11	Support Bumper R/H
46623290	73.06/1	12	Support Bumper L/H
46623291	73.06/1	1	Bar-Front Bumper
46623297	73.06/1	9	Vertical Support Bracket R/H
46623298	73.06/1	10	Vertical Support Bracket L/H
46623299	73.06/1	5	Washer
46623301	12.02/1	14	Hose-Fuel Supply
46623302	12.02/1	16	Hose-Fuel Supply
46623303	12.01/1	4	Sleeve
46623304	12.01/1	3	Sleeve
46623305	12.01	25	Hose-Overflow/Fuel (Pirelli)

Part Number	Subgroup	Illus. №	Description
46623306	12.01/1	10	Line Fuel
46623307	12.01/1	11	Line Fuel
46623308	73.07	3	Bar-Rear Bumper
46623309	71.25/2	15	Bar-Bumper Rear
46623316	64.01/2	21	Support-Fuse Dstandardo
46623320	71.05	16	Panel-Front
46623321	71.04	11	Wheelbox R/H
46623322	71.04	7	Wheelbox L/H
46623329	91.17	1	Label
46623339	12.01	19	Sleeve
46623341	12.01	19	Sleeve
46623344	65.05	9	Arm-Wiper/Front
46623347	12.02/1	1	Hose-Fuel-Suuply
46623352	65.05	8	Blade-Wiper/Front
46623355	43.02	6	Shock Absorber
46623356	43.02	6	Absorber-Shoc/Froit (Monroe)
46623357	65.05	9	Arm-Wiper/Front
46623358	65.05	8	Blade-Wiper/Front
46623360	11.06	26	Clip
46623361	61.01	28	Rubber Ring
46623373	10.01	1	Engine-Complete
46623378	71.09	5	Door Complete L/H
46623394	91.16	1	Label
46623399	71.05	7	Panel
46623426	12.61/1	4	Switch Vacuum
46623430	81.01/1	3	Cover-Seat Back IP60
46623432	81.01/2	3	Cover Cushion IP60 R/H
46623434	91.11	1	Label
46623435	71.25/1	4	Emblem GVX
46623442	81.02	16	Sleeve
46623444	81.02	14	Headrest IP60
46623454	71.25/2	4	Moulding R/H Door
46623455	71.25/2	3	Moulding L/H Door
46623456	71.25/2	13	Panel Doorsill L/H
46623457	71.25/2	12	Panel Doorsill R/H
46623460	12.02	2	Sleeve
46623461	12.02	16	Sleeve
46623462	12.01/1	1	Sleeve
46623463	71.09/1	S	Set-Lock Complete
46623471	31.01	8	Pedal-Brake
46623473	71.25/1	1	Screw
46623473	71.25/2	17	Screw
46623478	12.01	15	Sleeve
46623480	13.01	30	Filter Oil Donit
46623492	31.35	22	Equalizer-Emergency Brake Cable
46623550	14.03	16	Body-Water Pump
46623551	63.01	18	Retainer
46623582	65.03	8	Speedometer
46623600	13.01	3	Tubing
46623601	12.58	1	Valve
46623602	12.60	1	Corrector
46623603	12.05	4	Element-Air Filter
46623608	73.07/1	1	Bar-Rear Bumper (Complete)
46623645	12.05	3	Cover-Air Filter
46623699	31.02/2	2	Reservoir
46623700	91.20	6	Label
46623744	31.02	4	Line-Brake R/H
46623745	31.02	10	Line-Brake L/H
46623746	31.02	10	Line-Brake L/H
46623747	31.02	4	Line-Brake R/H
46623760	81.01/3	6	Seat Frame R/H

Part Number	Subgroup	Illus. №	Description
46623761	81.01/3	6	Seat Frame L/H
46623778	51.01	5	Sleeve
46623811	14.02	19	Pipe
46623816	64.01/1	17	Lamp-Tail
46623818	43.16	19	Cover-Waterpump
46623827	73.06/1	4	Support
46623831	61.01	4	Cable Harnes
46623888	91.17	2	Label
46623896	12.56	28	Muffler-Rear
46623926	12.01/1	2	Line Fuel Fulton Rohr
46623936	31.35	6	Cam-Hand Brake
46623945	81.02/2	1	Cover-Seat Back
46623946	81.02/2	2	Cover-Seat Back
46623947	81.02/1	1	Cover-Cushion IP20
46623948	81.02/1	2	Cover-Cushion IP60
46623954	81.01/4	11	Handle R/H IP60
46623955	81.01/4	12	Handle L/H IP60
46623958	81.01/4	5	Handle R/H IP20
46623959	81.01/4	6	Handle L/H IP20
46623962	81.01/4	7	Handle R/H IP60
46623963	81.01/4	8	Handle L/H IP60
46623964	81.01/4	9	Handle R/H IP20
46623965	81.01/4	10	Handle L/H IP20
46623972	12.01/1	2	Line
46624001	81.02	10	Headrest IP60
46624001	81.01	15	Headrest IP60
46624002	81.01	14	Headrest IP20
46624002	81.02	9	Headrest IP20
46624008	71.25/3	3	Emblem-GVL
46624044	91.17	4	Label
46624048	91.01	2	Kit-Bulb
46624050	91.01	2	Kit-Bulb
46624077	71.01	46	Scoop Hood 427
46624078	71.01	45	Scoop Hood 410
46624079	71.01	44	Scoop Hood 324
46624080	71.01	43	Scoop Hood 211
46624081	71.01	42	Scoop Hood 181
46624083	71.01	47	Scoop Hood 620
46624084	71.01	41	Scoop Hood 107
46624101	91.14	1	Label
46624115	71.15	17	Cable
46624120	81.02	10	Headrest IP60
46624158	81.07/1	15	Moulding-Doorsill
46624159	81.07/1	16	Moulding-Doorsill
46624171	91.20	3	Label
46624172	91.20	4	Label
46624173	91.20	5	Label
46624174	91.19	4	Label
46624175	91.19	3	Label
46624176	91.19	2	Label
46624177	91.19	1	Label
46624209	13.01	30	Filter-Oil Frad
46624210	13.01	30	Filter-Oil Donit
46624250	64.01/2	3	Harness-Wire
46624251	64.01/2	1	Harness-Wire
46624252	64.01/2	12	Harness-Wire RR
46624253	12.01/1	4	Line Fuel Refurn
46624263	61.01	28	Clamp
46624271	91.20	2	Label
46624272	22.07	17	Lever-Shift Control
46624309	43.16/1	13	Space-Plate-Wheel

Part Number	Subgroup	Illus. №	Description
46624461	71.02	23	Console-Radio/Utility IP60
46624500	91.18	1	Label
46624556	91.18	3	Label
46624557	91.18	4	Label
46624643	81.01/4	17	Handle IP60
46624644	63.01	8	Alternator 65A
46624655	71.02	30	Housing-Cig/Lighter
46624656	71.02	31	Element-Cig/Lighter
46624698	71.25/3	2	Emblem Yugo
46624699	91.25	1	Label
46624701	91.25	2	Label
46624706	91.23	1	Label
46624720	71.25/2	2	Panel Rocker Front L/H
46624721	71.25/2	1	Panel Rocker Front R/H
46624802	91.24	3	Label
46624803	91.24	4	Label
46624804	91.24	2	Label
46624805	91.24	1	Label
46624818	71.25/2	5	Plastic Rivet
46624818	71.25/1	3	Plastic Rivet
46624831	71.25/2	8	Tape Stripe Door
46624835	71.25/2	11	Tape Stripe Rocker R/H
46624836	71.25/2	10	Tape Stripe Rocker L/H
46624838	71.25/2	20	Plastic Rivet
46624845	66.35	1	Lamp Tail
46624868	12.25	7	Valve Egr-Transducer
46624889	65.06	7	Motor-Wiper Rear
46624892	43.16/1	18	Wheel-Road
46624892	43.16	18	Wheel-Road
46624892	43.16	22	Wheel-Road
46624900	65.01	7	Switch-Unit/Steer Column
46624901	65.01	8	Switch-Unit/Steer Column
46624910	64.01/1	14	Lamp-Back UP
46624911	64.01/1	15	Lamp-Back UP
46624913	91.21	1	Labels
46624914	91.21	3	Labels
46624915	91.26	1	Labels
46624922	71.04/1	19	Cap
46624927	65.05	3	Windshteld Wiper-Assy
46624928	64.01/2	3	Harness-Wire
46624929	64.01/2	1	Harness-Assu
46624932	71.25/2	14	Clip-Lower Door Aplique
46624935	61.01	26	Switch-Ignition
46624936	61.01	26	Switch-Ignition
46624959	43.16/1	12	Screw
46624960	91.20	1	Label
46624981	91.22	2	Label
46624983	65.05	3	Windshield Wiper
46624989	14.09	7	Motor-Heater
46624991	14.09	7	Motor Engine Cooling Fan
46625042	71.09/2	20	Channel-Door
46625043	71.09/2	19	Channel-Door
46625044	81.09/1	1	Insulation
46625058	71.04/1	2	Protection
46625067	81.12	1	Belt-Seat Rear
46625081	91.18	2	Label
46625084	71.02	6	Panel-Dash IP60
46625092	12.01/1	7	Line
46625093	12.01/1	7	Line
46625094	12.01/1	8	Hose-Fuel Supply
46625095	12.01/1	8	Hose-Fuel Supply

Part Number	Subgroup	Illus. №	Description
46625106	71.02	23	Console/Radio Utility
46625155	81.07/1	21	Clip
46625168	65.03	19	Switch-Rear Defog
46625170	12.01/1	13	Clamp (For Goodyera)
46625170	12.01/1	14	Clamp (For Goodyera)
46625200	12.01	19	Hose-Fuel Vapor (Goodyear)
46625201	12.01/1	4	Line-Fuel Return (Goodyear)
46625202	12.01/1	3	Line-Fuel Supply (Goodyear)
46625203	12.02/1	14	Hose-Fuel Supply
46625204	12.01/1	10	Line-Fuel (Goodyear)
46625205	12.01/1	11	Line-Fuel (Goodyear)
46625206	12.02/1	16	Hose-Fuel (Goodyear)
46625207	12.02/1	1	Hose-Fuel Supply Goodyear
46625217	91.21	2	Labels
46625226	71.25/2	9	Screw
46625242	64.01/2	31	Relay-Elektronik
46625259	81.01/4	18	Handle IP20
46625285	12.61/1	1	Switch Vaccum
46625300	91.26	2	Label
46625315	71.04/1	3	Cerpet
46625320	71.05	8	Panel
46625321	71.05	9	Panel
46625344	71.25/3	4	Emblem GVS
46625355	71.06	6	Protection
46625358	81.01/1	2	Cover-Seat Back
46625359	81.01/2	2	Cover Cushion
46625360	81.01	15	Headrest
46625362	81.02/2	2	Cover-Seat Back
46625363	81.02/1	2	Cover-Cushion IP60
46625364	64.01/2	3	Harness-Assy Complete
46625365	64.01/2	1	Harnes-Assy
46625366	64.01/2	12	Harness Wipe RR
46625397	91.22	1	Label
46625401	71.09	4	Door-Complete R/H
46625402	71.09	5	Door-Complete L/H
46625419	81.06	1	Carpet IP60
46625431	81.07	21	Panel-R/H IP60
46625432	81.07	22	Panel-L/H IP60
46625448	65.03	1	Gauge-Fuel
46625449	65.03	1	Cluster-Instrument
46625456	65.03	1	Gauge-Fuel
46625457	65.03	1	Cluster-Instrument
46625470	31.35	17	Lever
46625471	31.35	18	Lever
46625496	73.07	4	Reinforcement-Rear Bumper
46625501	71.25/3	7	Emblem-GV
46625502	71.25/3	8	Emblem GVL
46625503	71.25/3	6	Weaherstrip Rear Hatch
46625514	21.01	2	Cable-Clutch
46625522	71.04/1	18	Clip
46625523	81.09	6	Insulation
46625537	71.06	2	Spacer
46625541	64.01/1	1	Lamp-Side Marker R/H
46625542	64.01/1	4	Lamp-Side Marker L
46625543	64.01/1	5	Lamp-Side Marker
46625545	71.25/1	5	Emblem GVX
46625600	71.04	8	Panel-Dash
46625627	31.01	1	Support
46625628	81.01	16	Guide
46625645	91.23	3	Label

Part Number	Subgroup	Illus. №	Description
46625646	91.23	2	Label
46625666	10.01/1	22	Support-Transmossion
46625694	31.02/2	2	Reservoir
46625697	64.01/2	9	Support
46625739	81.01/1	4	Cover-Seat Back IP60 L/H
46625740	81.01/2	4	Cover Cushion IP60 L/H
46625761	65.05	12	Relay-Wiper
46625858	91.27	2	Label
46625859	91.27	1	Label
46625862	91.28	1	Label
46625980	71.25/2	16	Plastic Rivet
46625991	31.02/1	10	Compensator-Brake Action
46625995	31.02/1	11	Line Brake L/H
46625996	31.02/1	11	Line Brake L/H
46625997	31.02/1	9	Line Brake
46625999	31.02/1	9	Line Brake
46626001	31.02/1	8	Line Brake
46626003	31.02/1	8	Line Brake
46626013	31.02/1	1	Line Brake
46626015	31.02/1	1	Line Brake
46626017	31.02/1	2	Line Brake
46626019	31.02/1	2	Line Brake
46626045	43.16	23	Cover-Wheel
46626094	10.01	1	Engine-Complete
46626096	10.01	1	Engine-Complete
46626098	64.01/1	10	Lamp-Rear Side Marker
46626342	12.61/1	3	Sleeve
46626503	71.05	8	Panel
46626504	71.05	9	Panel
46626505	64.01/2	12	Harness-Wire RR
46626511	73.07	10	Washer
46626574	81.06	1	Carpet
46626620	71.04/1	3	Pan-Floor
46626622	65.03	22	Rheostat-Dash Light
46626623	65.03	31	Knob-Dash Rheostat
46626694	91.24	5	Label
46626694	91.28	2	Label
46626698	12.01	23	Cao-Fuel/Locking
46626700	12.01	23	Cao-Fuel/Locking
46626713	22.07	8	Plate-Shift
46626716	64.01/2	24	Clamp-Selfadhesive
46626717	64.01/2	25	Clamp
46626732	65.03	21	Harness-Wire
46626734	65.03	21	Harness-Wire
46626778	65.06	2	Arm-Wiper Rear
46626803	71.09/1	S	Kit
46626804	71.09/1	S	Set-Lock Complete
46626867	71.25/2	14	Clip
46626886	73.07	8	Reinforcement-Rear Bumper
46626930	63.01	18	Kable + Battery
46627036	71.15	4	Glass-Rear Door
46627056	73.01	5	Grille-Front/Radiator
46627080	73.06/1	1	Support Bumper-Front
46627139	73.01	1	Bezel-Headlamp R/H
46627140	73.01	6	Bazel-Headlamp L/H
46627410	64.01/1	8	Lamp-Tail R/H
46627412	64.01/1	9	Lamp-Tail L/H
46627493	91.29	5	Label
46627495	91.29	3	Label
46627496	91.29	8	Label
46627497	91.29	7	Label

Part Number	Subgroup	Illus. №	Description
46627499	91.29	9	Label
46627501	91.29	6	Label
46627502	91.29	2	Label
46627503	91.29	1	Label
46627557	71.15	14	Weatherstrip
46627576	81.01/1	2	Cover-Seat Back IP60
46627577	81.01/1	1	Cover-Seat Back IP20
46627579	81.01/2	2	Cover Cushion IP60
46627580	81.01/2	1	Cover Cushion IP20
46627777	71.15	4	Glass-Rear Door
46627875	64.01/2	3	Harness-Wire
46627876	64.01/2	1	Harness-Assy
46627916	64.01/2	12	Harness-Wire RR
46628001	71.06	6	Bolster-Knee
46628015	65.01	19	Buzzer
46628016	81.12	1	Belt-Seat
46628152	64.01/2	12	Harness-Wire
46628863	65.06	9	Bushing
46628864	65.06	8	Casing
46629143	91.30	2	Label
46629144	91.30	1	Label
46629145	91.32	2	Label
46629146	91.31	2	Emblem
46629147	91.31	1	Emblem
46629148	91.32	1	Emblem
46629249	71.06	6	Bolster-Knee
46629250	71.02	6	Panel-Dash IP60
46641202	12.04/1	4	Gasket-Carburetor
46641203	12.04/1	5	Spacer-Carburetor
46641232	11.01	11	Gasket
46641235	11.06	1	Cover-Timing Belt
46641236	11.01	20	Head-Cylinder
46641248	14.02	5	Pump-Water
46641249	14.02	23	Hose Waser L/260
46641250	12.62	10	Backrt Air Pump
46641295	12.62	15	Screw
46641321	11.05/1	6	Pin
46641322	11.05/1	1	Connecting Rod Compl
46641330	12.02/1	3	Pump-Fuel
46641339	61.01	16	Plug-Spark
46641342	10.01	2	Engine-Inocomplete
46641344	10.01	3	Engine-Short/Block
46641345	11.01/1	3	Head Cylinder
46641348	11.01	20	Head Cylinder
46641361	11.15	2	Belt Alternator/Water Pump
46641386	63.01	8	Alternator
46641387	63.01	8	Alternator
46641422	12.54	2	Connection Servo-Brake
91701767	31.35	5	Lever
91701926	22.01	4	Transmission
91702761	65.06	1	Blade-Wiper Rear
91703152	14.01	1	Radiator-Cooling
91703156	22.01/1	13	Housing-Transmission
91703221	71.01	48	Scoop Hood
91703253	81.01	2	Seat-Front Comp IP60
91703254	81.01	1	Seat-Front Complete IP20
91703255	81.01	18	Saet-Front Complete IP60
91703256	81.01	17	Seat-Front Complete IP20
91703304	51.01	3	Heater Assy
91703380	22.01	4	Transmisson
91703521	64.01/2	12	Harness Wire RR

Part Number	Subgroup	Illus. №	Description
91703581	81.02	1	Seat-Rear Complete IP20
91703582	81.02	2	Seat-Rear Complete IP60
91703583	81.02	15	Cushion-Seat IP20
91703584	81.02	16	Cushion-Seat IP60
91703585	81.02	13	Seat-Back Complete IP20
91703586	81.02	14	Seat-Back Complete IP60
91703622	22.01	4	Transmission
91703682	81.01	2	Seat-Front Complete R/H IP60
91703683	81.01	18	Seat-Front Complete L/H IP60
91703684	81.01	1	Seat-Front Complete R/H IP20
91703685	81.01	17	Seat-Front Complete IP20
91703686	81.02	18	Seat-Front Complete
91703687	81.02	19	Seat-Front Complete
91703688	81.02	1	Seat-Rear Complete IP20
91703689	81.02	2	Seat-Rear Complete IP60
91703691	73.06	1	Bar-Front Bumper (Complete)
91703695	81.01	2	Seat-Front Complete IP60 R/H
91703696	81.01	18	Seat-Front Complete IP60 L/H
91703698	81.02	2	Seat-Rear Complete IP60
91703706	64.01/2	1	Harness-Wire
91703712	81.01	1	Seat-Front Complete IP20
91703713	81.01	17	Seat-Front Complete IP20
91703714	81.01	2	Seat-Front Complete IP60
91703715	81.01	18	Seat-Front Complete IP60
91703759	71.02	23	Console IP60
91703760	71.02	22	Console IP20
91703816	65.05	9	Arm-Wiper/Front
91703911	81.01	2	Seat-Front Complete R/H
91703912	81.01	18	Seat-Front Complete L/H
91703913	81.02	19	Seat-Rear Complete
91703964	31.35	5	Lever
91704109	81.02	13	Seat-Back Complete
91704110	81.02	14	Seat-Back Complete
91704111	81.02	14	Seat-Back Complete
91704112	81.02	13	Seat-Back Complete
91704113	81.02	14	Seat-Back Complete
91704114	81.02	18	Seat-Rear Complete
91704115	81.02	19	Seat-Rear Complete
91704116	81.02	18	Seat-Rear Complete IP20
91704117	81.02	19	Seat-Rear Complete
91704118	81.02	19	Seat-Rear Complete
91704156	65.06	7	Motor-Wiper Rear
91705166	64.01/2	1	Harness-Assy Complete
91704167	64.01/2	1	Harness-Assy
91704183	64.01/2	1	Harness-Assy
91704184	64.01/2	1	Harness-Assy
91704207	81.01	2	Seat-Front Complete IP60 R/H
91704208	81.01	18	Seat-Front Complete IP60 L/H
91704209	81.01	1	Seat-Front Complete IP20 R/H
91704210	81.01	17	Seat-Front Complete IP20 L/H
91704259	64.01/2	1	Harness-Assy

PART NUMBER LISTING REVISIONS

NO	Replaced Part	Replacing Part	Subgroup	Illus No	Description
1	2	3	4	5	6
1.	—	1450292 (58)	14.02	1	Sending Unit
2.	—	1469658 (27)	73.06	5	Bar — Bumper
3.	—	1469660 (27)	73.07/1	8	Bar — Bumper
4.	—	1644273 (58)	73.06	5	Bar — Bumper
5.	—	1644275 (58)	73.07/1	8	Bar — Bumper
6.	—	4050791 (58)	71.06/1	8	Lock — Washer
7.	—	4068085 (58)	71.06/1	12	Bumper
8.	—	4114059 (58)	13.01/1	3	Trap — Flame
9.	—	4130913 (58)	12.04/3	9	Bushing
10.	—	4151335 (58)	71.06/1	9	Hinge
11.	—	4193835 (58)	12.01/2	39	Seal Filler Neck
12.	—	4320893 (58)	11.06	10	Bearing — Idler
13.	—	4399987 (58)	71.09/3	12	Clip
14.	—	4420827 (58)	64.01/1	6	Lamp — License Plate
15.	—	4421244 (58)	71.04/1	14	Wheelbox R/H
16.	—	4430260 (58)	12.01/2	12	Seal
17.	—	7575857 (58)	11.06	5	Belt — Timing
18.	—	7576136 (58)	11.06	5	Belt — Timing
19.	—	10396180 (58)	71.01	14	Grooved Bush
20.	—	10443011 (58)	66.14/1	9	Screw
21.	—	10516470 (58)	12.26	6	Washer — Lock
22.	—	10516470 (58)	12.01/2	43	Washer — Lock
23.	—	10516470 (58)	12.01/3	9	Washer — Lock
24.	—	10516670 (58)	12.01/2	20	Washer — Lock
25.	—	10519201 (58)	65.01/1	8	Washer
26.	—	10519201 (58)	12.01/2	6	Washer
27.	—	10519307 (58)	12.04/3	6	Washer — Lock
28.	—	10519401 (58)	65.01/1	15	Washer
29.	—	10571370 (58)	65.01/1	9	Washer — Lock
30.	—	10571470 (58)	66.14/1	11	Washer
31.	—	10571570 (58)	65.01/2	7	Washer
32.	—	10720111 (58)	12.01/3	15	Nut
33.	—	10721911 (58)	65.01/1	14	Nut M4
34.	—	10794011 (58)	65.01/1	10	Nut
35.	—	10902121 (58)	12.21	10	Screw
36.	—	10902621 (58)	12.01/3	8	Screw
37.	—	10979424 (58)	12.26	7	Screw MG x 10
38.	—	11054890 (58)	64.01/3	22	Fuse 7.5 AMP
39.	—	11087776 (58)	12.02/2	6	Washer Lock
40.	—	11193270 (58)	12.21	9	Washer Lock
41.	—	11193970 (58)	12.54/1	15	Washer
42.	—	11194070 (58)	12.26	2	Washer Lock
43.	—	11195370 (58)	65.01/1	9	Washer Lock
44.	—	11197770 (58)	12.04/3	12	Washer Lock
45.	—	12177390 (58)	12.04/3	2	Clamp
46.	—	12179990 (58)	12.54/1	14	Clamp
47.	—	12181090 (58)	12.01/2	17	Clamp
48.	—	12182190 (58)	12.54/1	3	Clamp
49.	—	12182490 (58)	12.01/2	9	Clamp
50.	—	12182490 (58)	12.01/3	4	Clamp
51.	—	12182790 (58)	12.01/2	13	Clamp
52.	—	12598071 (58)	65.01/1	13	Washer
53.	—	12599079 (58)	71.06/1	10	Washer
54.	—	12599171 (58)	61.01/1	4	Lockwasher
55.	—	12605270 (58)	65.01/1	2	Washer
56.	—	12605370 (58)	65.01/1	4	Washer
57.	—	12642801 (58)	12.01/2	38	Washer 4 x 12
58.	—	12646700 (58)	12.02/2	5	Washer
59.	—	12647001 (58)	12.01/2	19	Washer
60.	—	12647101 (58)	12.54/1	12	Washer

1	2	3	4	5	6
61.	—	13000990 (58)	12.04/3	2	Clamp
62.	—	13273011 (58)	65.01/1	12	Screw M4
63.	—	13274217 (58)	12.01/2	27	Screw
64.	—	13274817 (58)	12.04/3	5	Screw
65.	—	13276001 (58)	71.06/1	11	Screw
66.	—	13424017 (58)	13.01/1	7	Clamp
67.	—	13516811 (58)	12.54/1	16	Stud
68.	—	13588524 (58)	12.54/1	8	Stud
69.	—	13588924 (58)	12.54/1	9	Stud
70.	—	13589024 (58)	12.54/1	6	Stud
71.	—	14089811 (58)	12.04/3	7	Nut
72.	—	14150190 (58)	64.01/3	25	Bulb
73.	—	14205380 (58)	31.02	5	Hose
74.	—	14287811 (58)	61.01/1	3	Screw
75.	—	14305520 (58)	66.14/1	10	Screw
76.	—	14305520 (58)	11.02	30	Screw
77.	—	14305520 (58)	12.04/3	11	Screw
78.	—	14418921 (58)	12.01/2	37	Screw M4 x 0,7 x 8
79.	—	14496401 (58)	12.01/3	10	Washer
80.	—	14497764 (58)	65.01/1	8	Washer
81.	—	14560180 (58)	64.01/3	8	Clip
82.	—	14567787 (58)	65.01/2	11	Slamp
83.	—	14568280 (58)	65.01/2	10	Slamp
84.	—	14572686 (58)	64.01/3	23	Clip
85.	—	14575580 (58)	12.01/3	17	Clip
86.	—	15687207 (58)	71.04/1	20	Screw
87.	—	15690707 (58)	81.01	24	Screw M6 x 16
88.	—	15896211 (58)	65.01/2	6	Nut M6
89.	—	15896211 (58)	65.01/1	5	Nut M6
90.	—	15896411 (58)	65.01/1	3	Nut
91.	—	15902607 (58)	71.04/1	20	Screw
92.	—	15903307 (58)	73.06	23	Screw (M8 x 22)
93.	—	16043121 (58)	12.01/2	42	Screw M8
94.	—	16043521 (58)	12.26	3	Screw M8 x 22
95.	—	16100811 (58)	12.01/2	21	Nut
96.	—	46617403 (58)	71.01	13	Bracket
97.	—	46618001 (58)	22.01	53	Switch
98.	—	46620232 (58)	71.04/1	15	Wheel Box L/H
99.	—	46622659 (58)	65.01/1	19	Washer
100.	—	46622763 (58)	65.01/1	19	Washer
101.	—	46624034 (58)	12.01/2	25	Support
102.	—	46626024 (58)	64.01/3	27	Lamp — Interior/Roof
103.	—	46626382 (58)	81.08	1	Support — Spare Tire
104.	—	46626408 (58)	73.06	1	Bar — Front Bumper
105.	—	46626409 (58)	73.07/1	1	Bar — Rear Bumper
106.	—	46626415 (58)	12.56/1	20	Muffler — Rear
107.	—	46626448 (58)	12.01/2	18	Hose
108.	—	46626461 (58)	65.01/1	16	Support/Switch
109.	—	46626767 (58)	12.01/2	36	Tank — Fuel
110.	—	46626768 (58)	12.01/2	35	Tank — Fuel
111.	—	46626798 (58)	12.02/2	2	Housing
112.	—	46626800 (58)	12.02/2	4	Shaft/Support
113.	—	46626801 (58)	12.01/3	11	Filter — Fuel
114.	—	46626879 (58)	64.01/1	18	Headlamp R/H
115.	—	46626880 (58)	64.01/1	19	Headlamp L/H
116.	—	46626887 (58)	12.02/2	1	Busning/Fuel Pump
117.	—	46626905 (58)	12.01/3	19	Line — Fuel
118.	—	46626906 (58)	12.01/3	18	Line — Fuel Return
119.	—	46626928 (58)	12.56/1	14	Seal
120.	—	46626935 (58)	71.05	7	Panel Rear
121.	—	46627068 (58)	71.05	10	Panel — Roof
122.	—	46627078 (58)	12.01/2	11	Filter — Fuel/Tank
123.	—	46627101 (58)	81.07	31	Strap — Tool Kit
124.	—	46627316 (58)	12.01/2	34	Line — Intake Manifold
125.	—	46627317 (58)	12.01/2	30	Line — Fuel Vapor
126.	—	46627318 (58)	12.01/2	32	Hose — Regulator Valve

1	2	3	4	5	6
127.	—	46627329 (58)	12.04/1	4	Hose
128.	—	46627384 (58)	12.01/2	10	Hose — Fuel
129.	—	46627398 (58)	12.56/1	8	Converter — Catalytic
130.	—	46627520 (58)	12.04/3	1	Element — Air Filter
131.	—	46627809 (58)	12.04/3	8	Air — Filter
132.	—	46627812 (58)	12.04/3	3	Hose
133.	—	46627816 (58)	13.01/1	1	Housing — Separator
134.	—	46627817 (58)	13.01/1	31	Sleeve
135.	—	46627977 (58)	65.01/2	1	Electronic Directing Unit
136.	—	46627984 (58)	12.01/2	4	Pump — Fuel Electric
137.	—	46627985 (58)	61.01	2	Coil
138.	—	46628015 (58)	65.01/1	1	Buzzer
139.	—	46628089 (58)	81.07/1	1	Handle Grab
140.	—	46628093 (58)	81.07/1	15	Moulding R/H
141.	—	46628094 (58)	81.07/1	16	Moulding L/H
142.	—	46628099 (58)	81.07/1	18	Moulding — Carpet R/H
143.	—	46628100 (58)	81.07/1	19	Moulding — Carpet L/H
144.	—	46628110 (58)	81.07	33	Panel
145.	—	46628113 (58)	81.07	32	Panel
146.	—	46628252 (58)	81.07	40	Lining
147.	—	46628331 (58)	81.07/1	4	Visor R/H
148.	—	46628334 (58)	81.07/1	10	Visor L/H
149.	—	46628337 (58)	81.07/1	20	Hanger
150.	—	46628421 (58)	65.01/1	6	Timer
151.	—	46628452 (58)	14.02	22	Hose — Radiator
152.	—	46628481 (58)	12.01/2	31	Valve — Regulator
153.	—	46628482 (58)	12.01/2	33	Switch — Regulator Valve
154.	—	46628484 (58)	74.04/1	5	Rail R/H
155.	—	46628485 (58)	71.04/1	6	Rail L/H
156.	—	46628536 (58)	65.01/1	6	Timer — Electronic
157.	—	46628629 (58)	81.09	9	Clip
158.	—	46628704 (58)	12.01/2	2	Ring
159.	—	46628708 (58)	12.01/2	3	Support
160.	—	46628767 (58)	81.07	37	Clip
161.	—	46628768 (58)	65.01/2	9	Cable — Assy
162.	—	46628842 (58)	12.01/2	8	Hose — Fuel Return
163.	—	46628862 (58)	12.01/2	5	Screw
164.	—	46628881 (58)	12.01/3	13	Bracket
165.	—	46628882 (58)	12.01/3	14	Bracket
166.	—	46628886 (58)	12.01/3	12	Support — Filter Fuel
167.	—	46628906 (58)	71.01	17	Hood Engine
168.	—	46629014 (58)	12.56/1	7	Screw
169.	—	46629026 (58)	12.56/1	6	Spring
170.	—	46629053 (58)	12.56/1	1	Pipe — Front Exhaust
171.	—	46629054 (58)	12.56/1	5	Bushing
172.	—	46629055 (58)	12.56/1	21	Bracket Compl.
174.	—	46629056 (58)	12.56/1	26	Stud
175.	—	46629057 (58)	12.56/1	25	Bracket
176.	—	46629064 (58)	13.01/1	4	Housing/Trap Flame
176.	—	46629065 (58)	13.01/1	2	Hose
177.	—	46629066 (58)	13.01/1	19	Sleeve
178.	—	46629072 (58)	12.56/1	17	Half Schelle
179.	—	46629093 (58)	12.56/1	2	Gasket
180.	—	46629110 (58)	21.05	1	Plate — Driven
181.	—	46629183 (58)	12.01/3	3	Groomet — Fuel Line
182.	—	46629214 (58)	12.21	2	Cable — Accelerator
183.	—	46629221 (58)	12.01/3	16	Clip
184.	—	46629238 (58)	65.01/1	18	Support
185.	—	46629239 (58)	12.01/2	1	Sendin Unit
186.	—	46629269 (58)	12.01/2	14	Cap Fuel
187.	—	46629280 (58)	65.03/1	18	Bulb
188.	—	46629330 (58)	65.01/1	17	Switch — Ambiantal
189.	—	46629366 (58)	65.01/1	11	Switch
190.	—	46629367 (58)	12.56/1	5	Bushing
191.	—	46629385 (58)	43.01	11	Spring
192.	—	46629398 (58)	64.01/3	21	Support — Fuse 7,5 AMP

1	2	3	4	5	6
193.	—	46629544 (58)	12.01/2	15	Tube — Filler
194.	—	46629591 (58)	81.07	23	Pillar R/H Rear
195.	—	46629592 (58)	81.07	24	Pillar L/H Rear
196.	—	46629602 (58)	81.07	38	Panel R/H Cargo
197.	—	46629603 (58)	81.07	39	Panel L/H Cargo
198.	—	46629613 (58)	12.01/2	22	Hose — Vapor
199.	—	46629631 (58)	81.07	17	Panel — Speaker R/H
200.	—	46629632 (58)	81.07	18	Panel — Speaker L/H
201.	—	46629738 (58)	71.04/1	12	Support L/H
202.	—	46629742 (58)	12.01/2	41	Line — Vapor Valve
203.	—	46629743 (58)	12.01/2	24	Line — Rollower Valve
204.	—	46629770 (58)	12.01/2	40	Rollower Valve
205.	—	46629830 (58)	71.06/1	13	Lid/Cap
206.	—	46629855 (58)	71.06/1	7	Support
207.	—	46629913 (58)	65.01/1	7	Conector
208.	—	46629931 (58)	71.06/1	14	Striker Plate
209.	—	46629969 (58)	71.05	8	Panel — R/H Rear
210.	—	46629970 (58)	71.05	9	Panel L/H Rear
211.	—	46629971 (58)	71.05	S	Panel — QTR/Complete R/H
212.	—	46629972 (58)	71.05	S	Panel — QTR/Complete L/H
213.	—	46629973 (58)	71.04/1	16	Panel — Inner R/H
214.	—	46629974 (58)	71.04/1	17	Panel — Inner L/H
215.	—	46630057 (58)	91.01	2	Kit — Bulb Fuse
216.	—	46630059 (58)	91.01	2	Kit — Bulb Fuse
217.	—	46630119 (58)	64.01/1	8	Lamp Tail R/H
218.	—	46630120 (58)	64.01/1	9	Lamp Tail L/H
219.	—	46630159 (58)	64.01/3	6	Relay
220.	—	46630173 (58)	65.03/1	1	Cluster — Instrument
221.	—	46630174 (58)	65.03/1	1	Cluster — Instrument
222.	—	46630178 (58)	64.01/3	7	Relay
223.	—	46630189 (58)	71.04	4	Support Battery
224.	—	46630288 (58)	12.01/2	23	Line — Fuel Vapor
225.	—	46630289 (58)	65.01/2	5	Bushing
226.	—	46630296 (58)	12.01/2	23	Line — Fuel Vapor
227.	—	46630358 (58)	12.56/1	15	Pipe — Exhaust
228.	—	46630422 (58)	71.09/1	S	Set — Lock Complete
229.	—	46630559 (58)	71.12	1	Belt — Seat IP60
230.	—	46630580 (58)	81.07	36	Clip
231.	—	46630632 (58)	12.04/3	10	Bushing
232.	—	46630638 (58)	91.01	4	Jack
233.	—	46630645 (58)	65.01/2	3	Silencer
234.	—	46630756 (58)	63.01	22	Battery (Tesla)
235.	—	46630758 (58)	63.01	22	Battery (Trepča)
236.	—	46630773 (58)	12.01/3	19	Line — Fuel
237.	—	46630774 (58)	12.01/3	18	Line — Fuel Return
238.	—	46630791 (58)	12.21	7	Spring
239.	—	46630810 (58)	71.01	16	Rod Stay/Hood
240.	—	46630939 (58)	71.04	1	Stone Guard
241.	—	46630992 (58)	81.01	15	Headrest IP60
242.	—	46630998 (58)	81.01/1	2	Cover — Seat Back IP60
243.	—	46631030 (58)	81.01/2	2	Cover — Cushion IP60
244.	—	46631080 (58)	81.02/2	2	Cover — Seat Back IP60
245.	—	46631083 (58)	81.02/1	2	Cover — Cushion IP60
246.	—	46631126 (58)	71.25/3	9	Emblem GV Plus
247.	—	46631137 (58)	81.07/1	23	Panel — Storage
248.	—	46631155 (58)	71.09/3	3	Panel Door IP60 R/H
249.	—	46631156 (58)	71.09/3	4	Panel Door IP60 L/H
250.	—	46631179 (58)	81.07	21	Panel R/H
251.	—	46631180 (58)	81.07	22	Panel L/H
252.	—	46631255 (58)	81.06	1	Carpet IP60
253.	—	46631261 (58)	12.21	6	Pedal Accelerator
254.	—	46631282 (58)	71.25/3	10	Emblem EFI
255.	—	46631286 (58)	81.09	6	Insulation
256.	—	46631289 (58)	71.04	8	Panel — Dash
257.	—	46631301 (58)	71.02	6	Panel — Dash
258.	—	46631307 (58)	71.04/1	11	Support R/H

1	2	3	4	5	6
259.	—	46631310 (58)	71.04/1	3	Pan — Floor
260.	—	46631316 (58)	71.04	11	Wheelbox R/H
261.	—	46631317 (58)	71.04	7	Wheelbox L/H
262.	—	46631322 (58)	64.01/3	3	Harness — Wire
263.	—	46631323 (58)	64.01/3	1	Harness — Assy
264.	—	46631324 (58)	64.01/3	12	Harness — Wire RR
265.	—	46631389 (58)	64.01/1	14	Lamp — Back UP R/H
266.	—	46631390 (58)	64.01/1	15	Lamp — Back UP L/H
267.	—	46631429 (58)	81.11	2	Belt — Seat Rear
268.	—	46631436 (58)	71.02	26	Panel Under Dashboard
269.	—	46631493 (58)	12.01/2	7	Gasket
270.	—	46631495 (58)	12.01/3	7	Line — Fuel
271.	—	46631497 (58)	12.01/3	5	Line — Fuel
272.	—	46631498 (58)	12.01/3	1	Line — Fuel
273.	—	46631499 (58)	12.01/3	6	Line — Fuel
274.	—	46631500 (58)	12.01/2	16	Hose — Overflow
275.	—	46631505 (58)	65.01/2	2	Hose Elektronik Directing
276.	—	46631506 (58)	65.01/2	4	Hose/Silencer
277.	—	46631507 (58)	12.01/3	2	Line — Fuel
278.	—	46641352 (58)	66.14/1	1	Cap — Distributor
279.	—	46641451 (58)	11.01	29	Cover — Distributor
280.	—	46641452 (58)	66.14/1	2	Shielo — Distributor
281.	—	46641455 (58)	66.14/1	5	Rectifier
282.	—	46641458 (58)	66.14/1	7	Clip
283.	—	46641459 (58)	66.14/1	8	Clip
284.	—	46641468 (58)	1.06	1	Cover — Timing Belt
285.	—	46641466 (58)	11.02	31	Cover — Engine
286.	—	46641474 (58)	12.54/1	1	Manifold — Intake
287.	—	46641476 (58)	12.54/1	7	Gasket
288.	—	46641483 (58)	12.54/1	10	Manifold
289.	—	46641485 (58)	11.07	1	Camshaft
290.	—	46641487 (58)	11.06	15	Wheel
291.	—	46641488 (58)	11.06	15	Wheel
292.	—	46641490 (58)	11.06	14	Wheel
293.	—	46641492 (58)	11.06	14	Wheel
294.	—	46641493 (58)	12.04/3	4	Support
295.	—	46641507 (58)	12.04/3	14	Sending Unit
296.	—	46641512 (58)	12.26	5	Regulator
297.	—	46641513 (58)	12.26	1	Pipe
298.	—	46641528 (58)	13.01/1	12	Gear — Oil Pump
299.	—	46641530 (58)	13.01/1	10	Shaft — Oil Pump
300.	—	46641531 (58)	11.06	16	Wheel
301.	—	46641532 (58)	11.06	16	Wheel
302.	—	46641534 (58)	14.02	39	Pipe
303.	—	46641538 (58)	51.01	9	Connector
304.	—	46641540 (58)	14.02	28	Housing
305.	—	46641541 (58)	11.15	4	Pulley Crankshaft
306.	—	46641542 (58)	11.15	4	Pulley Crankshaft
307.	—	46641545 (58)	11.02	32	Sending Unit — Counter
308.	—	46641548 (58)	12.26	4	Jet — Fuel
309.	—	46641550 (58)	14.02	40	Sending Unit
310.	—	46641551 (58)	12.04/3	16	Sending — Unit
311.	—	46641552 (58)	12.54/1	5	Regulator
312.	—	46641555 (58)	12.54/1	11	Sonde
313.	—	46641558 (58)	10.01	4	Engine — Complete
314.	—	46641560 (58)	10.01	5	Engine — Incomplete
315.	—	46641561 (58)	10.01	6	Engine — Short/Block
316.	—	46641562 (58)	11.01/1	3	Head Cylinder Complete
317.	—	46641564 (58)	11.01	20	Head Cylinder
318.	—	46641568 (58)	65.01/2	8	Clamp
319.	—	46641572 (58)	12.54/1	2	Hose
320.	—	46641613 (58)	12.21	8	Support
321.	—	46641619 (58)	12.04/3	13	Gasket
322.	—	46641622 (58)	66.14/1	3	Rotor
323.	—	46641623 (58)	66.14/1	4	Screw
324.	—	46641631 (58)	13.01/1	10	Shaft — Oil Pump

1	2	3	4	5	6
325.	—	46641634 (58)	12.04/3	15	Shield
326.	—	46641645 (58)	66.14/1	6	O — Ring
327.	—	46641653 (58)	61.01	9	Clip
328.	—	46641674 (58)	14.02	5	Pump — Water
329.	—	46641738 (58)	14.03	20	Pulley — Water Pump
330.	—	46641987 (58)	61.01/1	10	Plug Spark
331.	—	46641923 (58)	61.01/1	1	Cable Assy
332.	—	91704705 (58)	81.02	16	Cushion — Seat IP60
333.	—	91704708 (58)	81.02	14	Seat — Back Complete IP60
334.	—	91704753 (58)	81.01	1	Seat — Front Complete R/H
335.	—	91704754 (58)	81.01	18	Seat — Front Complete L/H
336.	—	91704755 (58)	81.02	19	Seat — Rear Complete IP60
337.	—	91704767 (58)	81.07	37	Clip

PART NUMBER LISTING REVISIONS

No	Replaced Part	Replacing Part	Subgroup	Illus No	Description
1	2	3	4	5	6
1.		4112977	71.05/1	2	Screw
2.		4363896 (48)	81.02	27	Latch-Seat L/H
3.		4424367	71.05/1	9	Panel-Cowl
4.		4425170 (48)	71.16	2	Latch-Rear Door
5.		4437918 (48)	81.02	26	Latch-Seat R/H
6.	10519201	10519301 (58)	65.01/1	8	Washer
7.	10571370	10571470 (58)	65.01/1	9	Washer
8.	11195370	11195470 (58)	65.01/1	9	Washer-Ignition Coil
9.		12612207	81.07/2	15	Washer
10.		13836021	71.16	9	Screw M6X12
11.		14063807	71.19	21	Screw
12.		14151590	64.01/1	2	Bulb
13.		14570680	71.09/4	15	Clip
14.		14578083	71.16	12	Sleeve-Door Lock Rod
15.		15644007	71.05/1	1	Screw-Front License-Plate
16.		15690707	81.07/2	14	Screw M6X16
17.		15896411	65.01/1	6	Nut
18.		15904907	71.09/3	5	Screw 12X38
19.		46616225 (48)	64.01/1	22	Number Plate Lamp
20.	14418921	46619415 (58)	12.01/2	37	Screw M4X8, 5/Sending Unit
21.		46620022 (48)	12.05	3	Cover-Air Filter
22.		46620129	71.05/1	4	Protection For Engine
23.		46620295	71.05/1	8	Bracket
24.		46620624	71.09/4	14	Handle
25.		46620656	71.09/4	16	Ring
26.		46621221	71.05/1	7	Gasket
27.		46621976 (48)	71.16	8	Screw Strut Hatch
28.		46622328 (48)	10.01/1	30	Support-Transmission
29.		46625191 (48)	71.05/1	6	Fender-R/H Front
30.		46623192 (48)	71.05/1	5	Fender-L/H Front
31.		46623218 (48)	81.07/3	5	Grommet
32.		46623816	64.01/1	17	Lamp-Tail
33.		46625155 (48)	71.09/3	6	Clip
34.		46626103 (48)	71.05/1	8	Panel L/H Rear Quarter Assy
35.		46626104 (48)	71.04/1	16	Panel Inner Quarter R/H
36.		46626105 (48)	71.04/1	17	Panel Inner Quarter L/H
37.		46626108 (48)	71.05/2	14	Front Qtr Reinf Inner Assy R/H
38.		46626109 (48)	71.05/2	15	Front Qtr Reinf Inner Assy L/H
39.		46626127 (48)	71.05/1	12	Winoshield Frame Reinf-Inr
40.		46626130 (48)	71.05/1	11	Pillar-Windshield R/H
41.		46626131 (48)	71.05/1	10	Pillar-Windshield L/H
42.		46626133 (48)	71.05/2	7	Tailgate Sill Reinf Assy
43.		46626134 (48)	71.05/2	8	Rear Close-Out Panel Reinf Assy
44.		46626135 (48)	71.05/2	9	Upper Trough
45.		46626140 (48)	71.05/2	10	Tailgate Sill
46.		46626148 (48)	71.05/1	13	Winoshield Frame Reinf-Otr
47.		46626151 (48)	71.05/1	14	Panel Rear
48.		46626158 (48)	71.05/2	1	Rocker Reinf R/H
49.		46626159 (48)	71.05/2	2	Rocker Reinf L/H
50.		46626160 (48)	71.05/2	3	Reinf-B-Pillar Front R/H
51.		46626161 (48)	71.05/2	4	Reinf-B-Pillar Front L/H
52.		46626162 (48)	71.09	13	Door Complete R/H
53.		46626163 (48)	71.09	14	Door Complete L/H

1	2	3	4	5	6
54.	46626206 (48)	71.09/4	12	Channel/Door-Glass R/H	
55.	46626207 (48)	71.09/4	13	Channel/Door-Glass L/H	
56.	46626208 (48)	71.09/4	6	Channel/Door-Glass R/H	
57.	46626209 (48)	71.09/4	7	Channel/Door-Glass L/H	
58.	46626210 (48)	71.04/1	23	Rail R/H	
59.	46626211 (48)	71.04/1	24	Rail L/H	
60.	46626222 (48)	71.09/4	8	Glass-Door	
61.	46626223 (48)	71.09/4	9	Glass-Door	
62.	46626224 (48)	71.09/4	4	Rear Door Chanel W Strip	
63.	46626225 (48)	71.09/4	5	Assy R/H	
64.	46626236 (48)	71.05/2	5	Rear Door Chanel W Strip	
65.	46626237 (48)	71.05/2	6	Assy L/H	
66.	46626251 (48)	71.18/1	5	Rear Reinf-B-Pillar R/H	
67.	46626256 (48)	81.02/1	2	Rear Reinf-B-Pillar L/H	
68.	46626262 (48)	71.04/1	4	A-Pillar Header W/Strip	
69.	46626265 (48)	81.02/2	2	Assy	
70.	46626266 (48)	71.22	1	Cover-Cushion IP60	
71.	46626269 (48)	71.19	18	Reinforcement-Floor Pan	
72.	46626270 (48)	71.19	19	Cover-Seat Back IP60	
73.	46626290 (48)	71.22	50	Topstack Assy	
74.	46626291 (48)	71.22	49	Glass-Rear Otr R/H	
75.	46626294 (48)	71.22	40	Glass-Rear Otr L/H	
76.	46626295 (48)	71.22	39	Inner Side Rail Hinge L/H	
77.	46626314 (48)	71.16	3	Inner Side Rail Hinge R/H	
78.	46626316 (48)	81.01	15	1 Pivot Link L/H	
79.	46626318 (48)	81.01/2	2	1 Pivot Link R/H	
80.	46626320 (48)	71.22	38	Rod Latch Lock Control	
81.	46626321 (48)	71.22	37	Headrest IP60	
82.	46626322 (48)	71.22	29	Cover Cushion IP60	
83.	46626323 (48)	71.22	28	4 Pivot Link L/H	
84.	46626324 (48)	71.22	25	4 Pivot Link R/H	
85.	46626325 (48)	71.22	51	2 Pivot Link L/H	
86.	46626328 (48)	71.22	31	2 Pivot Link R/H	
87.	46626329 (48)	71.22	30	Outer Side Rail Hinge L/H	
88.	46626333 (48)	71.22	41	Outer Side Rail Hinge R/H	
89.	46626338 (48)	71.09/4	19	3 Pivot Link L/H	
90.	46626339 (48)	71.09/4	3	3 Pivot Link R/H	
91.	46626361 (48)	71.25/3	2	Rivet Oup Shoulder	
92.	46626363 (48)	81.01/1	2	Seal »B« Pillar L/H	
93.	46626474 (48)	71.05/2	11	Seal »B« Pillar R/H	
94.	46626481 (48)	71.09/4	10	Emblem Yugo	
95.	46626482 (48)	71.09/4	11	Cover-Seat Back IP60	
96.	46626486 (48)	71.09	17	Underbody Cross Reinf	
97.	46626487 (48)	71.09	16	Front Door Channel R/H	
98.	46626488 (48)	71.16	4	Front Door Channel L/H	
99.	46626489 (48)	71.16	5	W/Strip-Inner Door	
100.	46626490 (48)	71.16	6	W/Strip-Outer Door	
101.	46626499 (48)	71.16	7	Tailgate Compl	
102.	46626629 (48)	81.02	16	Hinge Assy-Tailgate R/H	
103.	46626631 (48)	81.02	14	Hinge Assu-Tailgate L/H	
104.	46626642 (48)	71.09/3	13	Gas-Strut	
105.	46626643 (48)	71.09/3	14	Cushion Seat IP60	
106.	46626648 (48)	81.07/3	12	Seat-Back Compl IP60	
107.	46626649 (48)	81.07/3	13	Panel-Door IP60 R/H	
108.	46626650 (48)	81.07/3	14	Panel-Door IP60 L/H	
109.	46626652 (48)	81.07/2	3	A-Pillar Garnish Inr R/H	
				IP60	
				A-Pillar Garnish-Inr L/H	
				IP60	
				Windshield Garnish-Inr IP60	
				Qtr Trim Panel R/H	

1	2	3	4	5	6
110.	46626653 (48)	81.07/2	13	Qtr Trim Panel L/H	
111.	46626674 (48)	81.06	1	Carpet IP60	
112.	46626680 (48)	81.07/2	6	Visor R/H	
113.	46626681 (48)	81.07/2	7	Visor L/H	
114.	46626682 (48)	71.25/3	11	Emblem	
115.	46626683 (48)	71.25/3	11	Emblem	
116.	46627104 (58)	12.01	48	Support/Tank Fuel	
117.	46627321 (48)	71.09/4	20	Stud Plate Assy	
118.	46628006 (48)	81.07/2	9	Moulding-Doorsill R/H	
119.	46628007 (48)	81.07/2	10	Moulding Doorsill L/H	
120.	46628484 (58)	71.04/1	21	Rail R/H	
121.	46628485 (58)	71.04/1	22	Rail L/H	
122.	46628545 (58)	81.01/3	6	Seat Frame R/H	
123.	46628546 (58)	81.01/3	6	Seat Frame L/H	
124.	46628629 (48)	81.07/2	8	Clip	
125.	46628714 (48)	71.02	6	Panel-Dash	
126.	46629157 (48)	71.09/4	21	Washer-Glass	
127.	46629158 (48)	71.09	15	Moulding-Drip/Window	
128.	46629159 (48)	71.09	12	Door Opening W Strip	
129.	46629261 (48)	71.05/1	3	Panel-Front	
130.	46629531 (48)	81.02	23	Seat-Back Frame	
131.	46629534 (48)	81.07/2	1	Qtr Trim Cap R/H	
132.	46629535 (48)	81.07/2	2	Qtr Trim Cap L/H	
133.	46629541 (48)	71.18	3	Molding-Windshield Frame-Qtr	
134.	46629542 (48)	81.07/3	11	Tonneau Cover	
135.	46629781 (58)	62.01	1	Motor-Starter	
136.	46629932 (48)	81.07/2	11	Moulding-Carpet R/H	
137.	46629933 (48)	81.07/2	12	Moulding-Carpet L/H	
138.	46630044 (48)	71.16	11	W/Strip Tailgate	
139.	46630084 (48)	81.07/3	4	Mirror L/H Outer	
140.	46630085 (48)	81.07/3	3	Mirror R/H Outer	
141.	46630119 (48)	64.01/1	23	Lamp-Tail R/H	
142.	46630120 (48)	64.01/1	24	Lamp-Tail L/H	
143.	46630136 (48)	81.09	6	Insulation	
144.	46630224 (48)	81.02	20	Seat-Latch Cover L	
145.	46630225 (48)	81.02	19	Seat-Latch Cover D	
146.	46630438 (48)	81.07/3	7	Door Molding Outer Assy R/H	
147.	46630439 (48)	81.07/3	8	Door Molding Outer Assy L/H	
148.	46630444 (48)	81.07/3	9	Rear Qtr Molding-Otr R/H	
149.	46630445 (48)	81.07/3	10	Rear Qtr Molding-Otr L/H	
150.	46630451 (48)	71.22	11	Tackstrip	
151.	46630452 (48)	71.22	35	Topstack Mtg R/H	
152.	46630453 (48)	71.22	36	Topstack Mtg L/H	
153.	46630467 (48)	65.03/1	28	Switch-Sliding Roof	
154.	46630474 (48)	64.01/2	3	Harness-Wire	
155.	46630475 (48)	64.01/2	1	Harness Assy	
156.	46630476 (48)	64.01/2	12	Harness-Wire RR	
157.	46630625 (48)	81.07/3	1	Mirror-Inner Garnish R/H	
158.	46630626 (48)	81.07/3	2	Mirror-Inner Garnish L/H	
159.	46630649 (48)	71.22	14	Hyd Cyl System	
160.	46630669 (48)	71.18/1	6	W/Strip-W/Sheild	
161.	46630670 (48)	71.22	27	Header Skin Retainer	
162.	46630706 (48)	71.05/1	S	Panel R/H Rear Quarter Assy	
163.	46630851 (48)	71.18	4	Windshield	
164.	46630925 (48)	81.07/3	6	Mirror Garnish-Inr	
165.	46630937 (48)	71.16	10	Rod	
166.	46630956 (48)	81.02	22	Cable/Latch-Seat	

1	2	3	4	5	6
167.		46630977 (48)	81.07/2	4	Panel R/H Cargo
168.		46630978 (48)	81.07/2	5	Panel L/H Cargo
169.		46631185 (48)	71.22	42	Header Mnt Brkt R/H
170.		46631186 (48)	71.22	43	Header Mnt Brkt L/H
171.		46631187 (48)	71.22	21	Frst Side Rail R/H
172.		46631188 (48)	71.22	22	Frst Side Rail L/H
173.		46631189 (48)	71.22	44	Header Mnt Garnish R/H
174.		46631190 (48)	71.22	45	Header Mnt Garnish L/H
175.		46631191 (48)	71.22	15	B-Pillar Cam R/H
176.		46631192 (48)	71.22	16	B-Pillar Cam L/H
177.		46631194 (48)	71.22	2	Header
178.		46631195 (48)	71.22	3	2 Bow
179.		46631196 (48)	71.22	5	3 Bow
180.		46631197 (48)	71.22	6	4 Bow
181.		46631198 (48)	71.22	9	C-Pillar R/H
182.		46631199 (48)	71.22	10	C-Pillar L/H
183.		46631200 (48)	71.22	17	C-Pillar Seal Retainer R/H
184.		46631201 (48)	71.22	18	C-Pillar Seal Retainer L/H
185.		46631202 (48)	71.22	19	B-Pillar R/H
186.		46631203 (48)	71.22	20	B-Pillar L/H
187.		46631204 (48)	71.19	17	Glass-Rear
188.		43631205 (48)	71.22	23	Rear Side Rail R/H
189.		46631206 (48)	71.22	24	Rear Side Rail L/H
190.		46631209 (48)	71.22	32	5 Pivot Link R/H
191.		46631210 (48)	71.22	33	5 Pivot Link L/H
192.		46631211 (48)	71.22	7	Connect Link 4 Bow R/H
193.		46631212 (48)	71.22	8	Connect Link 4 Bow L/H
194.		46631213 (48)	71.22	12	Support/Hyd Cyl
195.		46631214 (48)	71.23	13	Support/Hyd Cyl
196.		46631215 (48)	71.22	46	Connect Link
197.		46631216 (48)	71.22	34	Qtr Window Seal Pivot
198.		46631219 (48)	71.22	4	Retainer 2 Bow
199.		46631234 (48)	71.09	1	Seal Front Side Rail
200.		46631235 (48)	71.09	2	Assy R/H
201.		46631253 (48)	71.22	26	Seal Front Side Rail
202.		46631270 (48)	81.06	3	Assy L/H
203.		46631361 (48)	71.22	47	Cable Assy
204.		46631362 (48)	71.22	48	Carpet (Storage) IP60
205.		46631389 (48)	64.01/1	25	Striker Topstack Lock R/H
206.		46631390 (48)	64.01/1	26	Striker Topstack Lock L/H
207.	46627384	46631501 (58)	12.01/2	10	Lamp-Back UP R/H
208.	46628842	46631502 (58)	12.01/2	8	Lamp-Back UP L/H
209.		46631525 (48)	81.07/2	11	Hose-Fuel
210.		46631527 (48)	71.19	20	Hose-Fuel Return
211.		46631528 (48)	71.19	22	Insulation
212.		46631626 (48)	71.05/1	15	Washer
213.		46631627 (48)	71.05/1	16	Plug
214.		46631629 (48)	71.04	8	Panel R/H Rear Quarter
215.		46631718 (48)	71.04/1	3	Panel L/H Rear Quarter
216.		46631763 (48)	91.01	4	Panel-Dash
217.		46631767 (48)	71.04	11	Pan-Floor
218.		46631768 (48)	71.04	7	Jack
219.		46631774 (58)	12.01/2	11	Wheel Box R/H
220.		46631829 (48)	71.09/4	17	Wheel Box L/H
221.		46631830 (48)	71.09/4	18	Filter-Fuel
222.	46629738	46631835 (58)	71.04/1	12	Regulator-Window R/H
223.	46630998	46631868 (58)	81.01/1	2	Regulator-Window L/H
224.	46631030	46631871 (58)	81.01/2	2	Support L/H
225.		46631951 (48)	71.05/2	12	Cover-Seat Back
					Cover-Cushion
					Lower Rocker Reinf R/H

1	2	3	4	5	6
226.		46631952 (48)	71.05/2	13	Lower Rocker Reinf L/H
227.		46631957 (58)	71.06/1	1	Protection
228.	46628536	46631964 (58)	65.01/1	6	Timer Electronic
229.		46631989 (48)	71.04/1	15	Wheeblox L/H
230.		46632386 (48)	64.01/1	21	Lamp-Tail
231.		46632470 (58)	31.02/1	13	Line-Brake L/H
232.		46632472 (58)	31.02/1	13	Line-Brake L/H
233.		46632477 (48)	81.07/2	16	Support-Mirror
234.		46632615 (48)	81.09/1	12	Insulation D
235.		46632616 (48)	81.09/1	13	Insulation L
236.	46631080	46632702 (58)	81.02/2	2	Cover-Seat Back
237.	46631083	46632705 (58)	81.02/1	2	Cover-Cushion
238.	91704705	46632712 (58)	81.02	16	Cushion-Seat Complete
239.	91704708	46632715 (58)	81.02	14	Seat-Back Complete
240.		46641727 (58)	12.21	8	Support
241.		46641979 (58)	65.01/2	13	Support/Silencer
242.		46641980 (58)	65.01/2	12	Bushing/Silencer
243.		91703995 (48)	81.01	2	O/S/F Seat Ass (Catapult)
					Grey
244.		91703996 (48)	81.01	18	N/S/F Seat Ass (Catapult)
					Grey
245.		91704257 (48)	71.16	1	Chanel
246.		91704258 (48)	71.09/1	9	Set-Lock Complet
247.	91704753	91704946 (58)	81.01	2	Seat-Front R/H Compl.
248.	91704754	91704947 (58)	81.01	18	Seat-Front L/H Compl.
249.	91704755	91704959 (58)	81.02	19	Seat-Rear Compl.

PART NUMBER LISTING REVISIONS

No	Replaced Part	Replacing Part	Subgroup	Illus No	Description
1	2	3	4	5	6
1.	—	1619157	24.01	17	Constant Velocity Joint
2.	—	5947210	24.01	2	Spider — Axle Shaft
3.	—	5947834	24.01	18	Bearing — Axle
4.	—	5950720	24.04	13	Sun Gear
5.	—	5952431	24.04	16	Crowms Pinion Assembly
6.	—	5963126	24.01	33	R/H Drive Shaft boot
7.	—	5963911	24.01	28	Rubber Bush
8.	—	7564489	24.01	32	L/H Drive Shaft Boot
9.	—	10516570	71.05	22	Washer
10.	—	11055090	64.01/3	22	Fuse (15 AMP)
11.	—	13275917	71.05	21	Screw
12.	—	14144690	66.33	7	Bulb-Lamp Tail
13.	—	14496507	71.05	17	Washer
14.	—	15688007	71.05	18	Screw
15.	—	40004360	24.01	31	Seal
16.	—	46618520	24.01	29	L/H Drive Shaft Boot (kit)
17.	—	46618521	24.01	30	R/H Drive Shaft Boot (kit)
18.	—	46619139	14.01	2	Cap
19.	—	46623256	65.03/1	9	Speedometer
20.	46623471	46625982	31.01	8	Pedal — Brake
21.	—	46626734	65.03/1	24	Harness — Wire
22.	—	46627767	71.04	11	Wheelbox R/H
23.	—	46627768	71.04	7	Wheelbox L/H
24.	—	46628870	12.01/3	23	Support
25.	—	46628872	12.01/3	22	Support
26.	—	46628883	12.01/3	21	Gasket
27.	—	46628884	12.01/3	20	Gasket
28.	—	46629364	64.01/1	14	Lamp-Back up
29.	—	46629364	64.01/1	25	Lamp-Back up
30.	—	46629365	64.01/1	15	Lamp-Back up
31.	—	46629365	64.01/1	26	Lamp-Back up
32.	—	46629595	24.01	13	Drive Shaft Boot Duter
33.	46630178	46631707	64.01/3	6	Relay
34.	—	46632347	24.01	27	Shaft-Axle L/H
35.	—	46632352	24.01	23	Shaft-Axle L/H
36.	—	46632355	24.01	3	Shaft-Axle R/H
37.	—	46632363	24.01	14	Shaft-Axle
38.	—	46632365	24.01	23	Shaft-Axle L/H
39.	—	46632368	24.01	14	Shaft-Axle (Zreče)
40.	46641923	46632407	61.01/1	1	Cable Assy
41.	—	46632530	71.05	19	Protection For Engine
42.	—	46632582	71.05	20	Support
43.	—	46632851	13.01/1	31	Sleeve Ø 5,5x1,5x580
44.	—	46633194	65.01/2	4	Line-fuel (Continental)
45.	—	46633195	65.01/2	2	Hose-Elektronik Directing
46.	46627318	46633241	12.01/2	32	Hose
47.	—	46633250	71.04/1	3	Pan-Floor
48.	—	46633251	71.04/1	4	Reinforcement-Floor Pan
49.	—	46633744	91.10	2	Label
50.	—	46634091	71.01	38	Weatherstrip
51.	—	46634221	71.18	8	Moulding R/H
52.	—	46634222	71.18	9	Moulding L/H
53.	—	46634223	71.18	7	Moulding
54.	—	46634224	71.18	10	Moulding
55.	46641339	46641987	61.01	16	Plug-spark
56.	—	91704516	22.01	13	Housing — Transmission
57.	—	91704920	22.01	4	Transmission
58.	—	91705077	14.01	1	Radiator-Cooling

PART NUMBER LISTING REVISIONS

No	Replaced Part	Replacing Part	Subgroup	Illus No	Description
1	2	3	4	5	6
1.		890414	43.01/1	2	Screw-Ball Joint
2.		902160	11.03/1	7	Plate-Thrust (Standard)
3.		902161	11.03/1	8	Plate-Thrust
4.		1423502	31.02/2	9	Brake-Servo
5.		1617136	12.01/2	56	Gasket
6.		4103528	31.01/1	11	Locktab-Brake Pedal Support
7.		4136475	31.30/1	15	Plate-Brake Disc
8.		4142528	31.30/1	16	Screw-Brake Disc Back Plate
9.		4202351	43.01/1	12	Cup-Coil Spring
10.		4202352	43.01/1	11	Spring-Coil/Front
11.		4218233 (50)	42.10	7	Track Rod End
12.		4221815	31.30/1	17	Stud-Wheel/Locating
13.		4233367 (50)	43.05	2	Spring-Leaf
14.		4233368 (50)	43.05	6	Spring-Leaf
15.		4233470	43.01/1	11	Spring-Coil/Front
16.		4238373	31.01/1	1	Pin-Brake Pedal
17.		4249840	31.01/1	6	Spring-Return/Brake Pedal
18.		4250679 (50)	43.05	1	Spring-Rear Suspension
19.		4269482	43.01/1	1	Washer-Ball Joint
20.		4366772	22.10	36	Spacer
21.		4382055	31.02/1	11	Connection
22.		4374303	43.01/1	14	Seal
23.		4390950	43.01/1	15	Ring
24.		4400893	43.01/1	9	Plate-Coil Spring
25.		4400894	43.01/1	10	Ring-Coil Spring
26.		4400895	43.01/1	8	Ring-Coil Spring
27.		4400896	43.01/1	7	Cup-Coil Spring
28.		4402362	43.01/1	4	Bushing-Ball Joint
29.		4402363	43.01/1	3	Spacer-Ball Joint
30.		4426922 (50)	43.01	8	Shaft Steering
31.		5988269	43.01/1	16	Lockwasher
32.		5988270 (50)	43.01/1	17	Shield
33.		5958301 (50)	31.02/1	18	Cylinder-Rear Brake
34.		7544738 (50)	43.02	25	Bushing
35.		7550273 (50)	43.02	26	Washer
36.	11197470	7554486	11.02	3	Washer
37.		7589575	13.01/1	17	Cap
38.		7610246	13.01/1	28	Oil Pump
39.		7612430	13.01/1	5	Dip Stick
40.		7663366	11.02	11	Gasket-Oil Pan
41.		10396380 (50)	12.01/2	49	Grommet
42.		10418201	65.01/1	26	Clamp/Conector-Diagnostic 05
43.		10516470	31.30/1	11	Washer-Lock
44.		10516570	71.05/2	18	Washer
45.		10516670	31.01/1	4	Washer-Lock
46.		10516871	10.01/1	32	Washer-Lock
47.		10517073 (50)	22.01	6	Washer
48.		10519601	12.04/3	18	Washer*
49.		10571570	12.01/2	54	Washer-Lock
50.		10571570	65.01/1	21	Washer-Lock
51.		10571770	22.07/2	12	Washer-Lock
52.		10720111	12.01/2	52	Nut
53.		10720111	65.01/1	22	Nut

1	2	3	4	5	6
54.		10725911	12.02/2	9	Nut-Heater Valve
55.		10734301	31.01/1	13	Pin-Cotter/Brake Pedal
56.		10902011	65.01/2	20	Screw
57.		10902111	71.06/1	18	Screw
58.	10902221	10902224	11.02	07	Bolt
59.		10979421	31.30/1	12	Washer
60.		11106221	22.01	10	Screw
61.		11195479	81.07/3	18	Washer
62.		11234727	22.01	17	Screw
63.		11306937	10.01/1	31	Screw
64.		12164717	22.01	18	Washer
65.		12164737	10.01/1	33	Washer
66.		12574511 (50)	43.02	1	Nut-Rear Suspension Strut
67.		12574521	43.01/1	5	Nut-Shock Absorber
68.		12574521	43.01/1	5	Nut-Shock Absorber
69.		12599071	12.02/2	8	Lockwasher
70.		12628901 (50)	12.01/2	55	Washer
71.		12638601	31.01/1	12	Washer
72.		12641001	22.01	11	Washer
73.		12643701 (50)	71.06/1	19	Washer
74.		12643701	71.06/1	—	Washer
75.		12646821	22.01	14	Washer
76.		12647001	31.01/1	9	Washer
77.		13000190	12.01/2	9	Clamp
78.		13000190	12.01/3	4	Clamp
79.		13000490	12.54/1	14	Clamp
80.	12182490	13000490	31.02/2	3	Clamp
81.	12182490	13000490	14.02/1	24	Clamp
82.		13000490	31.02/2	3	Clamp
83.		13000690	14.02/1	23	Clamp
84.	12181090	13000890	12.01/2	17	Clamp
85.		13276017	71.05/2	19	Screw MG
86.		13336303	22.07/2	16	Washer
87.		13516811	12.04/3	17	Stud M8x12x20
88.		14048727	43.01/1	13	Nut
89.		14205480 (50)	31.02/2	5	Hose (O11x19x425)
90.		14328201	11.03/1	1	Plug-Crankshaft
91.		14348670	11.03/1	3	Bolt-Flywheel*
92.		14496401 (50)	12.01/2	53	Washer
93.		14496501	31.01/1	3	Washer
94.		14496507 (50)	31.02/1	4	Washer
95.		14496521 (50)	43.02	17	Washer
96.		14560180 (50)	64.01/2	25	Strap
97.		14568380 (50)	51.01	18	Clamp
98.		14572680	64.01/2	32	Clip
99.		15505911 (50)	43.02	27	Nut
100.		15540521	22.01	4	Screw
101.		15540921	22.01	7	Screw
102.		15687201 (50)	12.01/2	51	Screw
103.		15688001	31.01/1	10	Screw
104.		15896211	11.02	38	Nut
105.		15896411	81.07/3	17	Nut
106.		15903801 (50)	71.06/1	20	Screw
107.		15904107	71.06	1	Screw
108.		15904107	71.06	1	Screw
109.		15970527	22.01	13	Screw M10x1,25x20
110.		15970927	22.01	16	Screw M10x1,25x35
111.		15971621	22.01	12	Washer
112.		16100811	12.04/3	19	Nut
113.		16100811	31.01/1	5	Nut
114.		16101511	22.01	5	Nut

1	2	3	4	5	6
115.		16102211	43.02	15	Nut
116.		40001720	24.01/1	10	Seal-Axle Shaft*
117.		46602156	11.03/1	9	Bearing Set-Crankshaft
118.		46602157	11.03/1	10	Set-Bearing 254 Crankshaft
119.		46602158	11.03/1	11	Set-Bearing 508 Crankshaft
120.		46602159	11.03/1	12	Set-Bearing 762 Crankshaft
121.		46602617 (50)	31.30/1	21	Brake Pade (Seat)
122.		46602618 (50)	31.30/1	10	Caliper RepairKit
123.		46602621 (50)	66.08/2	—	Bushing
124.		46602992 (50)	66.08/2	—	Support
125.		46602993 (50)	66.08/2	—	Stator
126.		46602994 (50)	66.08/2	—	Rotor
127.		46618324 (50)	43.01/1	6	Track Control Arm
128.		46618471 (50)	43.01/1	18	Support L/H
129.		46618472 (50)	43.01/1	19	Support R/H
130.		46618703 (50)	31.30/1	20	Brake Disc
131.		46618781 (50)	31.30/1	19	L/H Brake Caliper (Assembly)
132.		46618782 (50)	31.30/1	18	L/H Brake Caliper (Assembly)
133.		46618785 (50)	31.30/1	7	L/H Caliper
134.		46618786 (50)	31.30/1	6	L/H Caliper
135.		46618793 (50)	31.30/1	9	Seal-Caliper
136.		46618794 (50)	31.30/1	8	Seal-Caliper
137.		46618795 (59)	31.30/1	5	Bleed Screw
138.		46618796 (50)	31.30/1	1	Support
139.		46618799 (50)	31.30/1	2	Guide
140.		46618800 (50)	31.30/1	3	Seal
141.		46618920 (50)	31.30/1	4	Cap
142.		46619043	71.04/1	25	Clip
143.		46619043	71.04/1	25	Clip
144.		46619103 (50)	31.02/2	1	Brake Reservoir Cap
145.		46619154 (50)	10.01/1	34	Support-Transmission
146.		46619155 (50)	10.01/1	35	Support-Transmission
147.	4391371	46619214	11.02	42	Pan-Oil
148.		46619258 (50)	12.56/1	32	Lining
149.		46619262 (50)	31.01/1	2	Gasket
150.		46619423	14.02/1	11	Spacer
151.		46619619	12.56/1	32	Lining
152.		46622039	71.09/2	46	Weatherstrip L/H
153.		46623778	51.01	5	Sleeve
154.		46624009 (50)	42.01	8	shaft-Steering
155.		46625106	71.02	23	Console/Radio Utility
156.		46626001	31.02/1	8	Line Brake
157.		46626003	31.02/1	8	Line Brake
158.		46626077	31.30/1	14	L/H Brake Disc Cover
159.		46626078 (50)	31.30/1	13	L/H Brake Disc Cover
160.		46626244	71.05/2	16	A-Pillar Seal Retainer R/H
161.		46626245	71.05/2	17	A-Pillar Seal Retainer R/H
162.		46627808	12.04/3	22	Housing-Air Filter/Lower
163.		46627828	13.01/1	33	Element-Oil Separator
164.		46628083 (50)	31.32	3	R/H Brake Back Plate
165.		46628084 (50)	31.32	4	L/H Brake Back Plate
166.		46629287	13.01/1	34	Clamp
167.		46629465 (50)	24.01/1	2	Spider-Axle Shaft
168.		46629595 (50)	24.01/1	13	Drive Shaft Boot Duter
169.		46629958 (50)	51.07	7	Connection
170.		46630354 (50)	31.02/1	17	House-Front Brake
171.		46630433	12.04/3	20	Bushing
172.		46630823	12.04/3	21	Hose
173.		46630998 (50)	81.01/1	2	Cover-Seat Back IP60
174.		46631080 (50)	81.02/1	2	Cover-Seat
175.		46631083 (50)	81.02/1	2	Cover-Cushion
176.		46631126	71.25/3	9	Emblem GV Plus
177.		46631155	71.09/3	13	Panel-Door IP60 R/H

1	2	3	4	5	6
178.		46631156	71.09/3	14	Panel-Door IP60 L/H
179.	46641572	46631504	12.54/1	02	Line-Fuel (Continental)
180.		46631576 (50)	24.01/1	26	Cover-C. V. Joint
181.		46631578 (50)	24.01/1	11	Boot-C. V. Joint
182.		46631579 (50)	24.01/1	9	Bushing/Shaft-Axle L/H
183.		46631581 (50)	24.01/1	32	Hub-Axle Shaft R/H
184.		46631582 (50)	24.01/1	8	Boot-C. V. Joint
185.		46631583 (50)	24.01/1	29	Bushing Axle Shaft R/H
186.		46631585 (50)	24.01/1	30	Washer-Axle Shaft R/H
187.		46631586 (50)	24.01/1	31	Ring-Axle Shaft R/H
188.		46631588 (50)	24.01/1	28	Collar-C. V. Joint Boot
189.		46631589	24.01/1	7	Clamp
190.		46631593	71.04	3	Reinforcement-R/H Inner Fender
191.		46631594	71.04	6	Reinforcement-L/H Inner Fender
192.		46631826 (50, 58)	91.01	4	Jack
193.		46631945	71.25/3	10	Emblem Efi
194.		46632335 (50)	12.01/2	50	Support
195.		46632530	71.05	4	Protection For Engine
196.		46632795	81.09	6	Insulation
197.		46632824 (58)	14.02	22	Hose-Radiator
198.		46632870 (50)	42.10	2	End Tie Rod
199.		46632871 (50)	42.10	5	End Tie Rod
200.		46632872 (50)	42.10	6	Ducting End Tie Rod
201.		46632884 (50)	31.02/2	4	Cylinder-Brake Masters
202.	46631503	46633193	12.26	8	Line-Fuel (Continental)
203.		46633473 (50)	43.02	10	Bar-Stabilizer
204.		46633481 (50)	42.01	7	Support Stering Column
205.		46633489 (50)	31.01/1	1	Support-Brake Pedal
206.		46633556 (58)	81.06	1	Carpet
207.		46633781 (50)	71.02	15	Cover-Stering Column IP60
208.		46633819 (50)	42.02	32	Nut M21x1
209.		46633827	42.01/1	3	Box-Stering
210.		46633851	31.01/1	14	Pedal Brake
211.		46633852 (50)	31.01/1	8	Shaft
212.		46633894 (50)	24.01/1	23	Shaft-Axle L/H
213.		46633896 (50)	24.01/1	14	Shaft-Axle (Löbro-Fiat)
214.		46633898 (50)	24.01/1	23	Shaft-Axle L/H
215.		46633900 (50)	24.01/1	14	Shaft-Axle (Zwickau DDR)
216.		46633902 (50)	24.01/1	23	Shaft-Axle (Löbro-Zreče)
217.		46633904 (50)	24.01/1	14	Shaft-Axle R/H (Löbro-Zreče)
218.		46633922 (50)	24.01/1	3	Shaft-Axle R/H
219.		46633923 (50)	24.01/1	27	Shaft-Axle L/H
220.		46633924 (50)	24.01/1	19	Key
221.		46633935 (50)	22.07/2	1	Support
222.		46633946 (50)	22.01	2	Plate
223.		46633958 (50)	11.03/1	5	Nut
224.		46633967 (50)	22.01	24	Protection/Transmission
225.		46633968 (50)	22.01	25	Protection/Transmission
226.		46633972 (50)	22.01	1	Transmission
227.		46633986 (50)	31.02/1	15	Line-Brake
228.		46633988 (50)	31.02/1	15	Line-Brake
229.		46633990 (50)	31.02/1	1	Line-Brake
230.		46633992 (50)	31.02/1	2	Line-Brake
231.		46633994 (50)	31.02/1	1	Line-Brake
232.		46633996 (50)	31.02/1	2	Line-Brake
233.		46633998 (50)	31.02/1	11	Line-Brake L/H
234.		46634000 (50)	31.02/1	12	Line-Brake R/H
235.		46634002 (50)	31.02/1	12	Line-Brake R/H
236.		46634004 (50)	31.02/1	11	Line-Brake L/H
237.		46634007 (50)	22.01	3	Clip

1	2	3	4	5	6
238.		46634008 (50)	22.01	6	Screw
239.		46634009 (50)	22.01	7	Washer
240.		46634011 (50)	22.01	4	Screw
241.		46634012	22.01	5	Washer
242.		46634032 (50)	71.05	5	Fender L/H Front
243.		46634036 (50)	22.07/2	11	Gearshift Outer Controls
244.		46634041 (50)	22.07/2	10	Lockwasher
245.		46634044 (50)	22.07/2	9	Lever-Shift Control
246.		46634045 (50)	22.07/2	5	Lever
247.		46634046 (50)	22.07/2	6	Key
248.		46634047 (50)	22.07/2	8	Ring
249.		46634048 (50)	22.07/2	4	Gasket-Transmission Housing
250.		46634049 (50)	22.07/2	7	Nut
251.		46634050 (50)	22.07/2	2	Nut
252.		46634051 (50)	22.24	5	Cable-Speedometer (Teleoptik)
253.		46634053 (50)	22.24	5	Cable-Speedometer MMG
254.		46634055 (50)	22.24	9	Retainer
255.		46634062 (50)	22.01	8	Lever-Transission
256.		46634076 (50)	71.04	4	Support
257.		46634081 (50)	71.04	7	Wheelbox L/H
258.		46634083 (50)	71.04	8	Panel-Dash
259.		46634084 (50)	71.04	1	Stone Guard
260.		46634089 (50)	71.04/1	3	Pan-Floor
261.		46634125	71.04/1	4	Reinforcement—Floor Pan
262.		46634160 (50)	81.09/1	1	Insulator
263.		46634161 (50)	81.06	1	Carpet IP60
264.		46634162 (50)	22.07/2	14	Housing-Transmission
265.		46634166 (50)	71.02	6	Panel-Dash IP60
266.		46634180 (50)	12.01/2	41	Ducting
267.		46634191 (50)	71.06	6	Protection IP60
268.		46634195 (50)	12.01/2	30	Line Fuel Vapor
269.		46634213 (48)	81.07/3	16	Cover
270.		46634214 (48)	81.07/3	15	Clip
271.		46634220 (50)	71.25/3	12	Type Plate
272.		46634235 (50)	62.01	1	Motor-Starter (Iskra)
273.		46634249 (50)	12.56/1	1	Pipe-Front Exhaust
274.		46634271 (50)	64.01/2	3	Harness-Wire
275.		46634272 (50)	64.01/2	1	Harness-Assy
276.		46634273 (50)	64.01/2	12	Harness-Wire RR
277.		46634275	65.01/2	9	Cable-Assy Electronic Directing
278.		46634288 (50)	65.01/1	25	Support
279.		46634289 (50)	65.01/1	24	Strap
280.		46634290	65.03/1	1	Cluster-Instrument
281.		46634291	65.03/1	9	Spedometer For 46634290
282.	46626767	46634324	12.01/2	36	Tank-Fuel Complete
283.	46626768	46634325	12.01/2	35	Tank-Fuel
284.		46634339	11.03/1	6	Plate
285.		46634341	11.03/1	4	Spacer
286.		46634342	11.03/1	13	Washer
287.		46634409	22.07/2	3	Support
288.		46634419 (50, 58)	71.02	30	Housing-Cig/Lighter
289.		46634420 (50, 58)	71.02	31	Element-Cig/Lighter
290.		46634472 (50)	51.01	5	Hose-Heater
291.		46634473 (50)	51.01	10	Hose-Heater
292.		46634487 (50)	22.01	3	Lockwasher
293.		46634488 (50)	22.01	15	Washer
294.		46634488	22.01	9	Washer
295.		46634630 (58)	65.03/1	1	Cluster-Instrum (Teleoptik)
296.		46634631 (58)	65.03/1	1	Cluster-Instrum (MMG)
297.		46634718	31.01/1	15	Pad-Pedal

1	2	3	4	5	6
298.		46634721	31.02/1	10	Pressure Regulator-By Pass
299.		46634721 (50)	31.02/1	10	Pressure Regulator-By Pass
300.		46634897 (50)	13.01/1	5	Dipstick
301.		46634920 (50)	22.01	1	Support
302.		46634956 (50)	12.04/3	26	Plate
303.		46634958 (50)	12.04/3	27	Screw
304.		46634963 (50)	24.01/1	33	Key
305.		46634993 (50)	31.02/1	5	Support-Pressure Regulator
306.		46634997 (50)	65.01/1	23	Support
307.	46629239	46635053	12.01/2	1	Sending Unit
308.		46635079	65.03/1	30	Gauge-Fuel (Teleoptik)
309.		46635080	65.03/1	29	Gauge-Fuel MMG
310.		46635087	12.56/1	31	Shaft/Support Fuel Pump
311.		46635142	14.02/1	22	Hose
312.		46635143	24.01/1	6	Shaft/Support Fuel Pump
313.	46626800	46635186	12.02/2	7	Shaft/Support Fuel Pump
314.		46635200	14.02/1	19	Hose
315.		46635201	14.02/1	17	Hose
316.		46635203	14.02/1	21	Hose
317.	46630773	46635217	12.01/3	19	Line-Fuel
318.	46626906	46635218	12.01/3	18	Line-Fuel Return
319.	46626905	46635219	12.01/3	19	Line-Fuel
320.	46630774	46635220	12.01/3	18	Line-Fuel Return
321.		46635230	71.06/1	1	Protection
322.		46635311 (50)	65.01/2	1	Electronic Directing Unit (Bosch)
323.		46635404 (50)	10.01/1	13	Support Engine
324.		46635419 (50)	22.01	2	Support/Cable Transmission
325.		46635426 (50)	24.01/1	1	Clip-Spider Joint
326.		46635458	13.01/1	4	Housing
327.		46635461 (50, 58)	81.08	1	Support-Spare Tire
328.		46635472	81.01/3	6	Seat Frame R/H
329.		46635473	81.01/3	6	Seat Frame L/H
330.		46635513	22.01	19	Protection/Transmission
331.		46635514 (50)	22.01	23	Support/Protection
332.		46635560 (50, 58)	71.02	23	Console
333.		46635566 (50)	81.01/2	2	Cover Cushion IP60
334.		46635639 (50)	71.06/1	4	Protection
335.		46635747 (50)	65.01/2	1	Electronic Directing
336.		46635963 (50)	13.01/1	37	Hose Imanifold-Intake
337.		46635964 (50)	65.01/2	4	Hose/Silencer
338.		46635965 (50)	13.01/1	35	Hose/Automatic Transmission
339.		46636126 (50)	31.02/1	11	Line Brake L/H
340.		46636598 (50)	31.02/1	2	Reservoir-Master Cylinder
341.		46641457 (58)	11.02	41	Gasket 35x47x7
342.	14325301	46641713 (58)	11.02	40	Plug
343.		46641714 (58)	11.02	39	Washer
344.		46641849 (58)	11.03/1	2	Camshaft
345.		46641854 (58)	12.04/3	—	Sending Unit-Fuel Flow
346.		46641855 (58)	12.04/3	4	Throttle
347.		46641979	12.04/3	23	Support/Silencer
348.		46641980	12.04/3	24	Bushing/Silencer
349.		46642031 (50)	14.02/1	20	Thermostat
350.		46642041 (50)	10.01	4	Engine-Complete
351.		46642062 (50)	11.01	20	Head-Cylinder
352.		46642064	14.02/1	6	Hose-Radiator Expansion
353.		46642067	14.02/1	1	Hose Water O 7,5x510
354.	46641512	46642071	12.26	5	Pressure Regulator
355.		46642314 (50)	12.21	11	Support
356.		46642315 (50)	12.04/3	28	Support
357.		91705052	42.01	4	Column-Steering
358.		91705276	81.01	18	Seat-Front Complet L/H
359.		91705277	81.01	2	Seat-Front Complet R/H
360.		91705302 (50)	81.02	19	Seat-Rear Complete IP60