



1. 2. 3. 4.	10791411 46620110 46620112 46620638 91705052 (50)	NUT - STEERING WHEEL WHEEL - STEERING IP20 WHEEL - STEERING IP60 COLUMN - STEERING COLUMN - STEERING
	46636134 (50)	COLUMN - STEERING
5.	4460398	BUSHING - STEERING COLUMN
6.	4460399	SHAFT - STEERING COLUMN
7.	46620639	SUPPORT STEERING COLUMN
	46633481 (50)	SUPPORT STEERING COLUMN
8.	46620044	SHAFT - STEERING
	4426922 (50)	SHAFT - STEERING
	46624009 (50)	SHAFT - STEERING
9.	10519601	WASHER
10.	10516470	WASHER - LOCK
11.	16100811	NUT
12.	4289140	WASHER - STEER/COLUMN SUPPORT
13.	4111357	BOLT - STEERING COLUMN SUPPORT
14.	16042637	SCREW
	16235437	SCREW (M8 x 35)
15.	16104421	NUT - STEERING COLUMN
16.	46636085 (50)	SHAFT - STEERING FOR 46636134

42,01



1. 2. 3.	4179802 4179801 1024628	BUSHING - STEERING RACK BRACKET - STEERING RACK BOX - STEERING
J •	46633827 (50)	BOX - STEERING
4.	4169380	BUSHING - STEERING RACK
5.	4169379	BRACKET - STEERING RACK
6.	10516671	WASHER - LOCK
7.	16043421	SCREW
8.	4210542	COVER - SHAFT
9.	17671301	SCREW
10.	4200425	SHIELD - STEERING BOX
11.	14215282	CLIP - STEERING COLUMN




STEERING BOX


42.02

```
1024645
1,
                       BUSHING - STEERING RACK
 2.
      1024647
                       BOOT - STEERING RACK
      1024629
                       HOUSING
      1611877
                       BRACKET - STEERING RACK BOOT
 5.
                       BEARING - STEERING SHAFT
      1024657
 6.
      1024658
                       RACK - STEERING
 7.
      1024651
                       SHAFT - PINION/STEERING
 8.
      1024644
                       GASKET - STEERING SHAFT
      1024650
9.
                       SCREW - STEERING SHAFT
10.
                       PLATE - STEERING SHAFT
      1024632
11.
                       GASKET - STEERING SHAFT
      1024634
12.
      1024652
                       RING 0,12
13.
      1024653
                       RING 0,20
14.
      1024654
                       RING 0,25
15.
      1024655
                       RING 2,50
16.
      1024666
                       NUT - STEERING RACK
17.
      1024660
                       SPRING - STEERING RACK
18.
      1024664
                       GUARD - STEERING RACK
19.
      1024663
                       PIN - STEERING RACK
20.
      1024665
                       NUT - STEERING RACK
21.
      1611878
                       BRACKET - STEERING RACK BOOT
22.
      1024646
                       BOOT - STEERING RACK
23.
                       SCREW (*1)
     13824521
     10902421
                       SCREW (*1)
24.
      1611876
                       COLLAR - STEERING RACK BOOT
25.
      1024633
                       COVER - STEERING BOX
26.
      1024661
                       SPRING
27.
      1024641
                       SHIM 0,15 - STEERING BOX ADJUSTING
28.
      1024640
                       SHIM 0,10 STEERING BOX ADJUSTING
29.
      1024656
                       SEAL - STEERING BOX
30.
                       PLUT - STEERING BOX
      1024659
31.
     10516421
                       WASHER
32.
    46633819 (50)
                       NUT M 21 x 1
NOTE 1: 13824521 CANCELED ITEM
```

13824521 = 10902421 + 10516421 - INTRODUCED ITEM




1. 2. 3. 4. 5. 6.	4191151 1615851 46632870 4306182 12575611 46632871 46632872	(50) (50)	NUT - TIE ROD END TIE ROD END TIE ROD CUP - TIE ROD END NUT END TIE ROD PIPE
7.	4218233		END TIE ROD



1. 2. 3. 4. 5. 6.	46633875 (58)	WASHER - BALL JOINT SCREW - BALL JOINT SPACER - BALL JOINT BUSHING - BALL JOINT (*2) JOINT - BALL/ASSY JOINT - BALL/ASSY JOINT - BALL/ASSY
7.	4400896	CUP - COIL SPRING
8.	4400895	RING - COIL SPRING
9.	4400893	PLATE - COIL SPRING
10.	4400894	RING - COIL SPRING
11.	4202352	SPRING - COIL/FRONT
	4233470 (31)	SPRING - COIL/FRONT
	46629385 (58,48)	SPRING - COIL/FRONT
12.	4202351	CUP COIL SPRING
13.	14048727	NUT
14.	4248947	SUPPORT R/H
15.	4248946	SUPPORT L/H
16.	16105111	NUT - BALL JOINT
17.	4443886	CUP (*1)
18.	4476293	SUPPORT L/H (*1)
19.	4476294	SUPPORT R/H (*1)


NOTE 1: 1 ST TYPE USED FROM CAR NO 10364 VIN 367846 NOTE 2: FOR MODEL (58) CANCELLED ITEM (VI 1991.)



FRONT SUSPENSION COMPONENTS

43.01/1

1.	4269482	WASHER - BALL JOINT
2.	890414	SCREW - BALL JOINT
3.	4402363	SPACER - BALL JOINT
4.	4402362	BUSHING - BALL JOINT
5.	12574521	NUT
6.	46634158 (50.)	JOINT - BALL/ASSY
	46634159 (50)	JOINT - BALL/ASSY
7.	4400896	CUP - COIL SPRING
8.	4400895	RING - COIL SPRING
9.	4400893	PLATE - COIL SPRING
10.	4400894	RING - COIL SPRING
11.	4202352 (58)	SPRING - COIL/FRONT
	4233470 (50)	SPRING - COIL/FRONT
12.	4202351	CUP COIL SPRING
13.	14048727	NUT
14.	4374303	SEAL
15.	4390950	CUP
16.	5988269	SPACER
17.	5988270	SHIELD
18.	46618471 (50)	SUPPORT L/H
19.	46618472 (50)	SUPPORT R/H




FRONT SHOCK ABSORBER AND STABILIZER BAR

43.02

1. 14048717 12574511 2. 4400904 3. 4400905 4. 4408340 6. 46620911 46621478 46623355	(50)	NUT NUT WASHER - FRONT STRUT SUPPORT - SHOCK ABSORBER WASHER FRONT STRUT BOOT - FRONT STRUT ABSORBER - SHOCK/FRONT (MONROE) ABSORBER - SHOCK/FRONT (WAY ASSAUTO) ABSORBER - SHOCK FRONT (WAY ASSAUTO)
46623356 7. 4188857 8. 12164711 9. 10516870 10. 4425435		ABSORBER - SHOCK FRONT (MONROE) BOLT - SHOCK ABSORBER NUT WASHER - LOCK BAR - STABILIZER
46622342 46633473 11. 4233064 12. 4233062	(50)	BAR - STABILIZER BAR - STABILIZER BRACKET - STABILIZER BAR BUSHING - STABILIZER BAR
46623241 13. 4306439 14. 16138921 15. 16100811		BUSHING - STABILIZER BAR BRACKET - STABILIZER BAR BOLT - STABILIZER BAR BRKT NUT
16102211 16. 10516673 17. 10519621 14496521	(50)	NUT WASHER - LOCK WASHER - FRONT STRUT WASHER - FRONT STRUT
26. 7550273	, ; ;	


NOTE 1: CANCELLED ITEM FOR MODEL (58) (VI 1991.)




REAR SUSPENSION COMPONENTS

43.05

1.	4250679 (50) 4248910	SPRING - REAR SUSPENSION SPRING - REAR SUSPENSION
2.	4188790	SPRING - REAR SUSPENSION SPRING - LEAF
	4233367 (50)	
3.	4171090	BAND LEAF SPRING
4.	4178800	SPRING - LEAF
5.	4200619	BRACKET - LEAF SPRING
6.	4188789	SPRING - LEAF
	4233368 (50)	SPRING - LEAF
7.	970490	WASHER - REAR SUSPENSION
8.	4426882	ARM - SWING
9.	4329658	ROD - REAR SUSPENSION
10.	4251115	WASHER - REAR SUSPENSION
11.	14048811	NUT - REAR SUSPENSION
12.	4404622	BUSHING
13.	4402134	SUPPORT - REAR LEAF SPRING
14.	10519401	WASHER
15.	10516471	WASHER - LOCK
16.	10902421	SCREW
17.	4188797	BUMPER - REAR SUSPENSION
18.	12626201	WASHER
19.	10516873	WASHER - LOCK
20.	12164711	NUT
21.	10516870	WASHER - LOCK
22.	12574521	NUT - REAR SUSPENSION STRUT
23.	4223398	BOLT - REAR SHOCK
24.	4246743	BOLT - REAR SHOCK
25.	46620912	
	46621499	ABSORBER - SHOCK/REAR (WAY ASSAUTO)
26.	4249852	PAD
27.	4227114	BUSHING
28.	4227113	WASHER - REAR SHOCK
29.	12575611	NUT
30.	4459433	PAD
31.	12574511	NUT - REAR SUSPENSION STRUT
32.	1618222	BUMPER - REAR SUSPENSION
33.	4427327	CAP
34.	46622156	PROTECTIVE COVER (PLASTIC)






43,16

ROAD WHEELS

43.16

1. 2. 3. 4. 5. 6. 7. 8. 9. 10. 11. 12.	4381043 4410279 1617708 1617531 1617532 1617533 1617534 1617535 5936826 5936827 5936828 5936829	HUB CAP - HUB WEIGHT - BALANCE
14. 15.	5936830 5936831	WEIGHT - BALANCE
16.	5936832	WEIGHT - BALANCE WEIGHT - BALANCE
17.	5936833	WEIGHT - BALANCE
18.	4411390	BOLT - WHEEL
19,	46621141	COVER - WHEEL
00	46623818	COVER - WHEEL
20.	46621262	CAP - TIRE VALVE
21.	1618853 46621491 (22)	VALVE - TIRE VALVE - TIRE
22.	1618923	WHEEL - ROAD
23.	46624892 (22) 46626045	WHEEL - ROAD (BLACK) COVER - WHEEL




ROAD WHEELS

43.16/1

1.	4381043	HUB
2.	4410279	CAP - HUB
3.	46622121*	WEIGHT - BALANCE
4.	46622122*	WEIGHT - BALANCE
5.	46622123*	WEIGHT - BALANCE
6.	46622124*	WEIGHT - BALANCE
7.	46622125*	WEIGHT - BALANCE
8.	46622126*	WEIGHT - BALANCE
9.	46622127*	WEIGHT - BALANCE
10.	46622128*	WEIGHT - BALANCE
11.	46622129*	WEIGHT - BALANCE
12.	46624959	SCREW $(M6x16,5)$
13.	46624309	PLATE - ROAD WHEEIS
14.	4357962	BCLT - WHEEL
15.	46622814	WHEEL - ROAD
16.	46620897	CAP - TIRE VALVE
17.	1618853	VALVE TIRE
18.	46624892	SPARE WHEEL - ROAD (BLACK)
19.	46622815	COVER - WHEEL

NOTE(*):FOR 46622814



1. 2. 3. 4308418 4307324

SHAFT - STUB/REAR

4307325